

**YAMAHA**

**FZS600 '98**

**5DM1-AE1**

**SERVICE MANUAL**

# HOW TO USE THIS MANUAL

This manual is intended as a handy, easy-to-read reference book for the mechanic. Comprehensive explanations of all installation, removal, disassembly, assembly, repair and inspection procedures are laid out with the individual steps in sequential order.

① The manual is divided into chapters. An abbreviation and symbol in the upper right corner of each page indicate the current chapter. Refer to "SYMBOLS" on the following page.

② Each chapter is divided into sections. The current section title is shown at the top of each page, except in Chapter 3 ("Periodic Inspections and Adjustments"), where the sub-section title (-s) appear.

(In Chapter 3, "Periodic Inspections and Adjustments", the sub-section title appears at the top of each page, instead of the section title.)

③ Sub-section titles appear in smaller print than the section title.

④ To help identify parts and clarify procedure steps, there are exploded diagrams at the start of each removal and disassembly section.

⑤ Numbers are given in the order of the jobs in the exploded diagram. A circled number indicates a disassembly step.

⑥ Symbols indicate parts to be lubricated or replaced (see "SYMBOLS").

⑦ A job instruction chart accompanies the exploded diagram, providing the order of jobs, names of parts, notes in jobs, etc.

⑧ Jobs requiring more information (such as special tools and technical data) are described sequentially.

CLUTCH    ENG

CLUTCH

⑤

Order	Job name/Part name	Q'ty	Remarks
<b>Removing the clutch</b>			
1	Compression spring	6	Remove the parts in the order listed.
2	Pressure plate	1	
3	Short clutch push rod	1	
4	O-ring	1	
5	Ball	1	
6	Long clutch push rod	1	
7	Friction plate	8	
8	Clutch plate	8	
9	Friction plate (large)	1	
10	Clutch spring plate	1	
11	Nut	1	

⑦

CLUTCH    ENG

CLUTCH

③

**REMOVING THE CLUTCH**

1. Straighten the lock washer tab.
2. Loosen:
  - clutch boss nut ①

**NOTE:**  
While holding the clutch boss ② with the universal clutch holder ③, loosen the clutch boss nut.

Universal clutch holder ③  
90890-04086

3. Remove:
  - spacer ①
  - bearing ②

**NOTE:**  
Insert two M6-mm bolts ③ into the spacer and then remove the spacer by pulling on the bolts.

**CHECKING THE FRICTION PLATES**  
The following procedure applies to all of the friction plates.

1. Check:
  - friction plate  
Damage/wear → Replace the friction plates as a set.
2. Measure:
  - friction plate thickness  
Out of specification → Replace the friction plates as a set.

**NOTE:**  
Measure the friction plate at four places.

Friction plate thickness  
2.94 - 3.06 mm  
◀Limit: 2.8 mm

**CHECKING THE CLUTCH PLATES**  
The following procedure applies to all of the clutch plates.

1. Check:
  - clutch plate  
Damage → Replace the clutch plates as a set.
2. Measure:
  - clutch plate warpage (with a surface plate and thickness gauge ①)  
Out of specification → Replace the clutch plates as a set.

Clutch plate warpage limit  
Less than 0.1 mm

⑧

4-32

4-34

## SYMBOLS

The following symbols are not relevant to every vehicle.

Symbols ① to ⑨ indicate the subject of each chapter.

- ① General information
- ② Specifications
- ③ Periodic inspection and adjustment
- ④ Engine
- ⑤ Cooling system
- ⑥ Carburetor(-s)
- ⑦ Chassis
- ⑧ Electrical system
- ⑨ Troubleshooting

Symbols ⑩ to ⑰ indicate the following.
























- ⑩ Serviceable with engine mounted
- ⑪ Filling fluid
- ⑫ Lubricant
- ⑬ Special tool
- ⑭ Tightening torque
- ⑮ Wear limit, clearance
- ⑯ Engine speed
- ⑰ Electrical data

Symbols ⑱ to ⑳ in the exploded diagrams indicate the types of lubricants and lubrication points.









- ⑱ Apply engine oil
- ⑲ Apply gear oil
- ⑳ Apply molybdenum disulfide oil
- ㉑ Apply wheel bearing grease
- ㉒ Apply lightweight lithium-soap base grease
- ㉓ Apply molybdenum disulfide grease


Symbols ㉔ to ㉕ in the exploded diagrams indicate the following:

- ㉔ Apply locking agent (LOCTITE®)
- ㉕ Use new one

① GEN INFO 	② SPEC 	
③ INSP ADJ 	④ ENG 	
⑤ COOL 	⑥ CARB 	
⑦ CHAS 	⑧ ELEC 	
⑨ TRBL SHTG ?	⑩ 	
⑪ 	⑫ 	
⑬ 	⑭ 	
⑮ 	⑯ 	⑰ 
⑱ 	⑲ 	⑳ 
㉑ 	㉒ 	㉓ 
㉔ 	㉕ <b>New</b>	

# INDEX

<b>GENERAL INFORMATION</b>	
	<b>GEN INFO</b> <b>1</b>
<b>SPECIFICATIONS</b>	
	<b>SPEC</b> <b>2</b>
<b>PERIODIC INSPECTIONS AND ADJUSTMENTS</b>	
	<b>CHK ADJ</b> <b>3</b>
<b>ENGINE</b>	
	<b>ENG</b> <b>4</b>
<b>COOLING SYSTEM</b>	
	<b>COOL</b> <b>5</b>
<b>CARBURETORS</b>	
	<b>CARB</b> <b>6</b>
<b>CHASSIS</b>	
	<b>CHAS</b> <b>7</b>
<b>ELECTRICAL SYSTEM</b>	
	<b>ELEC</b> <b>8</b>
<b>TROUBLESHOOTING</b>	<b>?</b>
	<b>TRBL SHTG</b> <b>9</b>




**GEN  
INFO**

**1**

---

## CHAPTER 1 GENERAL INFORMATION

<b>MOTORCYCLE IDENTIFICATION</b> .....	1-1
VEHICLE IDENTIFICATION NUMBER .....	1-1
MODEL CODE .....	1-1
<b>IMPORTANT INFORMATION</b> .....	1-2
PREPARATION FOR REMOVAL AND DISASSEMBLY .....	1-2
REPLACEMENT PARTS .....	1-2
GASKETS, OIL SEALS AND O-RINGS .....	1-2
LOCK WASHERS/PLATES AND COTTER PINS .....	1-3
BEARINGS AND OIL SEALS .....	1-3
CIRCLIPS .....	1-3
<b>CHECKING THE CONNECTIONS</b> .....	1-4
<b>SPECIAL TOOLS</b> .....	1-5




EB100000

## GENERAL INFORMATION MOTORCYCLE IDENTIFICATION

EB100010

### VEHICLE IDENTIFICATION NUMBER

The vehicle identification number ① is stamped into the right side of the steering head.



EB100020

### MODEL CODE



The model code label ① is affixed to the frame. This information will be needed to order spare parts.



EB102000

**IMPORTANT INFORMATION  
PREPARATION FOR REMOVAL AND  
DISASSEMBLY**

1. Before removal and disassembly, remove all dirt, mud, dust and foreign material.
2. Use only the proper tools and cleaning equipment.  
Refer to the "SPECIAL TOOLS" section.
3. When disassembling, always keep mated parts together. This includes gears, cylinders, pistons and other parts that have been "mated" through normal wear.  
Mated parts must always be reused or replaced as an assembly.
4. During disassembly, clean all of the parts and place them in trays in the order of disassembly. This will speed up assembly and allow for the correct installation of all parts.
5. Keep all parts away from any source of fire.



EB102010


**REPLACEMENT PARTS**

1. Use only genuine Yamaha parts for all replacements. Use oil and grease recommended by Yamaha for all lubrication jobs. Other brands may be similar in-function and appearance, but inferior in quality.


EB102020

**GASKETS, OIL SEALS AND O-RINGS**

1. When overhauling the engine, replace all gaskets, seals and O-rings. All gasket surfaces, oil seal lips and O-rings must be cleaned.
2. During reassembly, properly oil all mating parts and bearings and apply grease onto the oil seal lips.








EB102030

## LOCK WASHERS/PLATES AND COTTER PINS

1. After removal, replace all lock washers/plates ① and cotter pins. After the bolt or nut has been tightened to specification, bend the lock tabs along a flat of the bolt or nut.



EB102040

## BEARINGS AND OIL SEALS



1. Install bearings and oil seals so that the manufacturer's marks or numbers are visible. When installing oil seals, apply a light coat of lithium soap base grease onto the oil seal lips. Oil bearings liberally when installing, if appropriate.

① Oil seal

### CAUTION:

**Do not spin the bearing with compressed air because this will damage the bearing surfaces.**

① Bearing







EB102050

## CIRCLIPS

1. Before reassembly, check all circlips carefully and replace damaged or distorted circlips. Always replace piston pin clips after one use. When installing a circlip ①, make sure that the sharp-edged corner ②, is positioned opposite the thrust ③ that the circlip receives.

④ Shaft



EB103000

## CHECKING THE CONNECTIONS

Check the leads, couplers, and connectors for stains, rust, moisture, etc.

1. Disconnect:

- lead
- coupler
- connector

2. Check:

- lead
- coupler
- connector

Moisture → Dry with an air blower.

Rust/stains → Connect and disconnect several times.

3. Check:

- all connections

Loose connection → Connect properly.

**NOTE:** \_\_\_\_\_

If the pin 2 on the terminal is flattened, bend in up.

4. Connect:

- lead
- coupler
- connector

**NOTE:** \_\_\_\_\_

Make sure that all connections are tight.

5. Check:

- continuity  
(with a pocket tester)



**Pocket tester**  
**90590-03112**








**NOTE:** \_\_\_\_\_











- If there is no continuity, clean the terminals.
- When checking the wire harness, perform steps 1 to 3.
- As a quick remedy, use a contact revitalizer available at most part stores.

EB104000











**SPECIAL TOOLS**

The following special tools are necessary for complete and accurate tune-up and assembly. Use only the appropriate special tools as this will help prevent damage caused by the use of inappropriate tools or improvised techniques. When placing an order, refer to the list provided below to avoid any mistakes.

Tool No.	Tool name/Usage	Illustration
90890-01268	Ring nut wrench  This tool is used to loosen and tighten the steering ringnut.	
90890-01304	Piston pin puller  This tool is used to remove the piston pin.	
90890-01460 -01326	Damper rod holder ① T-handle ②  These tool ar used for holding the damper rod when removing or installing the damper rod.	
90890-01312	Fuel level gauge  This gauge is used to measure the fuel level in the float chamber.	
90890-01325 -01352	Radiator cap tester ① Adaptor ②  These tools are used for checking the cooling system.	
90890-01362 -01382	Flywheel puller ① Crank shaft protector ②  These tools are used for removing the rotor and starter clutch.	
90890-01367 -01381	Fork seal driver weight Fork seal driver attachment (ø41 mm)  These tools are used when installing the forkseal.	

Tool No.	Tool name/Usage	Illustration
90890-01399	<p>Special thickness gauge</p> <p>This tool is used to measure the valve clearance.</p>	
90890-01401	<p>Spark plug wrench</p> <p>This tool is used for removing or installing the spark plug.</p>	
90890-01403	<p>Ring nut wrench</p> <p>This tool is used to tighten the steering ring nut.</p>	
90890-01469	<p>Oil filter wrench</p> <p>This tool is used for removing or installing the oil filter.</p>	
90890-01701	<p>Sheave holder</p> <p>This tool is used for holding the magneto rotor.</p>	
90890-03081	<p>Compression gauge</p> <p>This tool is used to measure the engine compression</p>	
90890-03094	<p>Vacuum gauge</p> <p>This tool is used to measure the synchronizing the carburetors.</p>	
90890-03112	<p>Pocket tester ①</p> <p>These instruments are invaluable for checking the electrical system.</p>	
90890-03133	<p>Engine tachometer</p> <p>This tool is needed for detecting engine rpm.</p>	
90890-03153 -03139	<p>Oil pressure gauge Oil pressure adaptor H</p> <p>These tools are used to measure the engine oil pressure.</p>	




Tool No.	Tool name/Usage	Illustration
90890-03141	Timing light  This tool is necessary for checking ignition timing.	
90890-04044	Piston ring compressor  This tool is used to compress piston rings when installing the cylinder.	
90890-03158	Carburetor angle driver  This tool is used to adjust the pilot screw.	
90890-04086	Clutch holding tool  This tool is used for holding the clutch boss.	
90890-04101	Valve lapper  This tool is used for removing and installing the valve lifter and for lapping the valve.	
90890-04111	Valve guide remover (4.0 mm)  This tool is used to remove the valve guides.	
90890-04112	Valve guide installer (4.0 mm)  This tool is needed to install the valve guides properly.	
90890-04113	Valve guide reamer (4.0 mm)  This tool is used to rebore the new valve guide.	
90890-04019 -04114	Valve spring compressor ① Valve spring compressor attachment ②  These tools are used when removing or installing the valve and the valve spring.	
90890-06754	Ignition checker  This instrument is necessary for checking the ignition system components.	

# SPECIAL TOOLS

**GEN  
INFO**



Tool No.	Tool name/Usage	Illustration
90890-85505	Yamaha bond No.1215  This sealant (bond) is used for crankcase mating surface, etc.	 A line drawing of a tube of sealant, oriented horizontally with a small nozzle at the left end.



**SPEC**

**2**

---

## **CHAPTER 2 SPECIFICATIONS**

<b>GENERAL SPECIFICATIONS</b> .....	2-1
<b>MAINTENANCE SPECIFICATIONS</b> .....	2-4
ENGINE .....	2-4
CHASSIS .....	2-10
ELECTRICAL .....	2-14
<b>GENERAL TIGHTENING TORQUE SPECIFICATIONS</b> .....	2-17
<b>LUBRICATIONS AND LUBRICANT TYPES</b> .....	2-18
ENGINE .....	2-18
CHASSIS .....	2-19
<b>COOLING SYSTEM DIAGRAMS</b> .....	2-20
<b>LUBRICATION DIAGRAMS</b> .....	2-22
<b>CABLE ROUTING</b> .....	2-25





SPECIFICATIONS

GENERAL SPECIFICATIONS

Model	FZS600
Model code:	5DM1
Dimensions:	
Overall length	2,080 mm
Overall width	710 mm
Overall height	1,170 mm
Seat height	790 mm
Wheelbase	1,415 mm
Minimum ground clearance	130 mm
Minimum turning radius	2,900 mm
Basic weight:	
With oil and full fuel tank	210 kg
Engine:	
Engine type	Liquid cooled 4-stroke, DOHC
Cylinder arrangement	Forward inclined parallel 4-cylinder
Displacement	599 cm <sup>3</sup>
Bore × stroke	62.0 × 49.6 mm
Compression ratio	12 : 1
Compression pressure (STD)	1,550 kPa/400 r/min (15.5 kgf/cm <sup>2</sup> )
Starting system	Electric starter
Lubrication system:	Wet sump
Oil type or grade:	
Engine oil	<div style="display: flex; align-items: center;"> <div style="margin-left: 20px;"> <p>API STANDARD: SE or higher grade ACEA STANDARD: G4 or G5</p> </div> </div>
Periodic oil change	2.5 L
With oil filter replacement	2.7 L
Total amount	3.5 L
Radiator capacity	1.95 L
Total amount (including all routes)	
Air filter:	Dry type element
Fuel:	
Type	Regular unleaded gasoline
Fuel tank capacity	18 L
Fuel reserve amount	3.5 L

# GENERAL SPECIFICATIONS

**SPEC**



Model	FZS600
<b>Carburetor:</b> Type/quantity Manufacturer	BSR 33/4 MIKUNI
<b>Spark plug:</b> Type Manufacturer Spark plug gap	CR9E, CR8E/U27ESR-NU24ESR-N NGK/DENSO 0.7 ~ 0.8 mm
<b>Clutch type:</b>	Wet, multiple-disc
<b>Transmission:</b> Primary reduction system Primary reduction ratio Secondary reduction system Secondary reduction ratio Transmission type Operation Gear ratio      1st 2nd 3rd 4th 5th 6th	Spur gear 82/48 (1.708) Chain drive 48/15 (3.200) Constant mesh 6-speed Left foot operation 37/13 (2.846) 37/19 (1.947) 34/22 (1.545) 28/21 (1.333) 25/21 (1.190) 29/27 (1.074)
<b>Chassis:</b> Frame type Caster angle Trail	Double cradle 24° 88 mm
<b>Tire:</b> Type Size              front rear Manufacturer   front rear Type                front rear	Tubeless 110/70ZR 17 (54W) 160/60ZR 17 (69W) BRIDGESTONE/DUNLOP BRIDGESTONE/DUNLOP BT-57F/D207F BT-57R/D207J
<b>Tire pressure:</b> Maximum load-except motorcycle Loading condition A* front rear Loading condition B* front rear High-speed riding front rear	187 kg 0 ~ 90 kg 225 kPa (2.25 kg/cm <sup>2</sup> , 2.25 bar) 250 kPa (2.5 kg/cm <sup>2</sup> , 2.5 bar) 90 ~ 187 kg 225 kPa (2.25 kg/cm <sup>2</sup> , 2.25 bar) 280 kPa (2.8 kg/cm <sup>2</sup> , 2.8 bar) 225 kPa (2.25 kg/cm <sup>2</sup> , 2.25 bar) 280 kPa (2.8 kg/cm <sup>2</sup> , 2.8 bar)

\*Load is the total weight of cargo, rider, passenger, and accessories.

# GENERAL SPECIFICATIONS



**SPEC**



Model	FZS600
<b>Brake:</b> Front brake type operation Rear brake type operation	Dual disc brake Right hand operation Single disc brake Right foot operation
<b>Suspension:</b> Front suspension Rear suspension	Telescopic fork Swingarm (link suspension)
<b>Shock absorber:</b> Front shock absorber Rear shock absorber	Coil spring/Oil damper Coil spring/Gas-oil damper
<b>Wheel travel:</b> Front wheel travel Rear wheel travel	120 mm 120 mm
<b>Electrical:</b> Ignition system Generator system Battery type Battery capacity	T.C.I. (digital) A.C. magneto GT12B-4 12V 10 AH
<b>Headlight bulb type:</b>	Halogen bulb
<b>Bulb voltage, wattage × quantity:</b> Headlight Brake/tail light Front turn signal light Rear turn signal light License light Meter light Indicator light Neutral indicator light High beam indicator light Oil level warning light Turn indicator light Fuel level warning light Engine temperature warning light	12V 60 W/55 W × 2 12V 21W/5W × 2 12V 21 W × 2 12V 21 W × 2 12V 5 W × 2 12V 2 W × 3  12V 1.4 W × 1 12V 1.4 W × 1 12V 1.4 W × 1 12V 1.4 W × 2 12V 1.4 W × 1 LED



**MAINTENANCE SPECIFICATIONS**  
**ENGINE**

Item	Standard	Limit	
Cylinder head: Warp limit	•••	0.05 mm	
Cylinder: Bore size Taper limit Out of round limit	62.00 ~ 62.01 mm ••• •••	62.1 mm 0.09 mm 0.07 mm	
Camshaft: Drive method Cam cap inside dia. Camshaft out side dia. Camshaft to cap clearance Cam dimensions: Intake "A" "B" "C" Exhaust "A" "B" "C" Camshaft runout limit	Chain drive (center) 23.000 ~ 23.021 mm 23.967 ~ 22.980 mm 0.020 ~ 0.054 mm  32.75 ~ 32.85 mm 25.0 ~ 25.1 mm 7.65 ~ 7.85 mm 32.45 ~ 32.55 mm 24.95 ~ 25.05 mm 7.4 ~ 7.6 mm •••	••• ••• ••• 0.08 mm 32.7 mm 24.95 mm 7.5 mm 32.4 mm 24.9 mm 7.25 mm 0.03 mm	
Cam chain: Cam chain type/No. of links Cam chain adjustment method	92RH2010J/130 Automatic	••• •••	
Valve, valve seat, valve guide: Valve clearance (cold) IN EX Valve dimensions: 	0.11 ~ 0.20 mm 0.21 ~ 0.30 mm	••• •••	
"A" head dia. "B" face width "C" seat width "D" margin thickness Stem outside dia. Guide inside dia.	IN EX IN EX IN EX IN EX IN EX IN EX	23.9 ~ 24.1 mm 20.9 ~ 21.1 mm 1.56 ~ 2.40 mm 1.56 ~ 2.40 mm 0.9 ~ 1.1 mm 0.9 ~ 1.1 mm 0.6 ~ 0.8 mm 0.6 ~ 0.8 mm 3.975 ~ 3.990 mm 3.960 ~ 3.975 mm 4.000 ~ 4.012 mm 4.000 ~ 4.012 mm	••• ••• ••• ••• 1.6 mm 1.6 mm 0.5 mm 0.5 mm 3.95 mm 3.935 mm 4.042 mm 4.042 mm

# MAINTENANCE SPECIFICATIONS

**SPEC**



Item	Standard	Limit
Stem-to-guide clearance	IN 0.010 0.037 mm EX 0.025 0.052 mm	0.08 mm 0.1 mm
Stem runout limit	•••	0.04 mm
Valve seat width	IN 0.9 1.1 mm EX 0.9 1.1 mm	1.6 mm 1.6 mm
Valve spring:		
Free length	IN/EX 40.09 mm	37.5 mm
Set length (valve closed)	IN/EX 34.5 mm	•••
Compressed pressure	IN/EX 134 156 N (13.4 15.6 kg)	•••
Tilt limit	IN/EX •••	2.5°/1.8 mm
Direction of winding	IN/EX Clockwise	•••
Piston:		
Piston clearance	0.025 0.050 mm	0.07 mm
Piston size "D"	61.960 61.975 mm	•••
Measuring point "H"	5 mm	•••
Piston off-set	0.5 mm	•••
Piston off-set direction	In side	•••
Piston pin bore inside dia.	17.002 17.013 mm	•••
Piston pin outside dia.	16.991 17.000 mm	•••
Piston rings:		
Top ring:		
Type	Barrel	•••
Dimensions (B × T)	0.8 × 2.2 mm	•••
End gap (installed)	0.15 0.30 mm	0.6 mm
Side clearance (installed)	0.020 0.075 mm	0.1 mm
2nd ring:		
Type	Taper	•••
Dimensions (B × T)	0.8 × 2.3 mm	•••
End gap (installed)	0.25 0.40 mm	0.7 mm
Side clearance (installed)	0.020 0.055 mm	0.1 mm
Oil ring:		
End gap (installed)	1.5 × 2.3 mm 0.10 0.35 mm	••• •••
Connecting rod:		
Oil clearance	0.043 0.066 mm	0.08 mm
Color code (corresponding size)	1. Blue 2. Black 3. Brown 4. Green	•••
Crankshaft:		
Crankshaft width "A"	48.4 mm	•••
Assembly width "B"	296.8 298.0 mm	•••
Runout limit "C"	•••	0.03 mm
Big end side clearance "D"	0.160 0.262 mm	0.5 mm
Big end radial clearance "E"	0.043 0.066 mm	0.08 mm
Small end free play "F"	0.32 0.50 mm	0.8 mm
Journal oil clearance	0.025 0.043 mm	0.08 mm
Color code (corresponding size)	1. Black 2. Brown 3. Green 4. Yellow 5. Pink	•••

# MAINTENANCE SPECIFICATIONS

**SPEC**



Item	Standard	Limit
<b>Clutch:</b>		
Friction plate thickness	2.94 ~ 3.06 mm	•••
Quantity	8 pcs	•••
Wear limit	•••	2.8 mm
Friction plate thickness	2.94 ~ 3.06 mm	•••
Quantity	1 pcs	•••
Clutch plate thickness	1.9 ~ 2.1 mm	•••
Quantity	8 pcs	•••
Warp limit	•••	0.1 mm
Clutch spring free length	34.9 mm	•••
Quantity	6 pcs	•••
Minimum length	•••	34.3 mm
Clutch housing thrust clearance	0.05 ~ 0.13 mm	0.2 mm
Clutch housing radial clearance	0.005 ~ 0.041 mm	•••
Clutch release method	Inner push, screw push	•••
Push rod bending limit	•••	0.3 mm
<b>Transmission:</b>		
Main axle deflection limit	•••	0.02 mm
Drive axle deflection limit	•••	0.02 mm
<b>Shifter:</b>		
Shifter type	Guide bar	•••
Guide bar bending limit	•••	0.05 mm
<b>Carburetor:</b>		
I.D. mark	5DM1 00	•••
Main jet (M.J)	#115	•••
Main air jet (M.A.J)	#80	•••
Jet needle (J.N)	5D86	•••
Needle jet (N.J)	P-O	•••
Pilot air jet (P.A.J.1)	#130	•••
Pilot outlet (P.O)	0.9	•••
Pilot jet (P.J)	#12.5	•••
Bypass 1 (B.P.1)	0.9	•••
Bypass 2 (B.P.2)	0.8	•••
Bypass 3 (B.P.3)	0.8	•••
Pilot screw (P.S)	2	•••
Valve seat size (V.S)	1.0	•••
Starter jet (G.S.1)	0.6	•••
Starter jet (G.S.2)	0.8	•••
Throttle valve size (TH.V)	#110	•••
Fuel level (F.L) (with special tool)	4.5 mm	•••
Engine idle speed	1,150 ~ 1,250 r/min	•••
Intake vacuum	30.7 ~ 33.3 kPa (230 ~ 250 mmHg)	•••

# MAINTENANCE SPECIFICATIONS

**SPEC**



Item	Standard	Limit
Lubrication system:		
Oil filter type	Paper type	•••
Oil pump type	Trochoid type	•••
Tip clearance "A" or "B"	0.03 0.09 mm	0.15 mm
Side clearance	0.03 0.08 mm	0.15 mm
Bypass valve setting pressure	80 120 kPa (0.8 1.2 kg/cm <sup>2</sup> )	•••
Relief valve operating pressure	450 550 kPa (4.5 5.5 kg/cm <sup>2</sup> )	•••
Pressure check location	Main gallery	•••
Cooling system:		
Radiator core size:		
Width	320 mm	•••
Height	161.4 mm	•••
Thickness	27 mm	•••
Radiator cap opening pressure	95 125 kPa (0.95 1.25 kg/cm <sup>2</sup> )	•••
Radiator capacity	0.6 L	•••
Reservoir tank capacity	0.61 L	•••
From low to full level	0.22 L	•••
Water pump:		
Type	Single suction centrifugal pump	•••
Reduction ratio	82/48 × 48/49 (1.673)	•••

Item	Size
Bearings and oil seals:	
Big end bearing	Plane 30 × 15
Crankshaft bearing	Plane 30 × 16
Crankshaft oil seal	S3-29-40-7.5L HS
Water pump bearing	BWF26-44R
Water pump oil seal	SD-12-28-7-1 HS
Main axle bearing (left)	Ball 6204DLA8NUR
Main axle bearing (right)	83B285SH2C3 22 × 56 × 16
Drive axle bearing (left)	83424ASH2CS41
Drive axle bearing (right)	20NQ3315NE 20 × 33 × 15
Drive axle oil seal	SD7-35-52-8 VS
Shift shaft oil seal	SD-12-22-5 HS


**TIGHTENING TORQUES**  
**ENGINE**

Part to be tightened	Part name	Thread size	Q'ty	Tightening torque		Remarks
				Nm	m•kg	
Camshaft cap	Bolt	M6	24	10	1.0	
Cylinder head	Nut	M9	12	35	3.5	
Spark plug	–	M10	4	13	1.3	
Cylinder head cover	Bolt	M6	8	10	1.0	
Cylinder head side cover	Bolt	M5	8	9	0.9	
Connecting rod cap	Nut	M7	8	See NOTE		
Camshaft sprocket	Bolt	M7	4	24	2.4	
Timing chain tensioner case	Bolt	M6	2	10	1.0	
Timing chain guide (intake side)	Bolt	M6	2	10	1.0	
Timing chain tensioner cap	Bolt	M11	1	20	2.0	
Pipe 2	Bolt	M6	2	10	1.0	
Pipe 3/Pipe 4	Bolt	M6	2	10	1.0	
Thermostat cover	Bolt	M6	3	10	1.0	
Conduction assembly	Bolt	M6	1	10	1.0	
Radiator	Bolt	M6	3	7	0.7	
Joint	Bolt	M6	4	10	1.0	
Water pump	Bolt	M6	2	10	1.0	
Water pump housing	Bolt	M6	2	10	1.0	
Radiator cover	Bolt	M6	4	8	0.8	
Pipe 5/Pipe 6	Bolt	M6	4	10	1.0	
Roter housing	Screw	M6	1	7	0.7	
Oil pump assembly	Bolt	M6	3	10	1.0	
Strainer housing	Bolt	M6	2	10	1.0	
Strainer cover	Bolt	M6	14	12	1.2	
Oil cooler	Union bolt	M20	1	63	6.3	
Oil drain bolt	Bolt	M14	1	43	4.3	
Delivery pipe	Bolt	M10	2	20	2.0	
Delivery pipe holder	Bolt	M6	1	10	1.0	
Oil filter element	–	M20	1	17	1.7	
Carburetor joint 1.2	Bolt	M6	8	10	1.0	
Cap case to air filter case	Screw	M5	4	1	0.1	
Air filter case	Bolt	M6	3	7	0.7	
Air filter cover to air clearance	Screw	M6	6	2	0.2	
Exhaust pipe	Nut	M6	8	10	1.0	
Exhaust joint	Bolt	M8	1	20	2.0	
Crankcase	Bolt	M8	12	24	2.4	
Crankcase	Bolt	M6	21	12	1.2	
Crankcase	Bolt	M8	1	24	2.4	
Breather plate	Screw	M6	6	7	0.7	
Oil seal stopper plate	Bolt	M6	2	10	1.0	
A.C magneto cover	Bolt	M6	5	12	1.2	
Drive sprocket cover	Bolt	M6	5	10	1.0	
Drive sprocket cover	Screw	M5	4	4	0.4	






Part to be tightened	Part name	Thread size	Q'ty	Tightening torque		Remarks
				Nm	m•kg	
Starter cover	Bolt	M6	7	12	1.2	
Oil gallery	–	M16	2	8	0.8	
Clutch cover	Bolt	M6	10	12	1.2	
Clamp (A.C magneto cover)	Screw	M6	1	7	0.7	
Starter clutch assembly	Bolt	M10	1	80	8.0	
Starter clutch outer	Bolt	M8	3	30	3.0	
Pressure plate	Screw	M6	6	8	0.8	
Clutch boss	Bolt	M18	1	70	7.0	
Push lever	Screw	M5	2	5	0.5	
Push rod adjuster	Nut	M8	1	16	1.6	
Drive sprocket	Nut	M18	1	70	7.0	
Shift drum retainer	Bolt	M6	1	10	1.0	
Shift arm	Bolt	M6	1	10	1.0	
Shift fork guide bar retainer	Bolt	M6	2	10	1.0	
Shift pedal adjuster	Nut	M6	2	7	0.7	
Stopper lever	Bolt	M6	1	10	1.0	
Side plate 2	Screw	M5	1	4	0.4	
A.C magneto roter	Bolt	M12	1	130	13.0	
Stator coil	Bolt	M6	3	10	1.0	
Pickup coil	Screw	M5	2	5	0.5	
Starter motor	Bolt	M6	2	10	1.0	
Neutral switch	Screw	M6	2	4	0.4	
Oil level sensor	Bolt	M6	2	7	0.7	
Thermo switch (fan motor)	–	M16	1	23	2.3	
Thermo switch (warning light)	–	PT1/8	1	8	0.8	

**NOTE:**


After tightening to 15 Nm (1.5 m•kg), tighten another 90°.

**Crankcase tightening sequence**

Lower crankcase



Upper crankcase




**CHASSIS**

Item	Standard	Limit
Steering system: Steering bearing type	Angular bearing	•••
Front suspension: Front fork travel	120 mm	•••
Fork spring free length	323 mm	319 mm
Fitting length	315.9 mm	•••
Collar length	200 mm	•••
Spring Rate (K1)	7.5 N/mm (0.75 kg/mm)	•••
(K2)	14 N/mm (1.4 kg/mm)	•••
Stroke (K1)	0 70 mm	•••
(K2)	70 120 mm	•••
Optional spring	No	•••
Oil capacity	475 cm <sup>3</sup>	•••
Oil level	121 mm	•••
Oil grade	Fork oil 10W or equivalent	•••
Rear suspension: Shock absorber travel	50 mm	•••
Spring free length	177 mm	•••
Fitting length	168 mm	•••
Spring Rate (K1)	147 N/mm (14.7 kg/mm)	•••
Stroke (K1)	0 50 mm	•••
Optional spring	No	•••
Enclosed gas/air pressure (STD)	1200 kPa (12 kg/cm <sup>2</sup> )	•••
Swingarm: Swingarm free play limit-end	•••	1 mm
Swingarm free play limit-side	•••	1 mm
Front wheel: Type	Cast wheel	•••
Rim size	17 × MT3.00	•••
Rim material	Aluminum	•••
Rim runout limit radial	•••	1 mm
lateral	•••	0.5 mm
Rear wheel: Type	Cast wheel	•••
Rim size	17 × MT5.00	•••
Rim material	Aluminum	•••
Rim runout limit radial	•••	1 mm
lateral	•••	0.5 mm
Drive chain: Type/manufacturer	50VA7/DAIDO	•••
No. of links	110	•••
Chain free play	30 40 mm	•••

# MAINTENANCE SPECIFICATIONS

**SPEC**



Item	Standard	Limit
<b>Front disc brake:</b> Type Disc outside dia. × thickness Disc deflection limit Pad thickness Inner Pad thickness Outer Master cylinder inside dia. Caliper cylinder inside dia.  Brake fluid type	Dual 298 × 4 mm ●●● 5.5 mm 5.5 mm 14 mm 30.2 mm 27 mm DOT No.4	●●● ●●● 0.2 mm 0.5 mm 0.5 mm ●●● ●●● ●●● ●●●
<b>Rear disc brake:</b> Type Disc outside dia. × thickness Disc deflection limit Pad thickness inner Pad thickness outer Master cylinder inside dia. Caliper cylinder inside dia. Brake fluid type	Single 245 × 5 mm ●●● 5.5 mm 5.5 mm 12.7 mm 38.1 mm DOT No.4	●●● ●●● 0.15 mm 0.5 mm 0.5 mm ●●● ●●● ●●●
<b>Brake lever and brake pedal:</b> Brake pedal position (N) Clutch lever free play (lever end) Throttle grip free play	36.6 mm 10 15 mm 3 5 mm	●●● ●●● ●●●

Item	Size
<b>Bearings and oil seals:</b> Pivot shaft bearing Front wheel bearing (left) Front wheel bearing (right) Rear wheel bearing (left) Rear wheel bearing (right) Rear wheel oil seal (right) Clutch hub bearing Clutch hub oil seal	TA2428Z/24 × 31 × 28 6203LLU/2A 17 × 40 × 12 6203 LLU/2A 17 × 40 × 12 6204 2RS 20 × 47 × 14 6204 2RS 20 × 47 × 14 SD-28-47-7-1 62062RS 30 × 62 × 16 MHSA-40-62-8-B


**TIGHTENING TORQUES**  
**CHASSIS**

Part to be tightened	Thread size	Tightening torque		Remarks
		Nm	m•kg	
Upper bracket and inner tube	M8 × 1.25	30	3.0	
Upper bracket and steering stem	M22 × 1.0	110	11.0	
Handlebar under holder	M10 × 1.25	40	4.0	
Handlebar upper holder	M8 × 1.25	23	2.3	
Under bracket and inner tube	M10 × 1.25	30	3.0	
Ring nut (steering stem)	M25 × 1.0	–	–	NOTE
Master cylinder bracket	M6 × 1.0	10	1.0	
Master cylinder cap	M4 × 0.7	2	0.2	
Brake hose union bolt	M10 × 1.25	30	3.0	
Grip end	M10 × 1.0	7	0.7	
Cowling stay	M8 × 1.25	33	3.3	
Cowling bracket	M6 × 1.0	7	0.7	
Front fender	M6 × 1.0	7	0.7	
Engine bracket (front)	M8 × 1.25	33	3.3	
Engine mount (front)	M10 × 1.25	55	5.5	
Engine mount (rear upper)	M10 × 1.25	55	5.5	
Engine mount (rear under)	M10 × 1.25	55	5.5	
Engine bracket (rear)	M8 × 1.25	33	3.3	
Pivot shaft	M16 × 1.5	11.5	11.5	
Rear shock absorber (upper)	M10 × 1.25	40	4.0	
Rear shock absorber and relay arm	M10 × 1.25	40	4.0	
Relay arm and rear shock absorber bracket	M10 × 1.25	48	4.8	
Relay arm and connecting rod	M12 × 1.25	48	4.8	
Connecting rod and rear arm	M12 × 1.25	48	4.8	
Chain guide	M6 × 1.0	7	0.7	
Chain case	M6 × 1.0	7	0.7	
Fuel tank (front)	M6 × 1.0	10	1.0	
Fuel tank (rear)	M6 × 1.0	10	1.0	
Fuel tank bracket (rear)	M6 × 1.0	7	0.7	
Cap	M5 × 0.8	6	0.6	
Fuel cock	M6 × 1.0	7	0.7	
Fuel sender	M5 × 0.8	4	0.4	
Ignition coil	M6 × 1.0	7	0.7	
Seat lock	M6 × 1.0	7	0.7	
Roter	M6 × 1.0	7	0.7	
Rear fender and frame	M6 × 1.0	7	0.7	
Taillight bracket and rear fender	M6 × 1.0	7	0.7	
Tail cover and Taillight bracket	M5 × 0.8	4	0.4	
Tail cover and frame	M6 × 1.0	7	0.7	
Rear turn signal light	M6 × 1.0	7	0.7	
Taillight	M6 × 1.0	4	0.4	



Part to be tightened	Thread size	Tightening torque		Remarks
		Nm	m•kg	
Side cover and frame	M6 × 1.0	4	0.4	
Garb bar	M8 × 1.25	19	1.9	
Front wheel axle	M16 × 1.5	67	6.7	
Front wheel axle pinch bolt	M8 × 1.0	20	2.0	
Front brake caliper	M8 × 1.25	40	4.0	
Front brake disc	M8 × 1.25	23	2.3	
Front brake caliper bleed screw	M7 × 1.0	6	0.6	
Compression bar	M8 × 1.25	23	2.3	
Rear wheel sprocket	M10 × 1.25	60	6.0	
Drive chain puller nut	M8 × 1.25	16	1.6	
Rear brake caliper and caliper bracket	M10 × 1.25	40	4.0	
Rear wheel axle nut	M18 × 1.5	117	11.7	
Rear brake hose union bolt	M10 × 1.25	30	3.0	
Rear brake caliper bleed screw	M7 × 1.0	6	0.6	
Rear brake disc	M8 × 1.25	23	2.3	
Sidestand	M8 × 1.25	23	2.3	
Bracket footrest and frame	M8 × 1.25	28	2.8	
Rear master cylinder and bracket	M8 × 1.25	23	2.3	
Footrest bracket and footrest	M10 × 1.25	55	5.5	
Footrest bracket (rear) and frame	M8 × 1.25	28	2.8	
Center stand nut	M10 × 1.25	56	5.6	
Footrest bracket and exhaust pipe	M8 × 1.25	20	2.0	
Footrest bracket (rear) and muffler	M10 × 1.25	30	3.0	

**NOTE:**

1. First, tighten the ring nut (lower) approximately 52 Nm (5.2 m•kg) by using the torque wrench, then loosen the right nut completely.
2. Second, tighten the ring nut (lower) approximately 18 Nm (1.8 m•kg) by using the torque wrench, then finger tighten the ring nut (center). Align the slots both ring nut and install the lock washer.
3. Final, hold the ring nuts (lower and center) and tighten the ring nut (upper) 110 Nm (11.0 m•kg) by using the torque wrench.


**ELECTRICAL**

Item	Standard	Limit
Voltage	12 V	...
Ignition system: Ignition timing (B.T.D.C.) Advanced timing (B.T.D.C.) Advance type	10° / 1,250 r/min 50° / 4,500 r/min TPS and electrical type	... ... ...
T.C.I.: Pickup coil resistance T.C.I. unit model/manufacturer	189 ~ 231 Ω Y-L J4T085/MITSUBISHI	... ...
Ignition coil: Model/manufacturer Primary winding resistance Secondary winding resistance	J0313/DENSO 1.87 ~ 2.53 Ω at 20°C 12 ~ 18 kΩ at 20°C	... ... ...
Spark plug cap: Type Resistance	Resin type 10 kΩ	... ...
Charging system: Type Model/manufacturer Standard output Stator coil resistance	A.C. magneto F4T359/MITSUBISHI 12 V 18 A at 5,000 r/min 0.36 ~ 0.44 Ω at 20°C/W-W	... ... ... ...
Voltage regulator: Type Model/manufacturer No load regulated voltage	Semi conductor-short circuit type SH650-12/SHINDENGEN 14.1 ~ 14.9 V	... ... ...
Rectifier: Model/manufacture Capacity Withstand voltage	SH650-12/SHINDENGEN 18 A 200 V	... ... ...
Battery: Specific gravity	1,320	...
Electric starter system: Type	Constant mesh type	...



# MAINTENANCE SPECIFICATIONS

**SPEC**



Item	Standard	limit
Amperage for individual circuit:		
Main	30 A	...
Headlight	20 A	...
Signal	20 A	...
Ignition	20 A	...
Fan	10 A	...
Back up	5 A	...
Reserve	30 A	...
	20 A	...
	10 A	...
	5 A	...






EB201000

## GENERAL TIGHTENING TORQUE SPECIFICATIONS

This chart specifies tightening torques for standard fasteners with a standard ISO thread pitch. Tightening torque specifications for special components or assemblies are provided for each chapter of this manual. To avoid warpage, tighten multi-fastener assemblies in a crisscross pattern and progressive stages until the specified tightening torque is reached. Unless otherwise specified, tightening torque specifications require clean, dry threads. Components should be at room temperature.



A: Width across flats  
B: Thread diameter

A (Nut)	B (Bolt)	General tightening torques	
		Nm	m•kg
10 mm	6 mm	6	0.6
12 mm	8 mm	15	1.5
14 mm	10 mm	30	3.0
17 mm	12 mm	55	5.5
19 mm	14 mm	85	8.5
22 mm	16 mm	130	13.0



## LUBRICATION POINT AND LUBRICATION TYPES ENGINE

Lubrication Point	Symbol
Oil seal lips	
Bearing	
Crankshaft journal	
Connecting rod big end and small end	
Piston, piston pin	
Connecting rod bolt	
Camshaft journal, profile	
Valve stem (IN, EX)	
Valve stem end (IN, EX)	
Cylinder head tightening nut mounting surface	
Valve lifter	
Camshaft cap	
Water pump seal	Coolant
Water pump shaft	
Radiator hose	Silicon
Oil pump	
Relief valve O-ring	
Oil cooler O-ring	
Oil filter	
Oil level gauge	
Starter moter O-ring	
Starter idrer gear	
Main axle 5, 6th pinion	
Drive axle 1 ~ 4th wheel gear	
Push lever	
Push rod	
Shift cam	
Shift fork guide bar	
Shift shaft	
Starter idrer gear shaft 1	
Neutral switch O-ring	
Push rod	
Push rod 1 O-ring	
Shift pedal	
Shift shaft	
Water pump O-ring	
Cylinder head cover gasket	Yamaha bond No. 1215
Shift cam plug	
Breather plate	
Crankcase	Yamaha bond No. 1215
Taper plug	
Bearing plate	

# LUBRICATION POINT AND LUBRICATION TYPES

**SPEC**



## CHASSIS


Lubrication Point	Symbol
Steering bearing and bearing race (upper and lower)	
Pivot shaft	
Rear arm bearing	
Rear arm oil seal	
Rear arm cover oil seal lips	
Relay arm bearing	
Relay arm oil seal	
Rear shock absorber (upper/lower)	
Front wheel oil seal	
Speed sensor oil seal	
Rear wheel oil seal	
Clutch damper oil seal	
Clutch and rear wheel	
Throttle cable inner surface	
Starter cable inner surface and lever pivot	
Rear brake pedal shaft	
Shift pedal shaft	
Side stand sliding surface	
Rear foot rest pivot bolt	



EB203000


## COOLING SYSTEM DIAGRAMS

- ① Engine outlet hose
- ② Engine outlet hose
- ③ Carburetor inlet hose
- ④ Carburetor outlet hose
- ⑤ Water pump
- ⑥ Coolant drain bolt
- ⑦ Water pump outlet hose
- ⑧ Radiator outlet hose
- ⑨ Radiator
- ⑩ Radiator inlet hose





- ① Radiator
- ② Water pump outlet hose
- ③ Oil cooler inlet hose
- ④ Oil cooler outlet hose
- ⑤ Carburetor outlet hose






EB204000


**LUBRICATION DIAGRAMS**

- ① Oil nozzle (main nozzle)
- ② Oil nozzle (drive axle)
- ③ Projection
- ④ Oil filter
- ⑤ Relief valve
- ⑥ Oil strainer
- ⑦ Oil pump






- ① Main axle
- ② Drive axle
- ③ Camshaft
- ④ Oil delivery pipe





- ① Camshaft
- ② Crankshaft








EB205000

**CABLE ROUTING**


- ① Throttle cable
- ② Clutch cable
- ③ Handlebar switch (right)
- ④ Starter cable
- ⑤ Main switch
- ⑥ Brake hose
- ⑦ Speed sensor lead
- ⑧ Headlight lead
- ⑨ Handlebar switch (left)
- A Use a plastic clamp to fasten together the handlebar switch lead (left), clutch cable and starter cable.
- B Pass the brake hose out side of the speed sensor lead, then use a plastic clamp to fasten them.



# CABLE ROUTING

<b>SPEC</b>	
-------------	--


- |                                |                                  |                                    |
|--------------------------------|----------------------------------|------------------------------------|
| ① Main switch lead             | ⑪ Battery                        | ⑳ Speed sensor lead                |
| ② Starter cable                | ⑫ Starting circuit cut-off relay | ㉑ Horn                             |
| ③ Handlebar switch lead (left) | ⑬ Battery positive (+) lead      | ㉒ Starter relay                    |
| ④ Clutch cable                 | ⑭ Seat lock cable                | ㉓ Fuse box                         |
| ⑤ Rectifier/regulator          | ⑮ AC magneto lead                | ㉔ To front brake switch            |
| ⑥ Horn lead                    | ⑯ Starter motor lead             | ㉕ To battery negative (-) lead     |
| ⑦ Box                          | ⑰ Air filter drain hose          | ㉖ To starter relay                 |
| ⑧ Air guide plate              | ⑱ Sidestand switch               | ㉗ AC magneto coupler               |
| ⑨ Starter cable                | ㉒ Neutral switch                 | ㉘ Pickup coupler                   |
| ⑩ Flasher lery                 | ㉓ Oil level switch               | ㉙ Sidestand switch coupler         |
|                                |                                  | ㉚ Oil level/neutral switch coupler |



- A Use a plastic clamp to fasten the handlebar switch lead (left), main switch lead, clutch cable and starter cable to the frame.
- B Use a plastic band to fasten together wireharness, starter motor lead, AC magneto lead, sidestand switch lead and oil level/neutral switch lead, then hold the clamp to the frame bracket.

- C Position the band end to out side of chassis.
- D Use a plastic locking tie to fasten the starter motor lead, AC magneto lead, sidestand switch lead and oil level/neutral switch lead to the frame bracket. Cut off the excess end of the tie.

- E Use a steel holder to fasten together the AC magneto lead, sidestand lead and oil level/neutral switch lead.




# CABLE ROUTING

**SPEC**




- ① Battery negative (-) lead
- ② Rear brake switch lead
- ③ Battery
- ④ Reservoir tank hose
- ⑤ Air filter
- ⑥ Fuel tank breather hose
- ⑦ Fuel tank drain hose
- ⑧ T.P.S. lead
- ⑨ Handlebar switch lead (right)
- ⑩ Throttle cable
- ⑪ Brake hose
- ⑫ Headlight lead
- ⑬ Speed sensor lead
- ⑭ Main switch lead
- ⑮ Reservoir tank
- ⑯ Cross tube
- ⑰ Reservoir tank over flow hose
- ⑱ Swingarm bracket

- A** Use a plastic clamp to fasten together the throttle cables, headlight lead handlebar switch (right) and speed sensor lead.
- B** Use a plastic locking tie to fasten the handlebar switch (right) and brake hose to the right front fork inner tube.





- C** Pass the main switch lead under the throttle cables, headlight lead, handlebar switch lead (right) and speed sensor lead, then insert it right side of the box.
- E** Pass the battery negative (-) lead inside of the reservoir hose.
- D** Pass the reservoir tank overflow hose, fuel tank breather hose and fuel tank drain hose through the cable holder.




# CABLE ROUTING

SPEC



- |                                 |                                       |                                  |
|---------------------------------|---------------------------------------|----------------------------------|
| ① Throttle cable                | ⑪ Battery negative (-) lead           | ⑳ Starter motor lead             |
| ② Handlebar switch lead (right) | ⑫ Battery                             | ㉑ Starter relay                  |
| ③ Headlight lead                | ⑬ Rear brake reservoir tank           | ㉒ Starting circuit cut-off relay |
| ④ Speed sensor lead             | ⑭ Rear brake switch lead              | ㉓ Flasher relay                  |
| ⑤ Carburetor heater hose        | ⑮ Seat lock cable                     | ㉔ Fuel pump lead coupler         |
| ⑥ Reservoir tank hose           | ⑯ Ignitor                             | ㉕ Ignition coil                  |
| ⑦ Fuel pump                     | ⑰ Rear turn signal light lead (right) | ㉖ Clutch cable                   |
| ⑧ Fuel filter                   | ⑱ Rear turn signal light lead (left)  | ㉗ Ground lead                    |
| ⑨ T.P.S lead                    | ㉒ Starter motor lead                  | ㉘ Starter cable                  |
| ⑩ Fuel sender, coupler          |                                       | ㉙ Fan motor lead                 |
|                                 |                                       | ㉚ Rectifier/regulator lead       |







- ① Starter cable
- ② Clutch cable
- ③ Handlebar switch lead (left)
- ④ Main switch lead
- ⑤ To taillight
- ⑥ Rear fender
- ⑦ Clamp
- A Pass the wireharness under the starter relay.

- B Pass the rectifier/regulator lead, fan motor lead, handlebar switch lead (left), main switch lead, headlight lead, handlebar switch lead (right) and speed sensor lead through front side of the box, then connecte each coupler in the box.
- C Align the connector position of rear turn signal light leads (left and right), then bend the rear

- turn signal light lead and clamp it.
- D Pass the reservoir hose left side of thermo stat housing.
- E Do not fasten the high tension cord #4 with locking tie.
- F Use a plastic band to fasten the high tension cord #3, #4.
- G Pass the carburetor inlet hose under the high tension cord #2, #4.





**CHK**

---

**ADJ**

**3**





**CHAPTER 3  
PERIODIC INSPECTIONS AND ADJUSTMENTS**

<b>INTRODUCTION</b> .....	3-1
<b>PERIODIC MAINTENANCE/LUBRICATION INTERVALS</b> .....	3-1
<b>FRONT COWLING/SEAT/SIDE COVER/FUEL TANK</b> .....	3-3
<b>ENGINE</b> .....	3-5
ADJUSTING THE VALVE CLEARANCE .....	3-5
SYNCHRONIZING THE CARBURETORS .....	3-11
ADJUSTING THE ENGINE IDLING SPEED .....	3-13
ADJUSTING THE THROTTLE CABLE FREE PLAY .....	3-14
CHECKING THE SPARK PLUGS .....	3-15
CHECKING THE IGNITION TIMING .....	3-16
MEASURING THE COMPRESSION PRESSURE .....	3-17
CHECKING THE ENGINE OIL LEVEL .....	3-18
CHANGING THE ENGINE OIL .....	3-19
MEASURING THE ENGINE OIL PRESSURE .....	3-21
ADJUSTING THE CLUTCH CABLE FREE PLAY .....	3-22
CLEANING THE AIR FILTER ELEMENT .....	3-23
CHECKING THE CARBURETOR JOINTS AND INTAKE MANIFOLDS .....	3-24
CHECKING THE FUEL HOSES AND FUEL FILTER .....	3-24
CHECKING THE CRANKCASE BREATHER HOSE .....	3-25
CHECKING THE EXHAUST SYSTEM .....	3-25
CHECKING THE COOLANT LEVEL .....	3-26
CHECKING THE COOLING SYSTEM .....	3-26
CHANGING THE COOLANT .....	3-27
<b>CHASSIS</b> .....	3-30
ADJUSTING THE FRONT BRAKE .....	3-30
ADJUSTING THE REAR BRAKE .....	3-30
CHECKING THE BRAKE FLUID LEVEL .....	3-31
ADJUSTING THE REAR BRAKE LIGHT SWITCH .....	3-32
CHECKING THE BRAKE HOSES .....	3-33
BLEEDING THE HYDRAULIC BRAKE SYSTEM .....	3-33
ADJUSTING THE SHIFT PEDAL .....	3-34
ADJUSTING THE DRIVE CHAIN SLACK .....	3-35
LUBRICATING THE DRIVE CHAIN .....	3-36
CHECKING AND ADJUSTING THE STEERING HEAD .....	3-36
CHECKING THE FRONT FORK .....	3-38
ADJUSTING THE REAR SHOCK ABSORBER ASSEMBLY .....	3-38
CHECKING THE TIRES .....	3-39
CHECKING THE WHEELS .....	3-41
CHECKING AND LUBRICATING THE CABLES .....	3-42
LUBRICATING THE LEVERS AND PEDALS .....	3-42
LUBRICATING THE SIDESTAND .....	3-42
LUBRICATING THE CENTER STAND .....	3-42
LUBRICATING THE REAR SUSPENSION .....	3-42
<b>ELECTRICAL SYSTEMS</b> .....	3-43
CHECKING AND CHARGING THE BATTERY .....	3-43
CHECKING THE FUSES .....	3-48
REPLACING THE HEADLIGHT BULBS .....	3-49
ADJUSTING THE HEADLIGHT BEAMS .....	3-50



EB300000

## PERIODIC INSPECTIONS AND ADJUSTMENTS

### INTRODUCTION

This chapter includes all information necessary to perform recommended inspections and adjustments. If followed, these preventive maintenance procedures will ensure more reliable vehicle operation, a longer service life and reduce the need for costly overhaul work. This information applies to vehicles already in service as well as to new vehicles that are being prepared for sale. All service technicians should be familiar with this entire chapter.

EB301000

### PERIODIC MAINTENANCE/LUBRICATION INTERVALS

NO.	ITEM	CHECKS AND MAINTENANCE JOBS	INITIAL (1,000 km)	EVERY	
				6,000 km or 6 months (whichever comes first)	12,000 km or 12 months (whichever comes first)
1	*	<b>Fuel line</b>	<ul style="list-style-type: none"> <li>Check fuel hoses and vacuum hose for cracks or damage.</li> <li>Replace if necessary.</li> </ul>	√	√
2	*	<b>Fuel filter</b>	<ul style="list-style-type: none"> <li>Check condition.</li> <li>Replace if necessary.</li> </ul>		√
3		<b>Spark plugs</b>	<ul style="list-style-type: none"> <li>Check condition.</li> <li>Clean, regap or replace if necessary.</li> </ul>	√	√
4	*	<b>Valves</b>	<ul style="list-style-type: none"> <li>Check valve clearance.</li> <li>Adjust if necessary.</li> </ul>	Every 42,000 km or 42 months (whichever comes first)	
5		<b>Air filter</b>	<ul style="list-style-type: none"> <li>Clean or replace if necessary.</li> </ul>	√	√
6		<b>Clutch</b>	<ul style="list-style-type: none"> <li>Check operation</li> <li>Adjust or replace cable.</li> </ul>	√	√
7	*	<b>Front brake</b>	<ul style="list-style-type: none"> <li>Check operation, fluid level and vehicle for fluid leakage. (See NOTE.)</li> <li>Correct accordingly.</li> <li>Replace brake pads if necessary.</li> </ul>	√	√
8	*	<b>Rear brake</b>	<ul style="list-style-type: none"> <li>Check operation, fluid level and vehicle for fluid leakage. (See NOTE.)</li> <li>Correct accordingly.</li> <li>Replace brake pads if necessary.</li> </ul>	√	√
9	*	<b>Wheels</b>	<ul style="list-style-type: none"> <li>Check balance, runout and for damage.</li> <li>Rebalance or replace if necessary.</li> </ul>	√	√
10	*	<b>Tires</b>	<ul style="list-style-type: none"> <li>Check tread depth and for damage.</li> <li>Replace if necessary.</li> <li>Check air pressure.</li> <li>Correct if necessary.</li> </ul>	√	√
11	*	<b>Wheel bearings</b>	<ul style="list-style-type: none"> <li>Check bearing for looseness or damage.</li> <li>Replace if necessary.</li> </ul>	√	√
12	*	<b>Swingarm</b>	<ul style="list-style-type: none"> <li>Check swingarm pivoting point for play.</li> <li>Correct if necessary.</li> <li>Lubricate with molybdenum disulfide grease every 24,000 km or 24 months (whichever comes first).</li> </ul>	√	√
13		<b>Drive chain</b>	<ul style="list-style-type: none"> <li>Check chain slack.</li> <li>Adjust if necessary. Make sure that the rear wheel is properly aligned.</li> <li>Clean and lubricate.</li> </ul>	Every 1,000 km and after washing the motorcycle or riding in the rain	
14	*	<b>Steering bearings</b>	<ul style="list-style-type: none"> <li>Check bearing play and steering for roughness.</li> <li>Correct accordingly.</li> <li>Lubricate with lithium soap base grease every 24,000 km or 24 months (whichever comes first).</li> </ul>	√	√
15	*	<b>Chassis fasteners</b>	<ul style="list-style-type: none"> <li>Make sure that all nuts, bolts and screws are properly tightened.</li> <li>Tighten if necessary.</li> </ul>	√	√
16	*	<b>Sidestand/ centerstand</b>	<ul style="list-style-type: none"> <li>Check operation.</li> <li>Lubricate and repair if necessary.</li> </ul>	√	√

# PERIODIC MAINTENANCE/LUBRICATION INTERVALS



NO.	ITEM	CHECKS AND MAINTENANCE JOBS	INITIAL (1,000 km)	EVERY	
				6,000 km or 6 months (whichever comes first)	12,000 km or 12 months (whichever comes first)
17	*	<b>Sidestand switch</b>	<ul style="list-style-type: none"> <li>Check operation.</li> <li>Replace if necessary.</li> </ul>	√	√
18	*	<b>Front fork</b>	<ul style="list-style-type: none"> <li>Check operation and for oil leakage.</li> <li>Correct accordingly.</li> </ul>	√	√
19	*	<b>Rear shock absorber assembly</b>	<ul style="list-style-type: none"> <li>Check operation and shock absorber for oil leakage.</li> <li>Replace shock absorber assembly if necessary.</li> </ul>	√	√
20	*	<b>Rear suspension relay arm and connecting arm pivoting points</b>	<ul style="list-style-type: none"> <li>Check operation.</li> <li>Lubricate with molybdenum disulfide grease every 24,000 km or 24 months (whichever comes first).</li> </ul>	√	√
21	*	<b>Carburetors</b>	<ul style="list-style-type: none"> <li>Check engine idling speed, synchronization and starter operation.</li> <li>Adjust if necessary.</li> </ul>	√	√
22		<b>Engine oil</b>	<ul style="list-style-type: none"> <li>Check oil level and vehicle for oil leakage.</li> <li>Correct if necessary.</li> <li>Change. (Warm engine before draining.)</li> </ul>	√	√
23		<b>Engine oil filter cartridge</b>	<ul style="list-style-type: none"> <li>Replace.</li> </ul>	√	√
24	*	<b>Cooling system</b>	<ul style="list-style-type: none"> <li>Check coolant level and vehicle for coolant leakage.</li> <li>Correct if necessary.</li> <li>Change coolant every 24,000 km or 24 months (whichever comes first).</li> </ul>	√	√

\*Since these items require special tools, data and technical skills, they should be serviced by a Yamaha dealer.

**NOTE:**

- The air filter needs more frequent service if you are riding in unusually wet or dusty areas.
- Brake fluid replacement
  1. When disassembling the master cylinder or caliper cylinder, always replace the brake fluid. Check the brake fluid level regularly and fill as required.
  2. Replace the oil seals on the inner parts of the master cylinder and caliper cylinder every two years.
  3. Replace the brake hose every four years or if cracked or damaged.



**Download the full PDF manual instantly.**

**Our customer service e-mail:**

**[aservicemanualpdf@yahoo.com](mailto:aservicemanualpdf@yahoo.com)**