

SHOP MANUAL

KOMATSU

WA250PZ-5

MACHINE MODEL

SERIAL NUMBER

WA250PZ-5

H50051 and up

- This shop manual may contain attachments and optional equipment that are not available in your area. Please consult your local Komatsu distributor for those items you may require. Materials and specifications are subject to change without notice.
- WA250PZ-5 mount the SAA6D102E-2-A engine. For details of the engine, see the 102 Series Engine Shop Manual.

CONTENTS


	No. of page
01 GENERAL	01-1
10 STRUCTURE, FUNCTION AND MAINTENANCE STANDARD	10-1
20 TESTING AND ADJUSTMENT.....	20-1
30 DISASSEMBLY AND ASSEMBLY	30-1
90 OTHERS	90-1

SAFETY

SAFETY NOTICE

IMPORTANT SAFETY NOTICE

Proper service and repair is extremely important for safe machine operation. The service and repair techniques recommended by Komatsu and described in this manual are both effective and safe. Some of these techniques require the use of tools specially designed by Komatsu for the specific purpose.

To prevent injury to workers, the symbol  is used to mark safety precautions in this manual. The cautions accompanying these symbols should always be followed carefully. If any dangerous situation arises or may possibly arise, first consider safety, and take the necessary actions to deal with the situation.

GENERAL PRECAUTIONS

Mistakes in operation are extremely dangerous. Read the Operation and Maintenance Manual carefully BEFORE operating the machine.

1. Before carrying out any greasing or repairs, read all the precautions given on the decals which are fixed to the machine.
2. When carrying out any operation, always wear safety shoes and helmet. Do not wear loose work clothes, or clothes with buttons missing.
 - Always wear safety glasses when hitting parts with a hammer.
 - Always wear safety glasses when grinding parts with a grinder, etc.
3. If welding repairs are needed, always have a trained, experienced welder carry out the work. When carrying out welding work, always wear welding gloves, apron, hand shield, cap and other clothes suited for welding work.
4. When carrying out any operation with two or more workers, always agree on the operating procedure before starting. Always inform your fellow workers before starting any step of the operation. Before starting work, hang UNDER REPAIR signs on the controls in the operator's compartment.
5. Keep all tools in good condition and learn the correct way to use them.

6. Decide a place in the repair workshop to keep tools and removed parts. Always keep the tools and parts in their correct places. Always keep the work area clean and make sure that there is no dirt or oil on the floor. Smoke only in the areas provided for smoking. Never smoke while working.

PREPARATIONS FOR WORK

7. Before adding oil or making any repairs, park the machine on hard, level ground, and block the wheels or tracks to prevent the machine from moving.
8. Before starting work, lower blade, ripper, bucket or any other work equipment to the ground. If this is not possible, insert the safety pin or use blocks to prevent the work equipment from falling. In addition, be sure to lock all the control levers and hang warning signs on them.
9. When disassembling or assembling, support the machine with blocks, jacks or stands before starting work.
10. Remove all mud and oil from the steps or other places used to get on and off the machine. Always use the handrails, ladders or steps when getting on or off the machine. Never jump on or off the machine. If it is impossible to use the handrails, ladders or steps, use a stand to provide safe footing.

PRECAUTIONS DURING WORK

11. When removing the oil filler cap, drain plug or hydraulic pressure measuring plugs, loosen them slowly to prevent the oil from spurting out. Before disconnecting or removing components of the oil, water or air circuits, first remove the pressure completely from the circuit.
12. The water and oil in the circuits are hot when the engine is stopped, so be careful not to get burned.
Wait for the oil and water to cool before carrying out any work on the oil or water circuits.
13. Before starting work, remove the leads from the battery. Always remove the lead from the negative (-) terminal first.
14. When raising heavy components, use a hoist or crane.
Check that the wire rope, chains and hooks are free from damage.
Always use lifting equipment which has ample capacity.
Install the lifting equipment at the correct places.
Use a hoist or crane and operate slowly to prevent the component from hitting any other part.
Do not work with any part still raised by the hoist or crane.
15. When removing covers which are under internal pressure or under pressure from a spring, always leave two bolts in position on opposite sides. Slowly release the pressure, then slowly loosen the bolts to remove.
16. When removing components, be careful not to break or damage the wiring. Damaged wiring may cause electrical fires.
17. When removing piping, stop the fuel or oil from spilling out. If any fuel or oil drips onto the floor, wipe it up immediately. Fuel or oil on the floor can cause you to slip, or can even start fires.
18. As a general rule, do not use gasoline to wash parts. In particular, use only the minimum of gasoline when washing electrical parts.
19. Be sure to assemble all parts again in their original places.
Replace any damaged parts with new parts.
 - When installing hoses and wires, be sure that they will not be damaged by contact with other parts when the machine is being operated.
20. When installing high pressure hoses, make sure that they are not twisted. Damaged tubes are dangerous, so be extremely careful when installing tubes for high pressure circuits. Also, check that connecting parts are correctly installed.
21. When assembling or installing parts, always use the specified tightening torques. When installing protective parts such as guards, or parts which vibrate violently or rotate at high speed, be particularly careful to check that they are installed correctly.
22. When aligning two holes, never insert your fingers or hand. Be careful not to get your fingers caught in a hole.
23. When measuring hydraulic pressure, check that the measuring tool is correctly assembled before taking any measurements.
24. Take care when removing or installing the tracks of track-type machines.
When removing the track, the track separates suddenly, so never let anyone stand at either end of the track.

FOREWORD

GENERAL

This shop manual has been prepared as an aid to improve the quality of repairs by giving the serviceman an accurate understanding of the product and by showing him the correct way to perform repairs and make judgments. Make sure you understand the contents of this manual and use it to full effect at every opportunity.

This shop manual mainly contains the necessary technical information for operations performed in a service workshop. For ease of understanding, the manual is divided into the following chapters; these chapters are further divided into the each main group of components.

STRUCTURE AND FUNCTION

This section explains the structure and function of each component. It serves not only to give an understanding of the structure, but also serves as reference material for troubleshooting.

In addition, this section may contain hydraulic circuit diagrams, electric circuit diagrams, and maintenance standards.

TESTING AND ADJUSTING

This section explains checks to be made before and after performing repairs, as well as adjustments to be made at completion of the checks and repairs.

Troubleshooting charts correlating "Problems" with "Causes" are also included in this section.

DISASSEMBLY AND ASSEMBLY

This section explains the procedures for removing, installing, disassembling and assembling each component, as well as precautions for them.

MAINTENANCE STANDARD

This section gives the judgment standards for inspection of disassembled parts.

The contents of this section may be described in STRUCTURE AND FUNCTION.

OTHERS

This section mainly gives hydraulic circuit diagrams and electric circuit diagrams.

In addition, this section may give the specifications of attachments and options together.

NOTICE

The specifications contained in this shop manual are subject to change at any time and without any advance notice. Use the specifications given in the book with the latest date.

HOW TO READ THE SHOP MANUAL

VOLUMES

Shop manuals are issued as a guide to carrying out repairs. They are divided as follows:

- Chassis volume:** Issued for every machine model
- Engine volume:** Issued for each engine series
- Electrical volume:** } Each issued as one
- Attachments volume:** } volume to cover all models


These various volumes are designed to avoid duplicating the same information. Therefore, to deal with all repairs for any model, it is necessary that chassis, engine, electrical and attachment volumes be available.

DISTRIBUTION AND UPDATING


Any additions, amendments or other changes will be sent to KOMATSU distributors. Get the most up-to-date information before you start any work.

FILING METHOD


1. See the page number on the bottom of the page. File the pages in correct order.
2. Following examples show how to read the page number.
Example 1 (Chassis volume):



Example 2 (Engine volume):



3. Additional pages: Additional pages are indicated by a hyphen (-) and number after the page number. File as in the example.



REVISED EDITION MARK

When a manual is revised, an edition mark ((1)(2)(3)....) is recorded on the bottom of the pages.

REVISIONS

Revised pages are shown in the LIST OF REVISED PAGES next to the CONTENTS page.

SYMBOLS


So that the shop manual can be of ample practical use, important safety and quality portions are marked with the following symbols.

Symbol	Item	Remarks
	Safety	Special safety precautions are necessary when performing the work.
	Caution	Special technical precautions or other precautions for preserving standards are necessary when performing the work.
	Weight	Weight of parts of systems. Caution necessary when selecting hoisting wire, or when working posture is important, etc.
	Tightening torque	Places that require special attention for the tightening torque during assembly.
	Coat	Places to be coated with adhesives and lubricants, etc.
	Oil, water	Places where oil, water or fuel must be added, and the capacity.
	Drain	Places where oil or water must be drained, and quantity to be drained.

01 GENERAL

General assembly drawings	01-2
Specifications	01-3
Weight table	01-7
List of lubricant and coolant	01-9

GENERAL ASSEMBLY DRAWINGS



Item		Unit	WA250PZ-5
Operating weight		kg	12,275
Rated load		kg	3,680
Bucket capacity (piled)		m ³	2.3
Engine model		—	KOMATSU SAA6D102E-2-A-Diesel engine
Flywheel horse power		kW {HP} / rpm	101{135} / 2,000
A	Overall length	mm	7,245
B	Overall height	mm	3,240
C	Overall height when bucket is raised	mm	5,230
D	Overall width	mm	2,470
E	Min. ground clearance	mm	460
F	Bucket width	mm	2,550
G	Dumping clearance	Tip of cutting edge/Tip of tooth	mm 2,840 / 2,730
H	Dumping reach	Tip of cutting edge/Tip of tooth	mm 1,075 / 1,230
I	Bucket dump angle	deg.	45
	Min. turning radius	Tip of cutting edge/Tip of tooth	mm 5,840 / 5,920
		Center of outside wheel	mm 4,950
Travel speed	F1	km / h	4.0 – 13.0
	F2	km / h	13.0
	F3	km / h	18.0
	F4	km / h	38.0
	R1	km / h	4.0 – 13.0
	R2	km / h	13.0
	R3	km / h	18.0
	R4	km / h	38.0

SPECIFICATIONS

Machine model			WA250PZ-5	
Serial No.			H50051 and up	
Weight	Operating weight	kg	12,275	
	Distribution (front) SAE travel posture	kg	5,350	
	Distribution (rear) SAE travel posture	kg	7,270	
Performance	Bucket capacity (piled)	m ³	2.3	
	Rated load	kg	3,680	
	Travel speed	FORWARD 1st	km / h	4.0 – 13.0
		FORWARD 2nd	km / h	13.0
		FORWARD 3rd	km / h	18.0
		FORWARD 4th	km / h	38.0
		REVERSE 1st	km / h	4.0 – 13.0
		REVERSE 2nd	km / h	13.0
		REVERSE 3rd	km / h	18.0
		REVERSE 4th	km / h	38.0
	Max. rimpull	FORWARD	kN {kg}	96 {9,800}
		REVERSE	kN {kg}	96 {9,800}
	Gradeability	deg.	25	
Min. turning radius (Center of outside wheel)	mm	4,950		
Min. turning radius [SAE travel posture] (Tip of cutting edge)	mm	5,800		
Dimensions	Overall length (Tip of cutting edge)	mm	7,245	
	Overall width (chassis)	mm	2,470	
	Bucket width (Without tooth/With tooth)	mm	2,550	
	Overall height (top of cab)	mm	3,240	
	Overall height (Bucket approx. raised to max.)	mm	5,230	
	Wheel base	mm	2,900	
	Tread	mm	1,930	
	Min. ground clearance	mm	460	
	Max. height of bucket hinge pin	mm	3,965	
	Dumping clearance (Tip of cutting edge/Tip of tooth)	mm	2,840 / 2,730	
	Dumping reach (Tip of cutting edge/Tip of tooth)	mm	1,075 / 1,230	
	Steering angle	deg.	40	
	Bucket tilt angle (travel posture)	deg.	48	
	Bucket tilt angle (max. height)	deg.	55	
	Bucket dump angle (max. height)	deg.	48	
	Digging depth (10° dump) (Tip of cutting edge/Tip of tooth)	mm	305 / 385	

Machine model			WA250PZ-5
Serial No.			H50051 and up
Engine	Model		SAA6D102E-2-A
	Type		4-cycle, water-cooled, in-line, 6-cylinder, direct injection with turbocharger, aftercooler
	No. of cylinders - bore x stroke	mm	6 – 102 x 120
	Piston displacement	ℓ {cc}	5.88 {5,880}
	Flywheel horsepower	kW / rpm {HP / rpm}	101 / 2,000 {135 / 2,000}
	Maximum torque	Nm / rpm {kgm / rpm}	618 / 1,400 {63 / 1,400}
	Min. fuel consumption ratio	g / kWh {g / HPh}	224 {167}
	High idling speed	rpm	2,225
	Low idling speed	rpm	825
	Starting motor		24 V 4.5 kW
Alternator		24 V 60 A	
Battery		24 V 110 Ah x 2 pcs.	
Power train	HST pump		Variable displacement swash plate-type piston pump
	HST motor 1		Variable displacement swash plate-type piston motor
	HST motor 2		Variable displacement swash plate-type piston motor
	Transfer		Multiple shaft planetary compound-type, spur gear constant mesh-type, 2 alternative power systems
	Reduction gear		Spiral bevel gear, splash lubrication type
	Differential		Straight bevel gear type, torque portioning
	Final drive		Planetary gear 1-stage, splash lubrication type
Axle	Drive type		Front and rear wheel drive
	Front axle		Fixed to frame, semi-floating type
	Rear axle		Center pin support, semi-floating type
Tire	Tire size		20.5–25–L3
	Rim size		25x17.00–1.7
	Inflation pressure	Front tire	kPa {kg / cm ² } 274 {2.8}
		Rear tire	kPa {kg / cm ² } 274 {2.8}
Brakes	Main brake	Braking system	4 wheel braking, Front and rear wheel independent system control
		Brake type	Enclosed wet multiple disc type
		Operation method	Hydraulically controlled
		Control method	Hydraulic power servo assisted brake
	Parking brake	Braking system	Speed change gear output shaft braking
		Brake type	Wet multiple disc type
		Operation method	Mechanical type
		Control method	Hand lever type

		Machine model		WA250PZ-5
		Serial No.		H50051 and up
Steering control	Type			Articulated steering
	Control			Hydraulic control
Hydraulic system	Hydraulic pump	Steering pump		Gear type
		• Type		
		• Delivery	ℓ / min	110
		Work equipment pump		Gear type
	• Type			
	• Delivery	ℓ / min	78	
	Brake and cooling fan pump		Gear type	
	• Type			
	• Delivery	ℓ / min	19	
	Transfer lubrication pump		Gear type	
	• Type			
	• Delivery	ℓ / min	22	
	Cylinder	Steering cylinder	Type	
Cylinder inner diameter			mm	70
Piston rod diameter			mm	40
Stroke			mm	453
Max. length between pins			mm	1,271
Min. length between pins		mm	818	
Lift cylinder		Type		Reciprocating piston type
		Cylinder inner diameter	mm	130
		Piston rod diameter	mm	70
		Stroke	mm	717
		Max. length between pins	mm	1,950.5
Min. length between pins		mm	1,233.5	
Bucket cylinder		Type		Reciprocating piston type
		Cylinder inner diameter	mm	170
		Piston rod diameter	mm	100
	Stroke	mm	491	
	Max. length between pins	mm	1,815	
Min. length between pins	mm	1,335		

		Machine model	WA250PZ-5
		Serial No.	H50051 and up
Hydraulic system	Control valve	Work equipment control valve	
		<ul style="list-style-type: none"> • Type • Set pressure 	MPa {kg / cm ² }
	Steering valve		
		<ul style="list-style-type: none"> • Type • Set pressure 	MPa {kg / cm ² }
	Motor	Cooling fan motor	
		<ul style="list-style-type: none"> • Type 	Fixed displacement piston type
Work equipment	Link type		Z bar link
	Bucket edge type		Flat blade with top BOC

WEIGHT TABLE

★ This weight table is a guide for use when transporting or handling components.

Unit: kg

Machine model	WA250PZ-5
Serial Numbers	H50051 and up
Engine (without coolant and oil)	608
Cooling assembly (without coolant)	54
Cooling fan motor	6
Damper	3
HST pump	60
HST motor 1	59
HST motor 2	59
Transfer	211
Front drive shaft	18
Rear drive shaft	4
Front axle	555
Rear axle	492
Axle pivot (rear axle)	79
Wheel (each)	130
Tire (each)	147
Orbit-roll valve	7
Priority valve	6
Steering cylinder assembly (each)	18
Brake valve	10
Hydraulic tank (without hydraulic oil)	59
4-gear pump unit	40
Work equipment PPC valve	3
Attachment PPC valve	1
Work equipment control valve	26
Lift cylinder assembly (each)	104
Bucket cylinder assembly	220
Engine hood (with side panel)	164
Front frame	1,015
Rear frame	704

Unit: kg

Machine model	WA250PZ-5
Serial Numbers	H50051 and up
Lift arm (including bushing)	906
Bucket (2.1m ² , excluding BOC)	—
Bucket (2.0m ² , including tooth)	840
Tilt lever	232
Quick coupler	383
Coupler plunger Ass'y	4
Bucket link	68
Counterweight	1,770
Additional counterweight (1 piece)	50/125
Fuel tank (without fuel)	79
Battery (each)	33
Operator's Cab (including air conditioner and interior parts)	755
Operator's seat	41

LIST OF LUBRICANT AND COOLANT

WA250PZ-5	LUBRICANTS, FUELS AND FILLING CAPACITIES					
	Lubricant and operating medium	Short code / cask lettering	Quality grade	Temperature range	Viscosity range	Filling capacity in litres
Engine	Engine oil	EO 0030A EO 0540A EO 10 EO 30 EO 1030A EO 1540A	ACEA E5 or, if not available: API CD or API CE or API CF -4	-30° up to 40° C -25° up to 40° C -20° up to 10° C 0° up to 40° C -20° up to 40° C -15° up to 50° C	SAE 0W-30 SAE 5W-40 SAE 10 SAE 30 SAE 10W-30 SAE 15W-40 *)	20 (19,5 **)
Transfer case	Transmission oil	TO 10	ACEA E5 or, if not available: API CD or API CE or API CF -4	-30° up to 40° C	SAE 10W*)	7,7 (6,9 **)
Hydraulic system	Hydraulic oil	HYD 0530 HYD 1030	HVLP, HVLP D	-30° up to 40° C -20° up to 30°C	ISO VG46 *) ISO VG68	135 (67**)
	or Engine oil	EO 1030A	ACEA E5 or, if not available: API CD or API CE or API CF -4	-30° up to 40° C	SAE 10W-30	
Axle with standard differential	Axle oil	AXO 80 (*2) AXO	Shell: DONAX TD5W-30 ***)		80W SAE 5W-30 *)	each 18 (each 18**)
	or Engine oil	EO 30	ACEA E5 or, if not available: API CD or API CE or API CF -4	0° up to 40° C	SAE 30	
Axle with limited-slip differential (*3)	Axle oil(*4)	AXO	Shell: DONAX TD5W-30 ***) Esso: TORQUE FLUID56****) Mobil: MOBILFLUID 424 Fuchs: TITAN HYDRA ZF 20W-40		SAE 5W-30*) SAE 20W-40	
Fuel tank	Diesel fuel	ASTM D975 No.1 ASTM D975 No.2 DIN-EN 590	CFPP class B CFPP class D CFPP class F	-30° up to -10° C -10° up to 40° C 0° up to 40° C -10° up to 40° C -20° up to 40° C	-----	184
Grease nipples	Multi purpose grease on a lithium base	MPG-A	KP2N-20	-30° up to 40° C	NLGI-No. 2	---
Grease box of central lubrication unit	Multi purpose grease on a lithium base	MPG-A	KP2N-20	-30° up to 40° C	NLGI-No. 2	---
Cooling system	Water and coolant	AF-NAC	TEXACO: Havoline XLC *) *****) Tanigawa Oil: NA2001 CCI: L246 TOTAL FINA ELF: GILACELF CHP SUPRA Showa: MCR20			19
Air conditioner	Coolant	NRS	R134a (CFC-free)			860 g

* Work filling

** Top-up quantity

*** North American manufactured DONAX TD 20W-40 must not be used.


**** North American manufactured TORQUE FLUID 56 must not be used.

***** Proportion of mixture: 50% coolant : 50% water, Min. freeze proofing: -35°C


10 STRUCTURE, FUNCTION AND MAINTENANCE STANDARD

Engine mount and transfer mount	10-2	4-gear pump unit	10-114
Damper	10-3	Accumulator (for ppc circuit)	10-116
Cooling system	10-4	Lock valve	10-117
Power train	10-5	Bypass valve	10-118
Power train system diagram	10-6	E.C.S.S. valve	10-121
Drive shaft (propeller shaft)	10-8	Accumulator (for E.C.S.S.)	10-123
HST hydraulic piping diagram	10-9	Hydraulic piping of cooling system	10-124
HST pump	10-10	Cooling fan motor	10-125
High-pressure relief valve	10-12	Work equipment control valve	10-127
Low-pressure relief valve	10-14	Work equipment PPC valve	10-140
HST charge pump	10-15	Attachment PPC valve	10-152
Speed-related valve (DA valve)	10-16	Work equipment linkage	10-156
High-pressure cut-off valve	10-17	Bucket	10-158
HST motor	10-18	Control of bucket positioner, boom kick-out	10-159
EP servo valve	10-21	Work equipment cylinder	10-169
HA servo valve	10-22	Air conditioner	10-171
Forward-reverse shuttle valve	10-23	Machine monitoring system	10-172
Transfer	10-24	Machine monitor	10-182
Transfer oil cooler	10-35	List of items displayed on monitor	10-183
Clutch solenoid valve	10-36	Electrical system (HST controller system)	10-209
Axle	10-37	HST controller	10-213
Differential	10-40	Function of selecting forward-reverse selector switch	10-214
Limited-slip differential	10-46	Engine start circuit	10-216
Final drive	10-52	Engine stop circuit	10-218
Axle mounting and center hinge pin	10-58	Preheating circuit (automatic preheating system).....	10-219
Steering piping	10-63	Parking brake circuit	10-220
Steering column	10-64	Electronically controlled suspension system	10-223
Priority valve	10-65	Sensors	10-224
Orbit-roll valve	10-68		
2-way restrictor valve	10-76		
Steering cylinder	10-77		
Emergency steering piping	10-79		
Emergency steering valve	10-80		
Brake piping	10-83		
Brake valve	10-84		
Inching valve	10-88		
Charge valve	10-90		
Accumulator (for brake)	10-94		
Slack adjuster	10-95		
Brake	10-98		
Parking brake control	10-103		
Parking brake	10-104		
Hydraulic piping	10-106		
Work equipment lever linkage	10-108		
Hydraulic tank	10-112		

ENGINE MOUNT AND TRANSFER MOUNT



DAMPER



Unit: mm


No.	Check item	Criteria		Remedy
1	Distance between HST pump mounting face and tip of boss	Standard size	Repair limit	Adjust
		75.1	± 0.8	
2	Wear of internal teeth of coupling (plastic)	Repair limit: 1.0		Replace

- 3. Coupling
- 4. Boss
- 5. HST pump input shaft
- 6. Cover
- 7. Flywheel

Outline

- The damper reduces the torsional vibration caused by fluctuation of the engine torque to protect the drive system after the engine from the torsional vibration.
- The power from the engine is transmitted through flywheel (7) to coupling (3), which absorbs the torsional vibration, and then transmitted through boss (4) to the HST pump.

COOLING SYSTEM




- 25. Oil cooler
- 26. Charge air cooler
- 27. Radiator

- 28. Reservoir tank
- 29. Cooling fan
- 30. Cooling fan motor

Specification


	Radiator	Oil cooler	Charge air cooler
Core type	AL WAVE-4	CF40-1	
Fin pitch (mm)	3.5 / 2	3.5 / 2	4.0 / 2
Total heat radiating area (m ²)	27.9	4.67	7.23
Pressure valve opening pressure (kPa {kg/cm ² })	68.6 {0.7}	—	—
Vacuum valve opening pressure (kPa {kg/cm ² })	0 - 4.9 {0 - 0.05}	—	—

POWER TRAIN



1. Engine
2. Damper
3. HST pump
4. 4-gear pump unit
5. High-pressure hose
6. HST motor 1
7. HST motor 2
8. Transfer
9. Front drive shaft
10. Front axle
11. Rear drive shaft
12. Rear axle

POWER TRAIN SYSTEM DIAGRAM




9JB01254

1. Engine
2. Damper
3. HST pump
4. Steering pump
5. Work equipment pump
6. Brake and cooling fan pump
7. Transfer lubricating oil pump
8. High-pressure hose
9. HST motor 1
10. HST motor 2
11. Emergency steering valve
12. Transfer
13. Transfer clutch
14. Parking brake
15. Front drive shaft
16. Front axle
17. Differential
18. Wet multiple disc brake
19. Final drive
20. Front tire
21. Rear drive shaft
22. Rear axle
23. Differential
24. Wet multiple disc brake
25. Final drive
26. Rear tire

Outline

- The power of engine (1) is transmitted to HST pump (3) through damper (2) which is installed to the flywheel and which absorbs the torsional vibration of the power,
- The power of engine (1) is also transmitted to HST pump (3), HST charge pump built in HST pump (3), steering pump (4) connected to HST pump (3), work equipment pump (5), brake and cooling fan pump (6), and transfer lubricating oil pump (7).
- HST pump (3) is equipped with the forward-reverse shifting valve and servo piston, which changes the discharge direction and discharge rate of HST pump (3) continuously by changing the swash plate angle.
- HST motors (9) and (10) are installed to transfer (12) and connected to HST pump (3) by high-pressure hose (8).
- The turning direction and speed of HST motors (9) and (10) are changed by the hydraulic power of HST pump (3) to control the travel direction and travel speed of the machine.
- The power of HST motor 1 (9) is transmitted through transfer clutch (13) in transfer (12) to the output shaft.
The power of HST motor 2 (10) is transmitted through the gear in transfer (12) to the output shaft.
- Parking brake (14) is installed on the rear side in transfer (12). It operates the wet multiple disc brake to stop the machine according to the operation of the parking brake lever.
- The power for the front side is transmitted through front drive shaft (15) to front axle (16). The power for the rear side is transmitted through rear drive shaft (21) to rear axle (22).
- The power transmitted to axles (16) and (22) is reduced in speed by the pinion gears of differentials (17) and (23), and then transmitted through the sun gear shaft to the sun gear.
- The power of the sun gear is reduced in speed by the planetary mechanisms of final drives (19) and (25), and then transmitted through the axle shaft and wheels to tires (20) and (26).

DRIVE SHAFT (PROPELLER SHAFT)



1. Front axle
2. Front drive shaft
3. Transfer
4. Rear drive shaft
5. Rear axle

Outline

- The power from the output shaft of the transfer is transmitted through front drive shaft (2) and rear drive shaft (4) to front axle (1) and rear axle (5).
- When the machine is articulated or it receives an impact from the road during travel or a working impact, the positions of the transfer and front and rear axles change. The drive shafts can change their angles and lengths by means of the universal joints and sliding joints so that the power will be transmitted without damaging any part even when the positions of the components change because of the impacts.



Download the full PDF manual instantly.

Our customer service e-mail:

aservicemanualpdf@yahoo.com