




YAMAHA

YW50AP

SERVICE MANUAL

INDEX

GENERAL INFORMATION	 1
SPECIFICATIONS	 2
PERIODIC INSPECTION AND ADJUSTMENT	 3
ENGINE OVERHAUL	 4
CARBURETION	 5
CHASSIS	 6
ELECTRICAL	 7
TROUBLESHOOTING	 8

CHAPTER 1. GENERAL INFORMATION

SCOOTER IDENTIFICATION	1-1
VEHICLE IDENTIFICATION NUMBER	1-1
MODEL CODE	1-1
IMPORTANT INFORMATION	1-2
PREPARATION FOR REMOVAL AND DISASSEMBLY	1-2
REPLACEMENT PARTS	1-2
GASKETS, OIL SEALS AND O-RINGS	1-2
LOCK WASHERS/PLATES AND COTTER PINS	1-2
BEARINGS AND OIL SEALS	1-3
CIRCLIPS	1-3
CHECKING OF CONNECTIONS	1-4
HOW TO USE THE CONVERSION TABLE	1-5
CONVERSION TABLE	1-5
SPECIAL TOOLS	1-6

CHAPTER 2. SPECIFICATIONS

GENERAL SPECIFICATION	2-1
MAINTENANCE SPECIFICATION	2-4
ENGINE	2-4
TIGHTENING TORQUES	2-6
ENGINE	2-6
MAINTENANCE SPECIFICATION	2-7
CHASSIS	2-7
TIGHTENING TORQUES	2-8
CHASSIS	2-8
MAINTENANCE SPECIFICATION	2-9
ELECTRICAL	2-9
GENERAL TORQUE SPECIFICATIONS	2-11
LUBRICATION POINTS AND LUBRICATION TYPE	2-12
ENGINE	2-12
CHASSIS	2-13
CABLE ROUTING	2-14

CHAPTER 3.

PERIODIC INSPECTION AND ADJUSTMENTS

INTRODUCTION	3-1
PERIODIC MAINTENANCE/LUBRICATION INTERVALS	3-1
COVER AND PANEL	3-3
SIDECOVER AND SEAT	3-3
LOWER COWLING, UPPER COVER, LEG SHIELD 1, 2 AND FOOTREST BOARD	3-4
HANDLEBAR COVER(FRONT AND REAR)	3-5
ENGINE	3-6
IDLE SPEED ADJUSTMENT	3-6
THROTTLE CABLE FREE ADJUSTMENT	3-7
AUTOLUBE PUMP AIR BLEEDING	3-8
SPARK PLUG INSPECTION	3-9
ENGINE OIL LEVEL INSPECTION	3-10
TRANSMISSION OIL REPLACEMENT	3-11
AIR FILTER ELEMENT CLEANING	3-12
V-BELT INSPECTION	3-14
CHASSIS	3-15
FRONT BRAKE LEVER FREE PLAY CHECK	3-15
REAR BRAKE LEVER FREE PLAY CHECK	3-15
BRAKE PAD INSPECTION	3-15
BRAKE SHOE INSPECTION	3-16
BRAKE FLUID LEVEL INSPECTION	3-16
AIR BLEEDING (HYDRAULIC BRAKE SYSTEM)	3-17
STEERING ADJUSTMENT	3-18
TIRE INSPECTION	3-19
WHEEL INSPECTION	3-22
FRONT FORK INSPECTION	3-22
REAR SHOCK ABSORBER INSPECTION	3-22
SEAT LOCK CABLE ADJUSTMENT	3-22
CABLE CHECKING AND LUBRICATING	3-23
LEVERS LUBRICATING	3-23
CENTERSTAND LUBRICATING	3-23
ELECTRICAL	3-24
BATTERY INSPECTION	3-24
FUSE INSPECTION	3-29
HEADLIGHT BEAM ADJUSTMENT	3-30
HEADLIGHT BULB REPLACEMENT	3-30
TURN SIGNAL AND TAILLIGHT BULB REPLACEMENT	3-31
TAILLIGHT BULB REPLACEMENT	3-32
LICENSE LIGHT BULB REPLACEMENT	3-32

CHAPTER 4.

ENGINE

ENGINE OVERHAUL	4-1
WIREHARNESS AND CABLES	4-1
CYLINDER HEAD, CYLINDER AND PISTON	4-3
CYLINDER HEAD, CYLINDER AND PISTON	4-3
PISTON PIN AND PISTON REMOVAL	4-4
CYLINDER HEAD INSPECTION	4-4
CYLINDER AND PISTON INSPECTION	4-5
PISTON RINGS INSPECTION	4-7
PISTON PIN AND PISTON PIN BEARING	4-7
PISTON PIN AND PISTON INSTALLATION	4-8
CYLINDER AND CYLINDER HEAD	4-9
V-BELT, CLUTCH AND SECONDARY/PRIMARY SHEAVE	4-11
KICK STARTER AND CRANKCASE COVER(LEFT)	4-11
KICK STARTER	4-12
KICK STARTER INSTALLATION	4-13
V-BELT, CLUTCH AND SECONDARY/PRIMARY SHEAVE	4-14
SECONDARY SHEAVE	4-15
PRIMARY SHEAVE REMOVAL	4-16
SECONDARY SHEAVE REMOVAL	4-16
CLUTCH INSPECTION	4-17
V-BELT INSPECTION	4-18
PRIMARY SHEAVE INSPECTION	4-19
SECONDARY SHEAVE	4-20
SECONDARY SHEAVE INSTALLATION	4-21
PRIMARY SHEAVE	4-22
STARTER CLUTCH AND STARTER MOTOR	4-24
STARTER CLUTCH AND STARTER MOTOR	4-24
STARTER CLUTCH AND GEARS INSPECTION	4-26
C.D.I. MAGNET	4-27
C.D.I. MAGNETO	4-27
C.D.I. MAGNETO REMOVAL	4-28
C.D.I. MAGNETO INSTALLATION	4-28
AUTOLUBE PUMP	4-29
AUTOLUBE PUMP	4-29
AUTOLUBE PUMP INSTALLATION	4-30
TRANSMISSION	4-31
TRANSMISSION	4-31
CRANKCASE AND REED VALVE	4-33
CRANKCASE AND REED VALVE	4-33
CRANKCASE(RIGHT) REMOVAL	4-35
CHECKING THE CRANKCASE	4-35
CHECKING THE BEARINGS AND OIL SEALS	4-35
REED VALVE INSPECTION	4-36
CRANKCASE (RIGHT) INSTALLATION	4-36
CRANKSHAFT	4-38
CRANKSHAFT	4-38
CRANKSHAFT REMOVAL	4-39
CRANKSHAFT INSPECTION	4-39
CRANKSHAFT INSTALLATION	4-40

CHAPTER 5

CARBURETION

CARBURETION	5-1
CARBURETOR	5-1
CABURETOR DISASSEMBLY	5-2
CABURETOR INSPECTION	5-3
CARBURETOR ASSEMBLY	5-5
FUEL LEVEL ADJUSTMENT	5-6
AUTO CHOKE INSPECTION	5-7
FUEL COCK INSPECTION	5-8

CHAPTER 6

CHASSIS

FRONT WHEEL AND BRAKE DISC	6-1
FRONT WHEEL AND BRAKE DISC	6-1
FRONT WHEEL DISASSEMBLY	6-2
FRONT WHEEL DISASSEMBLY	6-3
FRONT WHEEL INSPECTION	6-3
BRAKE DISC INSPECTION	6-4
FRONT WHEEL ASSEMBLY	6-4
FRONT WHEEL INSTALLATION	6-5
WHEEL STATIC BALANCE ADJUSTMENT	6-6
FRONT BRAKE	6-8
BRAKE PAD	6-8
BRAKE PAD REPLACEMENT	6-9
MASTER CYLINDER	6-12
MASTER CYLINDER DISASSEMBLY	6-13
MASTER CYLINDER INSPECTION	6-14
MASTER CYLINDER ASSEMBLY	6-14
MASTER CYLINDER INSTALLATION	6-15
CALIPER	6-17
CALIPER DISASSEMBLY	6-18
BRAKE CALIPER DISASSEMBLY	6-19
CALIPER INSPECTION	6-19
BRAKE CALIPER ASSEMBLY	6-20
BRAKE CALIPER INSTALLATION	6-20
REAR WHEEL AND REAR BRAKE	6-21
REAR WHEEL	6-21
REAR BRAKE	6-22
REAR WHEEL INSPECTION	6-23
REAR BRAKE INSPECTION	6-23
REAR BRAKE INSTALLATION	6-24
HANDLEBAR	6-25
HANDLEBAR	6-25
HANDLEBAR INSTALLATION	6-27
STEERING	6-29
STEERING	6-29
STEERING REMOVAL	6-30
STEERING INSPECTION	6-31
STEERING INSTALLATION	6-31
FRONT FORK	6-34
FRONT FORK	6-34
FRONT FORK DISASSEMBLY	6-35
FRONT FORK REMOVAL	6-36
FRONT FORK DISASSEMBLY	6-36
FRONT FORK INSPECTION	6-37
FRONT FORK ASSEMBLY	6-37
FRONT FORK INSTALLATION	6-39

CHAPTER 7

ELECTRICAL


ELECTRICAL COMPONENTS	7-1
ELECTRICAL COMPONENTS	7-1
CIRCUIT DIAGRAM	7-2
CHECKING SWITCHES	7-4
CHECKING STEPS	7-4
SWITCH CONNECTION AS SHOWN IN THIS MANUAL.....	7-4
SWITCH POSITION AND TERMINAL CONNECTION	7-5
CHECKING THE BLUBS AND BULB SOCKETS	7-5
CHECKING THE BULBS AND BULB SOCKETS	7-6
TYPES OF BULBS	7-6
CHECKING THE CONDITION OF THE BULBS.....	7-7
CHECKING THE CONDITION OF THE BULB SOCKETS	7-8
IGNITION SYSTEM	7-9
CIRCUIT DIAGRAM	7-9
TROUBLESHOOTING	7-10
CHARGING SYSTEM	7-14
CIRCUIT DIAGRAM	7-14
TROUBLESHOOTING	7-15
ELECTRIC STARTING SYSTEM	7-18
CIRCUIT DIAGRAM	7-18
TROUBLESHOOTING	7-19
STARTER MOTOR	7-22
STARTER MOTOR DISASSEMBLY.....	7-23
INSPECTION AND REPAIR	7-24
LIGHTING SYSTEM	7-26
CIRCUIT DIAGRAM	7-26
TROUBLESHOOTING	7-27
LIGHTING SYSTEM CHECK	7-29
SIGNAL SYSTEM	7-33
CIRCUIT DIAGRAM	7-33
TROUBLESHOOTING	7-34
SIGNAL SYSTEM CHECK	7-36
AUTO CHOKE SYSTEM	7-42
CIRCUIT DIAGRAM	7-42
TROUBLESHOOTING	7-43

CHAPTER 8

TROUBLESHOOTING

STARTING FAILURE/HARD STARTING	8-1
FUEL SYSTEM	8-1
IGNITION SYSTEM	8-2
COMPRESSION SYSTEM	8-2
POOR IDLE SPEED PERFORMANCE	8-3
POOR IDLE SPEED PERFORMANCE	8-3
POOR MIDIUM AND HIGH SPEED PERFORMANCE	8-3
POOR MIDIUM AND HIGH SPEED PERFORMANCE	8-3
FULTY AUTOMATIC(V-BELT TYPE)	8-4
SCOOTER DOES NOT MOVE WHILE ENGINE IS OPERATING	8-4
CLUTCH OUT FAILURE	8-4
POOR STANDING START(LOW CLIMBING ABILITY)	8-4
POOR ACCELERATION(Poor HIGH SPEED)	8-4
OVER HEAT	8-5
OVERHEAT	8-5
POOR SPEED	8-5
POOR SPEED	8-5
IMPROPER KICKING	8-6
SLIPPING	8-6
HARD KICKING	8-6
KICK CRANK NOT RETURNING	8-6
FAULTY BRAKE	8-7
POOR BRAKING EFFECT	8-7
MALFUNCTION	8-7
INSTABLE HANDLING	8-8
INSTABLE HANDLING	8-8
FAULTY SIGNAL AND LIGHTING SYSTEM	8-9
HEADLIGHT DARK	8-9
BULB BURNT OUT	8-9
FLASHER DOES NOT BLINK	8-9
FLASHER KEEPS ON	8-9
FLASHER BLINKS SLOWER	8-10
FLASHER BLINKS QUICKER	8-10
HORN DOES NOT SOUND	8-10

SCOOTER IDENTIFICATION



EAS00015

GENERAL INFORMATION SCOOTER IDENTIFICATION

EAS00017

VEHICLE IDENTIFICATION NUMBER

The vehicle identification number ① is stamped into the frame.




EAS00018

MODEL CODE

The model code label ① is affixed to the location shown in the figure. Record the information on this label in the space provided. This information will be needed to order spare parts.


IMPORTANT INFORMATION




EAS00020

IMPORTANT INFORMATION PREPARATION FOR REMOVAL AND DISASSEMBLY

1. Before removal and disassembly, remove all dirt, mud, dust and foreign material.
2. Use only the proper tools and cleaning equipment.
Refer to "SPECIAL TOOLS".
3. When disassembling, always keep mated parts together. This includes gears, cylinders, pistons and other parts that have been "mated" through normal wear. Mated parts must always be reused or replaced as an assembly.
4. During disassembly, clean all of the parts and place them in trays in the order of disassembly. This will speed up assembly and allow for the correct installation of all parts.
5. Keep all parts away from any source of fire.



300-008



300-016

EAS00021

REPLACEMENT PARTS


Use only genuine Yamaha parts for all replacements. Use oil and grease recommended by Yamaha for all lubrication jobs.

Other brands may be similar in function and appearance, but inferior in quality.

EAS00022

GASKETS, OIL SEALS AND O-RINGS

1. When overhauling the engine, replace all gaskets, seals and O-rings. All gasket surfaces, oil seal lips and O-rings must be cleaned.
2. During reassembly, properly oil all mating parts and bearings and lubricate the oil seal lips with grease.




EAS00023

LOCK WASHERS/PLATES AND COTTER PINS

After removal, replace all lock washers/plates ① and cotter pins. After the bolt or nut has been tightened to specification, bend the lock tabs along a flat of the bolt or nut.

IMPORTANT INFORMATION

GEN
INFO




EAS00024

BEARINGS AND OIL SEALS

Install bearings and oil seals so that the manufacturer's marks or numbers are visible. When installing oil seals, lubricate the oil seal lips with a light coat of lithium soap base grease. Oil bearings liberally when installing, if appropriate.


① Oil seal



CAUTION:

Do not spin the bearing with compressed air because this will damage the bearing surfaces.

① Bearing



EAS00025

CIRCLIPS

Before reassembly, check all circlips carefully and replace damaged or distorted circlips. Always replace piston pin clips after one use. When installing a circlip ①, make sure the sharp-edged corner ② is positioned opposite the thrust ③ that the circlip receives.

④ Shaft

IMPORTANT INFORMATION

GEN
INFO





EB801000


CHECKING OF CONNECTIONS

Dealing with stains, rust, moisture, etc. on the connector.

1. Disconnect:
 - Connector
2. Dry each terminal with an air blower.



3. Connect and disconnect the connector two or three.
4. Pull the read to check that it will not come off.
5. If the terminal comes off, bend up the pin ① and reinsert the terminal into the connector.



6. Connect:
 - Connector


NOTE: _____

The two connectors "click" together.

7. Check for continuity with a tester.

NOTE: _____

- If there is no continuity, clean the terminals.
- Be sure to perform the steps 1 to 7 listed above when checking the wireharness.
- For a field remedy, use a contact revitalizer available on the market.
- Use the tester on the connector as shown.



HOW TO USE THE CONVERSION TABLE



EB201000

HOW TO USE THE CONVERSION TABLE

All specification data in this manual are listed in SI and METRIC UNITS.

Use this table to convert METRIC unit data to IMPERIAL unit data.

Ex.

METRIC	MULTIPLIER	IMP
** mm	× 0.03937	= ** in
2 mm	× 0.03937	= 0.083 in

CONVERSION TABLE

METRIC TO IMP			
	Known	Multiplier	Result
Torque	m.kg	7.233	ft.lb
	m.kg	86.794	in.lb
	cm.kg	0.0723	ft.lb
	cm.kg	0.8679	in.lb
Weight	kg	2.205	lb
	g	0.03527	oz
Distance	km/h	0.6214	mph
	km	0.6214	mi
	m	3.281	ft
	m	1.094	yd
	cm	0.3937	in
	mm	0.03937	in
Volume/ Capacity	cc(cm ³)	0.03527	oz (IMP liq.)
	cc(cm ³)	0.06102	cu.in
	lit(liter)	0.8799	qt(IMP liq.)
	lit(liter)	0.2199	gal(IMP liq.)
Miscellaneous	kg/mm	55.997	lb/in
	kg/cm ²	14.2234	psi(lb/in ²)
	Centigrade	9/5(°C)+32	Fahrenheit (°F)



EE102000

SPECIAL TOOLS

The following special tools are necessary for complete and accurate tune-up and assembly. Use only the appropriate special tools; this will help prevent damage caused by the use of inappropriate tools or improvised techniques.

When placing an order, refer to the list provided below to avoid any mistakes.

Tool No.	Tool name / Function	Illustration
YU-01235	Rotor holding tool This tool is used to hold the generator rotor when removing or installing the generator rotor bolt.	
YS-28891	Clutch spring holder This tool is used to disassembly and assembly the secondary pulley.	
YU -90050 -90062	Crankshaft Installation set ① Adapter ② These tools are used to install the crankshaft.	
YU-01189	Flywheel puller This tool is used for removing the rotor.	
YU- 01135-A	Crankcase Separating tool This tool is used to remove the crankshaft or separate the crankcase.	
YM-33299	Oil seal guide This tool is used for protecting the oil seal lip when installing the secondary sliding sheave.	
YU-33975	Steering nut wrench This tool is used to loosen or tighten the steering stem ring nut.	
YU-01701	Sheave holder This tool is used to hold the clutch housing when removing or installing the clutch housing nut.	
YU-8036-A	Inductive tachometer This tool is used to check engine speed.	

SPECIAL TOOLS

**GEN
INFO**



Tool No.	Tool name / Function	Illustration
YU-03112	Pocket tester This tool is used to check the electrical system.	
YM-1409	Oil seal guide This tool is used to install the left side crankcase oil seal.	
YM-1410	Oil seal driver This tool is used to install the left side crankcase oil seal.	
YM-34487	Dynamic spark tester This instrument is necessary for checking the ignition system components.	
ACC-1100-15-01	Quick Gasket ® This sealant is used to seal to mating surfaces (e.g., crankcase mating surfaces).	
90890-01348	Locknut wrench This tool is used to loosen and tighten the clutch carrier locknut of the secondary sheave.	
YU-33963 ① -1400 ②	Front fork seal driver Weight ① Adapter ② These tools are used when installing the fork seal.	
T-handle ① YM-01326 Holder YM-01300-1 ②	T-handle ① / Damper rod holder ② These tools are needed to loosen and tighten the damper rod holding bolt.	
YM-01312-A	Fuel level gauge This gauge is used to measure the fuel level in the float chamber.	

GENERAL SPECIFICATION**SPEC** **SPECIFICATION****GENERAL SPECIFICATION**

Model	YW50AP
Model code:	5PJ1
Dimensions:	
Overall length	1,890 mm(74.4 in)
Overall width	705 mm(27.8 in)
Overall height	1,110 mm(43.7 in)
Seat height	765 mm(30.1 in)
Wheelbase	1,275 mm(50.2 in)
Minimum ground clearance	120 mm(4.7 in)
Minimum turning radius	2,000 mm(78.7 in)
Basic weight:	
With oil and full fuel tank	94 kg(207 lb)
Engine:	
Engine type	Air cooled 2 strcke, gasoline torque induction
Cylinder arrangement	Forward- inclined single cylinder
Displacement	49cm ³ (2.99 cu.in)
Bore × stroke	40.0 × 39.2 mm(1.57 × 1.54 in)
Compression ratio	7.2:1
Starting system	Electric and kick starter
Lubrication system:	Separate lubrication
Oil Type or Grade:	
Engine Oil	For YAMAHA brand: Yamalube 2 or Air cooled 2-stroke engine oil (ISO EG-C, EG-D grade)
Transmission Oil	Yamalube 4 SAE 10W/30 SE or GL gear oil
Oil Capacity:	
Oil Tank (Engine Oil)	1.4 L (1.23 Imp.qt, 1.48 US qt)
Transmission Oil:	
Periodic Oil Change	0.11 L(0.096 Imp.qt, 0.12 US qt)
Total Amount	0.13 L(0.11 Imp.qt, 0.13 US qt)
Air Filter:	Wet type element
Fuel:	
Type	Regular unleaded gasoline
Tank Capacity	5.7 L (1.25 Imp.gal, 1.5 US gal)
Carburetor:	
Type / Manufacturer	Y14P/1/ TEIKEI

GENERAL SPECIFICATION

SPEC 


Model		YW50A
Spark Plug: Type/Manufacturer Gap		BPR7HS/NGK 0.6 ~ 0.7 mm(0.02 ~ 0.03 in)
Clutch Type		Dry, Centrifugal automatic
Transmission: Primary Reduction System Primary Reduction Ratio Secondary Reduction System Secondary Reduction Ratio Transmission Type Operation		Helical gear 4.000 Supur gear 3.666 V-belt Automatic
Chassis: Frame type Caster angle Trail		Steel tube underbone 26.5° 93mm(3.7 in)
Tire: Type Size front rear Manufacturer front rear Type front rear		Tubeless 120/90-10 130/90-10 CHENG SHIN CHENG SHIN 56J 59J
Maximum load* Cold tire Pressure: Up to 90 kg Front Rear 90 kg load~Maximum load* Front Rear		143 kg(315 lb) 200kpa(2.0 kg/cm ² , 29 psi) 200kpa(2.0 kg/cm ² , 29 psi) 200kpa(2.0 kg/cm ² , 29 psi) 200kpa(2.0 kg/cm ² , 29 psi)
Brake: Front brake type operation Rear brake type operation		Single disc brake Right hand operation Drum brake Left hand operation
Suspension: Front suspension Rear suspension		Telescopic fork Unit swing
Shock absorber: Front shock absorber Rear shock absorber		Coil spring/oil damper Coil spring/oil damper
Wheel travel: Front wheel travel Rear wheel travel		65 mm(2.56 in) 60 mm(2.36 in)
Electrical: Ignition system Generator system Battery type Battery capacity		C.D.I Flywheel Magneto YTX5L-BS 12V 4AH

GENERAL SPECIFICATION

SPEC 


Model	YW50A
Headlight type:	Bulb
Bulb wattage x quantity:	
Headlight	12V 35W/35W×2
Tail/brake light	12 V 5W/21W×1
Flasher light	10W×4
Licence plate light	5W×1
Meter light	3.4W×1/1.7W×1
High beam indicator light	1.7W×1
Oil indicator light	1.7W×1
Turn indicator light	1.7W×1

MAINTENANCE SPECIFICATION**ENGINE**

Item	Standard	Limit
Cylinder head: Warp limit 	...	0.03 mm (0.0012 in)
*Lines indicate straightedge measurement		
Cylinder: Bore size Taper limit Out of round limit	40.000~40.014mm (1.5748~1.5754 in)	40.10 mm (1.5787 in) 0.05 mm (0.0020 in) 0.03 mm (0.0012 in)
Piston: Piston to cylinder clearance Piston size "D" Measuring point "H" Piston pin bore inside diameter Piston pin outside diameter	0.035~0.040 mm (0.0014~0.0016 in) 39.958~39.972 mm (1.5731~1.5737 in) 5 mm(0.2 in) 10.004~10.015 mm (0.3939~0.3943 in) 9.996~10.000 mm (0.3935~0.3937 in)	0.10 mm (0.0039 in) 10.045 mm (0.4 in) 9.975 mm (0.39 in)
Piston Ring: Sectional Sketch (B × T)/Type Top Ring 2nd Ring End Gap (Installed): Top Ring 2nd Ring Side Clearance (Installed): Top Ring 2nd Ring	1.2 × 1.6 mm/ keystone (0.05 × 0.06 in) 1.2 × 1.6 mm/ keystone (0.05 × 0.06 in) 0.15~0.35 mm (0.005~0.01 in) 0.15~0.35 mm (0.005~0.01 in) 0.03~0.05 mm (0.0012~0.0020 in) 0.03~0.05 mm (0.0012~0.0020 in)	0.6 mm(0.02 in) 0.6 mm(0.02 in) 0.1 mm(0.0039 in) 0.1 mm(0.0039 in)

MAINTENANCE SPECIFICATION

SPEC 

Item	Standard	Limit
Crankshaft:		
Crank Width "A" Run Out Limit "C" Connecting Rod Big End Side Clearance "D" Small End Free Play "F"	 37.90~37.95 mm(1.49~1.49 in) 0.03 mm(0.0012 in) 0.2~0.5 mm (0.0029~0.020 in) 0.4~0.8 mm (0.016~0.031 in) 1.0 mm(0.04 in) ...
Automatic centrifugal clutch:		
Clutch shoe thickness Clutch housing inside diameter Clutch shoe spring free length Clutch - in revolution Clutch - stall revolution	4.0 mm(0.16 in) 105 mm (4.13 in) 94 mm(3.7 in) 3,300~3,700 r/min 5,500~6,500 r/min	2.5 mm(0.1 in) 105.5 mm (4.15 in) 91 mm(3.58 in)
V-belt:		
V-belt width	16.6 mm(0.65 in)	14.6 mm(0.57 in)
Kick Starter:		
Type Kick Clip Tension	Ratchet type 1.5~2.5 N (0.15~0.25 kgf) (0.34~0.56 lb)	
Carburetor:		
I.D. Mark Main Jet (M.J.) Needle jet (N.J.) Jet Needle-clip Position (J.N.) Main Air Jet (M.A.J.) Cutaway (C.A.) Pilot Jet (P.J.) Bypass Valve Seat Size (V.S.) Starter Jet (G.S.)	5DA-01 #80 2.085 3N24-3/5 2.0 3.5 #44 0.8 1.8 #48 15 ~ 17 mm(0.59 ~ 0.67 in) 3.0~4.0 mm(0.12 ~ 0.16 in)	
Fuel level height Engine Idling Speed		
Reed Valve:		
Thickness Valve Stopper Height Valve bending limit	0.150~0.154 mm(0.059~0.0060 in) 6.0~6.4 mm(0.24~0.25 in) 0.2 mm (0.0078)	

MAINTENANCE SPECIFICATION

SPEC



TIGHTENING TORQUES ENGINE

Part to be tightened	Part name	Thread size	Q'ty	Tightening torque			Remarks
				Nm	m•kg	ft•lb	
Spark plug	—	M 14	1	20	2.0	14	
Cylinder head and cylinder	Nut	M 7	4	14	1.4	10	
Cylinder	Stud bolt	M 7	4	10	1.0	7	
Air shroud 1	Screw	M 6	3	7	0.7	5.1	
Air shroud 1×2	Screw	6.0	1	2	0.2	1.4	
Fan	Screw	M 6	3	7	0.7	5.1	
Autolube pump	Screw	M 5	2	4	0.4	2.8	
Reed valve	Bolt	M 6	4	11	1.1	8.0	
Air filter	Screw	M 6	2	9	0.9	6.5	
Carburetor cap	Screw	M 4	2	2	0.2	1.4	
Exhaust pipe	Screw	M 6	2	9	0.9	6.5	
Muffler	Bolt	M 8	2	26	2.6	18.2	
Exhaust protector	Bolt	M 6	3	11	1.1	8.0	-G
Protector	Screw	M 6	1	9	0.9	6.5	-G
Crankcase 1×2	Bolt	M 6	6	12	1.2	8.4	
Transmission case cover	Bolt	M 6	6	12	1.2	8.4	
Crankcase cover 1(left)	Bolt	M 6	12	12	1.2	8.4	
Bolt(case2)	Screw	M 6	1	7	0.7	5.1	
Crankcase cover2(left)	Bolt	M 6	3	7	0.7	5.1	
Drain bolt	Bolt	M 8	1	18	1.8	13	
Oil plug	Plug	M 14	1	3	0.3	22	
Idle gear plate	Screw	M 6	2	8	0.8	5.8	
Kick crank	Bolt	M 6	1	9	0.9	6.5	
Starter motor	Bolt	M 6	2	13	1.3	9.4	
Clutch housing	Nut	M 10	1	40	4.0	29	
Clutch weight	Nut	M 10	1	30	3.0	22	
Magnet base	Screw	M 6	2	8	0.8	5.8	
C.D.I. rotor	Nut	M 10	1	38	3.8	27	

MAINTENANCE SPECIFICATION

SPEC 

CHASSIS

Item	Standard	Limit
Steering system: Steering bearing type No /size of steel balls:	Ball and race bearing 22 pcs 19 pcs
Front suspension: Front fork travel Fork spring free length Fork length (Installed) Spring rate (K1) (K2) Inner tube vend limit	70 mm(2.8 in) 236.6 mm(9.31 in) 212.1 mm(8.35 in) 15.68 Nm/mm(1.6 kg/mm,90lb/in) 23.5 Nm/mm(2.43 kg/mm,136lb/in) ...	233.6 mm 0.2 mm (0.008 in)
Rear suspension: Shock absorber stroke Shock absorber free length (Installed) Spring free length (Installed) Spring rate (K1)	55 mm(2.2 in) 281.8 mm(11.1 in) 159.8 mm(6.29 in) 71.15 N/mm(7.26 kg/mm,407lb/in)
Front wheel: Type Rim size Rim material Rim runout limit	Cast wheel MT3.50×10 Aluminum 1 mm(0.04 in) 1 mm(0.04 in)
Rear wheel: Type Rim size Rim material Rim runout limit	Cast wheel MT3.50×10 Aluminum 1 mm(0.04 in) 1 mm(0.04 in)
Front disc brake: Type Disc outside diameter × thickness Pad thickness Master cylinder inside diameter Caliper cylinder outside diameter Brake fluid type	Single 180×4.0mm (7.1×0.16 in) 6 mm(0.24 in) 11 mm(0.4 in) 34.93 mm(1.38 in) DOT #4(or DOT #3)	... 180×3.5 mm (7.1×0.14in) 0.8 mm(0.03 in)
Rear drum brake: Type Drum inside diameter Shoe thickness	Leading, trailing 130 mm(5.12 in) 4 mm(0.16 in)	... 131 mm(5.16 in) 2 mm(0.08 in)
Brake lever: Brake lever free play (front at lever side) Brake lever free play (rear) Throttle cable free play	2~5 mm(0.08~0.20 in) 10~20 mm(0.39~0.79 in) 3~5 mm(0.12~0.20 in)

MAINTENANCE SPECIFICATION

SPEC 

TIGHTENING TORQUES CHASSIS

Part to be tightened	Thread size	Tightening torque			Remarks
		Nm	m·kg	ft·lb	
Frame and engine bracket	M 12	84	8.4	61	
Engine bracket, compression rod and engine	M 10	45	4.5	31	
Rear carrier	M 6	13	1.3	9.4	
Rear shock absorber and frame	M 10	30	3.0	22	
Rear shock absorber and engine	M 8	16	1.6	12	
Steering ring nut	M 25	22	2.2	16	See "page3-18"
Handle holder and steering shaft	M 10	43	4.3	37	
Brake hose and master cylinder	M 8	20	2.0	14	
Fuel tank	M 6	10	1.0	7	
Fuel cock	M 6	7	0.7	5.1	
Fuel sender	M 5	4	0.4	2.9	
Box	M 6	7	0.7	5.1	
Seat lock assembly	M 6	7	0.7	5.1	
Plastic parts & cover	M 5	2	0.2	1.4	
Footrest board	M 6	7	0.7	5.1	
Front wheel axle and nut	M 10	70	7.0	51	
Rear wheel axle and nut	M 14	120	12.0	87	
Rear brake cam lever	M 6	10	1.0	7.2	
Front brake caliper and front fork	M 8	23	2.3	16.6	- 
Brake disc and hub	M 10	20	2.0	14.5	
Brake hose and caliper	M 8	23	2.3	16.6	
Brake caliper and bleed screw	M 5	6	0.6	4.3	

MAINTENANCE SPECIFICATION

SPEC 

ELECTRICAL

Item	Standard	limit
Ignition timing: Ignition timing (B.T.D.C.) Advanced type	14° at 5,000 r/min Fixed
C.D.I.: Pickup coil resistance/color Source coil resistance/color	248 ~ 372Ω at 20°C (68°F) (W/R-W/L) 640 ~ 960 Ω at 20°C (68°F) (B/ R-G/W)
C.D.I. unit model/manufacturer	5PJ/TIIC	...
Ignition coil: Model/manufacturer Minimum spark gap Primary winding resistance Secondary winding resistance	4WX/TIIC 6 mm (0.24 in) 0.32~0.48 Ω at 20°C (68°F) 5.68~8.52kΩ at 20°C (68°F)
Spark plug cap: Type Resistance	Resin 5 kΩ
Charging System/Type:	Flywheel magneto	...
C.D.I. Magneto: Model/Manufacturer Nominal output Charging current Charging voltage Charging Coil Resistance (Color) Lighting Coil Resistance (Color) Lighting Voltage Rectifier: Model/Manufacturer Capacity Withstand voltage	5PJ/TIIC 12V 85W/5,000 rpm 0.6A at 3,000r/min 1.2A at 8,000r/min 13~14V at 4,000 rpm 0.48~0.72 Ω (White-Black) 0.4~0.6 Ω (Yellow/Red- Black) 12~15V (3,000~8,000 rpm) 3GF/Taichung 8A 18V
Battery: Specific gravity	1.320	...
Electric starter system: Type Starter motor: Model/manufacturer/ID number Output Armature coil resistance Brush overall length Spring force Commutator diameter Mica undercut (depth)	Constant mesh type 4WX/shulin 0.14 kw 0.0648 ~ 0.0792 Ω at 20°C (68°F) 6.5 mm (0.26 in) 5.49 ~ 8.24 N (360~540 g) (12.69~19.04 oz) 16.1 mm (0.63 in) 1.05 mm (0.04 in) 3 mm (0.12 in) 400g 15.1 mm (0.59 in) ...
Starter relay: Model/manufacturer Amperage rating Coil resistance	4WX/Shulin 20A 54~66 Ω

MAINTENANCE SPECIFICATION

SPEC 

Item	Standard	limit
Horn: Model/manufacturer Maximum amperage	4KP/Asian 1.5A
Flasher relay: Type Flasher frequency	Capacitor 60~120 Cycle/min
Fuel gage: Model/manufacturer Sender unit resistance	4VP/San Chu 4~10 Ω 90~100 Ω
Oil level gauge: Model/manufacturer	4VP/Lun Ping	...
Circuit breaker: Type MAIN	Fuse 7Ax1pc.


GENERAL TORQUE SPECIFICATIONS

SPEC 

GENERAL TORQUE SPECIFICATIONS

This chart specifies torque for standard fasteners with standard I.S.O. pitch threads. Torque specifications for special components or assemblies are included in the applicable sections of this book. To avoid warpage, tighten multi-fastener assemblies in a crisscross fashion, in progressive stages, until full torque is reached. Unless otherwise specified, torque specifications call for clean, dry threads. Components should be at room temperature.

A (Nut)	B (Bolt)	General torque specifications		
		Nm	m·kg	ft·lb
10 mm	6 mm	6	0.6	4.3
12 mm	8 mm	15	1.5	11
14 mm	10 mm	30	3.0	22
17 mm	12 mm	55	5.5	40
19 mm	14 mm	85	8.5	61
22 mm	16 mm	130	13.0	94



A: Distance across flats

B: Outside thread diameter



LUBRICATION POINTS AND LUBRICATION TYPE

ENGINE

Lubrication Point	Lubricant Type
Oil seal lips	
O-rings	
Bearings	
Piston surface	
Piston pin	
Cylinder	
Transmission case (bearing)	
Autolube pump	
Starter wheel gear	
Idle gear plate	
Secondary drive gear	
Kickstarter pinion gear	
Drive axle	
Pump drive gear	
Main axle	
Main axle (bearing)	

LUBRICATION POINTS AND LUBRICATION TYPE

SPEC




CHASSIS

Lubrication Point	Lubricant Type
Oil seal lips	A small icon showing a horizontal line with a circle containing the letters "LS" at one end.
O-rings	A small icon showing a horizontal line with a circle containing the letters "LS" at one end.
Bearings	A small icon showing a horizontal line with a circle containing the letters "LS" at one end.
Speedometer drive gear	A small icon showing a horizontal line with a circle containing the letters "LS" at one end.
Front brake camshaft	A small icon showing a horizontal line with a circle containing the letters "LS" at one end.
Front brake cable	A small icon showing a horizontal line with a circle containing the letters "LS" at one end.
Throttle cable	A small icon showing a horizontal line with a circle containing the letters "LS" at one end.
Tube guide (throttle grip) inner surface	A small icon showing a horizontal line with a circle containing the letters "LS" at one end.
Upper steering stem ring nut	A small icon showing a horizontal line with a circle containing the letters "LS" at one end.
Upper bearing outer race	A small icon showing a horizontal line with a circle containing the letters "LS" at one end.
Lower bearing outer race	A small icon showing a horizontal line with a circle containing the letters "LS" at one end.
Rear brake camshaft	A small icon showing a horizontal line with a circle containing the letters "LS" at one end.
Centerstand	A small icon showing a horizontal line with a circle containing the letters "LS" at one end.

CABLE ROUTING

- ① Horn
- ② Rectifier regulator
- ③ Main switch
- ④ Headlight leads
- ⑤ Speedometer cable
- ⑥ Ignition coil
- ⑦ Throttle cable 1
- ⑧ Throttle cable 3
- ⑨ Battery negative(-)
- ⑩ Wire brake
- ⑪ Fuel sender lead
- ⑫ Seat lock cable
- ⑬ Oil tank hose
- ⑭ C.D.I. unit

- ⑯ Wire harness
- A Pass the speedometer cable through the right hole of front fender, then through the guide.
- B Pass the wire harness through the inside of ignition coil.
- C Secure the ground lead and the ignition coil base to the ignition coil stay.
- D Pass the wire harness through the inside of oil tank.
- E Pass the seat cable through the inside of frame.
- F Align the clip with the white brand.
- G Clamp the wire harness.
- H Insert the seat cable through the frame tube.
- I Clamp wireharness, rear brake cable throttle cable 1,3.
- J Position the cylinder between the supporter and main switch.




CABLE ROUTING

SPEC



- ① Brake cable
- ② Speedometer cable
- ③ Fuel tank overflow hose
- ④ Brake cable holder
- ⑤ Brake hose
- ⑥ Brake hose holder
- ⑦ License bracket
- ⑧ Flasher relay
- ⑨ Fuel tank breather hose
- ⑩ Fuel hose
- ⑪ Breather hose

- A Pass the brake hose through the holder.
- B Insert the fuel overflowhose bottom.
- C Pass the fuel overflowhose through the rear fender hole.
- D Pass the fuel overflowhose through the holder.
- E Hold the fuel overflowhose with a clamp.
- F Pass the brake cable through the holder.





Download the full PDF manual instantly.

Our customer service e-mail:

aservicemanualpdf@yahoo.com