

PREFACE

This manual covers the construction, function and serving procedures for the Honda BF135A•BF150A outboard motors.

All information contained in this manual is based on the latest product information available at the time of printing. We reserve the right to make changes at anytime without notice.


No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, by any means, electronic, mechanical, photocopying, recording, or otherwise, without prior written permission of the publisher. This includes text, figures, and tables.

As you read this manual, you will find information that is preceded by a **NOTICE** symbol. The purpose of this message is to help prevent damage to the outboard motor, other property, or the environment.

SAFETY MESSAGES

Your safety, and the safety of others, are very important. To help you make informed decisions, we have provided safety messages and other safety information throughout this manual. Of course, it is not practical or possible to warn you about all the hazards associated with servicing these outboard motors. You must use your own good judgment.

You will find important safety information in a variety of forms, including:

- **Safety Labels** -- on the engine cover.
- **Safety messages** -- Preceded by a safety alert symbol  and one of three signal words, DANGER, WARNING, or CAUTION.

These signal words mean:

DANGER

You **WILL** be **KILLED** or **SERIOUSLY HURT** if you don't follow instructions.

WARNING

You **CAN** be **KILLED** or **SERIOUSLY HURT** if you don't follow instructions.

CAUTION

You **CAN** be **HURT** if you don't follow instructions.

- **Instructions** -- how to service this outboard motor correctly and safely.

Honda Motor Co., Ltd.
Service Publications Office

CONTENTS

| | |
|---|-----------|
| SPECIFICATIONS | 1 |
| SERVICE INFORMATION | 2 |
| MAINTENANCE | 3 |
| ENGINE COVER/COVER LOCK | 4 |
| PROGRAMMED-FUEL INJECTION | 5 |
| ALTERNATOR | 6 |
| ENGINE REMOVAL/INSTALLATION | 7 |
| THERMOSTAT/RELIEF VALVE/FLUSH VALVE | 8 |
| CRANKSHAFT PULLEY/CAM CHAIN | 9 |
| CYLINDER HEAD/VALVES | 10 |
| OIL PUMP/FLYWHEEL | 11 |
| CRANKCASE/BALANCER | 12 |
| CYLINDER BLOCK/CRANKSHAFT/PISTONS | 13 |
| PROPELLER/GEAR CASE/EXTENSION CASE/OIL CASE | 14 |
| MOUNTING CASE/STERN BRACKET/SWIVEL CASE/POWER TRIM/TILT ASSEMBLY | 15 |
| STEERING ROD/REMOTE CONTROL BOX | 16 |
| CABLES/SHIFT LINK BRACKET/SHIFT ARM/NEUTRAL SWITCH | 17 |
| ELECTRICAL EQUIPMENT | 18 |
| OPERATION | 19 |
| SYSTEM DIAGRAM/WIRING DIAGRAM | 20 |

| | | | |
|--|------------|--|------------|
| 1. SPECIFICATIONS | 1-1 | 3. MAINTENANCE | 3-1 |
| 1. SPECIFICATIONS | 1-1 | 1. MAINTENANCE SCHEDULE | 3-1 |
| 2. DIMENSIONAL DRAWINGS | 1-4 | 2. ENGINE OIL | 3-2 |
| 2. SERVICE INFORMATION | 2-1 | 3. OIL FILTER | 3-3 |
| 1. THE IMPORTANCE OF PROPER SERVICING | 2-1 | 4. GEAR CASE OIL | 3-4 |
| 2. IMPORTANT SAFETY PRECAUTIONS | 2-1 | 5. SPARK PLUGS | 3-6 |
| 3. SERVICE RULES | 2-2 | 6. VALVE CLEARANCE | 3-9 |
| 4. SYMBOLS USED IN THIS MANUAL | 2-2 | 7. FUEL STRAINER (LOW PRESSURE SIDE) | 3-15 |
| 5. SERIAL NUMBER LOCATIONS | 2-2 | 8. FUEL STRAINER (HIGH PRESSURE SIDE) | 3-18 |
| 6. MAINTENANCE STANDARDS | 2-3 | 9. WATER SEPARATOR with WATER LEVEL SENSOR | 3-19 |
| 7. TORQUE VALUES | 2-7 | 10. IDLING | 3-22 |
| 8. SPECIAL TOOLS | 2-10 | 11. SHIFT CONTROL CABLE | 3-24 |
| 9. TROUBLESHOOTING | 2-14 | 12. THROTTLE CONTROL CABLE/ THROTTLE LINK | 3-26 |
| a. ENGINE | 2-14 | 13. REMOTE CONTROL LEVER FRICTION | 3-28 |
| HARD STARTING | 2-14 | 14. ALTERNATOR BELT | 3-28 |
| CYLINDER COMPRESSION TEST | 2-15 | 4. ENGINE COVER/COVER LOCK | 4-1 |
| ENGINE DOES NOT RUN SMOOTHLY | 2-16 | 1. ENGINE COVER | 4-2 |
| b. IGNITION (POWER) SYSTEM | 2-20 | 2. FRONT SEPARATE COVER | 4-7 |
| ENGINE DOES NOT START | 2-20 | 3. L./R. ENGINE UNDER COVERS | 4-9 |
| FUZE LOAD CHART | 2-21 | 4. UNDER COVER FRONT BRACKET/ L./R. SIDE COVER BRACKETS | 4-20 |
| FUZE BOX CONNECTION TABLE | 2-22 | 5. PROGRAMMED-FUEL INJECTION | 5-1 |
| c. STARTER SYSTEM | 2-23 | 1. SERVICE PRECAUTIONS | 5-2 |
| ENGINE DOES NOT START | 2-23 | 2. CIRCUIT DIAGRAM | 5-3 |
| d. IGNITION SYSTEM | 2-25 | 3. VACUUM CONNECTIONS | 5-5 |
| ENGINE IS HARD TO START | 2-25 | 4. PARTS LOCATION/ ECM TERMINAL LAYOUT | 5-6 |
| e. FUEL SYSTEM | 2-28 | 5. TROUBLESHOOTING | 5-11 |
| ENGINE IS HARD TO START | 2-28 | 6. TROUBLESHOOTING WITH HDS TESTER | 5-13 |
| f. CHARGING SYSTEM | 2-30 | a. TROUBLESHOOTING GUIDE BY DTC | 5-15 |
| BATTERY UNDER CHARGED | 2-30 | b. TROUBLESHOOTING | 5-18 |
| ACG INDICATOR LINE INSPECTION | 2-31 | MIL DOES NOT COME ON | 5-18 |
| g. ALERT SYSTEM | 2-32 | MIL COMES ON BUT DTC CODE DOES NOT APPEAR | 5-21 |
| OIL ALERT SYSTEM | 2-32 | ALERT SYSTEM INITIAL OPERATION IS FAULTY | 5-23 |
| OVERHEAT ALERT SYSTEM | 2-32 | NEUTRAL SWITCH MALFUNCTION | 5-26 |
| ALTERNATOR WARNING SYSTEM | 2-32 | TACHOMETER MALFUNCTION | 5-27 |
| FULL WATER (IN WATER SEPARATOR) WARNING SYSTEM | 2-32 | ECM TROUBLESHOOTING | 5-28 |
| MIL WARNING SYSTEM | 2-32 | MAP SENSOR TROUBLESHOOTING | 5-28 |
| WARNING SYSTEM | 2-32 | CKP SENSOR TROUBLESHOOTING | 5-30 |
| WARNING BUZZER SOUNDS CONTINUOUSLY | 2-33 | ECT SENSOR 1 TROUBLESHOOTING | 5-33 |
| OIL PRESSURE INSPECTION | 2-35 | TP SENSOR TROUBLESHOOTING | 5-34 |
| INTERMITTENT PROLONGED SOUND OF WARNING BUZZER KEEPS SOUNDING | 2-37 | CMP SENSOR TROUBLESHOOTING | 5-36 |
| INTERMITTENT SHORT SOUND OF WARNING BUZZER KEEPS SOUNDING | 2-38 | IAT SENSOR TROUBLESHOOTING | 5-38 |
| h. SHIFT MECHANISM | 2-39 | BARO SENSOR TROUBLESHOOTING | 5-39 |
| i. POWER TRIM/TILT ASSEMBLY | 2-40 | IAC VALVE TROUBLESHOOTING | 5-41 |
| POWER TRIM/TILT ASSEMBLY DOES NOT MOVE | 2-40 | VTEC SOLENOID VALVE TROUBLESHOOTING | 5-42 |
| POWER TRIM/TILT ASSEMBLY DOES NOT HOLD | 2-41 | KNOCK SENSOR TROUBLESHOOTING | 5-43 |
| POWER TRIM/TILT MOTOR DOES NOT MOVE | 2-42 | A/F SENSOR HEATER TROUBLE- SHOOTING | 5-44 |
| POWER TRIM/TILT ASSEMBLY QUICK REFERENCE CHART | 2-43 | A/F SENSOR TROUBLESHOOTING | 5-49 |
| CHECK POINT | 2-44 | ECT SENSOR 2 TROUBLESHOOTING | 5-51 |
| 10. CABLE/HARNESS ROUTING | 2-45 | ECT SENSOR 3 TROUBLESHOOTING | 5-52 |
| 11. TUBE ROUTING | 2-66 | | |
| 12. LUBRICATION | 2-77 | | |

| | |
|--|-------------|
| EOP SWITCH (HIGH PRESSURE SIDE) TROUBLESHOOTING | 5-54 |
| ECT SENSOR 4 TROUBLESHOOTING | 5-55 |
| 7. TROUBLESHOOTING WITHOUT | |
| HDS TESTER | 5-57 |
| a. TROUBLESHOOTING GUIDE | 5-59 |
| b. TROUBLESHOOTING | 5-61 |
| MIL DOES NOT COME ON | 5-61 |
| MIL ON BUT MIL DOES NOT BLINK WITH SCS CIRCUIT SHORTED | 5-64 |
| ALERT SYSTEM INITIAL OPERATION IS FAULTY | 5-66 |
| NEUTRAL SWITCH MALFUNCTION | 5-70 |
| TACHOMETER MALFUNCTION | 5-70 |
| MAP SENSOR TROUBLESHOOTING | 5-71 |
| CKP SENSOR TROUBLESHOOTING | 5-72 |
| ECT SENSOR 1 TROUBLESHOOTING | 5-74 |
| TP SENSOR TROUBLESHOOTING | 5-75 |
| CMP SENSOR TROUBLESHOOTING | 5-77 |
| IAT SENSOR TROUBLESHOOTING | 5-78 |
| BARO SENSOR TROUBLESHOOTING | 5-80 |
| IAC VALVE TROUBLESHOOTING | 5-81 |
| VTEC SOLENOID VALVE TROUBLE- SHOOTING | 5-82 |
| KNOCK SENSOR TROUBLESHOOTING | 5-83 |
| ECT SENSOR 2 TROUBLESHOOTING | 5-84 |
| ECT SENSOR 3 TROUBLESHOOTING | 5-86 |
| EOP SWITCH (HIGH PRESSURE SIDE) TROUBLESHOOTING | 5-87 |
| ECT SENSOR 4 TROUBLESHOOTING | 5-89 |
| A/F SENSOR HEATER TROUBLE- SHOOTING | 5-90 |
| A/F SENSOR TROUBLESHOOTING | 5-92 |
| 8. IDLE CONTROL SYSTEM | 5-93 |
| TROUBLESHOOTING | 5-93 |
| IDLE ADJUSTING SCREW ADJUSTMENT | 5-94 |
| THROTTLE BODY INSPECTION/ CLEANING | 5-95 |
| IAC VALVE REPLACEMENT | 5-95 |
| 9. FUEL SUPPLY SYSTEM | 5-96 |
| TROUBLESHOOTING | 5-96 |
| PGM-FI MAIN RELAY HARNESS INSPECTION | 5-97 |
| INJECTOR HARNESS INSPECTION | 5-100 |
| HOW TO RELIEVE FUEL PRESSURE | 5-102 |
| FUEL PRESSURE MEASUREMENT | 5-102 |
| FUEL LINE INSPECTION | 5-104 |
| FUEL INJECTOR INSPECTION | 5-105 |
| PRESSURE REGULATOR INSPECTION | 5-106 |
| FUEL PUMP (HIGH PRESSURE SIDE) INSPECTION | 5-107 |
| 10. IAB (INTAKE AIR BYPASS) CONTROL SYSTEM | 5-109 |
| IAB CONTROL VALVE INSPECTION | 5-109 |
| SHUTTER VALVE DIAPHRAGM INSPECTION | 5-110 |
| 11. VAPOR SEPARATOR/FUEL PUMP (HIGH PRESSURE SIDE) | 5-111 |
| 12. SILENCER CASE/THROTTLE BODY/ INTAKE MANIFOLD | 5-128 |
| 13. FUEL INJECTOR/PRESSURE REGULATOR | 5-136 |
| 14. FUEL PUMP (LOW PRESSURE SIDE) | 5-142 |
| 15. FUEL STRAINER (LOW PRESSURE SIDE)/ WATER SEPARATOR | 5-144 |
| 16. EOP (ENGINE OIL PRESSURE) SWITCH (HIGH PRESSURE SIDE) | 5-146 |
| 17. EOP (ENGINE OIL PRESSURE) SWITCH (LOW PRESSURE SIDE) | 5-146 |
| 18. ECT (ENGINE COOLANT TEMPERATURE) SENSOR 1 | 5-147 |
| 19. ECT (ENGINE COOLANT TEMPERATURE) SENSOR 2, 3, 4 | 5-148 |
| 20. BARO (BAROMETRIC PRESSURE) SENSOR | 5-149 |
| 21. KNOCK SENSOR | 5-149 |
| 22. CMP (CAMSHAFT POSITION) SENSOR | 5-149 |
| 23. CKP (CRANKSHAFT POSITION) SENSOR | 5-150 |
| 24. VTEC SOLENOID VALVE | 5-150 |
| 25. VAPOR CHAMBER/CHECK VALVE | 5-151 |
| 26. EXHAUST MANIFOLD | 5-152 |
| 6. ALTERNATOR | 6-1 |
| 1. SILENCER DUCT | 6-2 |
| 2. ALTERNATOR | 6-5 |
| 7. ENGINE REMOVAL/INSTALLATION | 7-1 |
| 1. REMOVAL | 7-2 |
| 2. INSTALLATION | 7-6 |
| 8. THERMOSTAT/RELIEF VALVE/FLUSH VALVE | 8-1 |
| 1. THERMOSTAT | 8-2 |
| 2. WATER RELIEF TUBE/RELIEF VALVE | 8-5 |
| 3. FLUSH VALVE | 8-10 |
| 9. CRANKSHAFT PULLEY/CAM CHAIN | 9-1 |
| 1. DISASSEMBLY | 9-2 |
| 2. ASSEMBLY | 9-9 |
| 10. CYLINDER HEAD/VALVES | 10-1 |
| 1. CYLINDER HEAD COVER REMOVAL | 10-2 |
| 2. CYLINDER HEAD COVER DISASSEMBLY | 10-4 |
| 3. CAMSHAFT/ROCKER ARM DISASSEMBLY | 10-5 |
| 4. CAMSHAFT/ROCKER ARM INSPECTION | 10-13 |
| 5. CYLINDER HEAD ASSEMBLY REMOVAL | 10-19 |
| 6. CYLINDER HEAD ASSEMBLY DISASSEMBLY | 10-20 |
| 7. CYLINDER HEAD ASSEMBLY INSPECTION | 10-23 |
| 8. VALVE GUIDE REPLACEMENT | 10-26 |
| 9. VALVE SEAT RECONDITIONING | 10-28 |
| 10. CYLINDER HEAD ASSEMBLY ASSEMBLY | 10-30 |
| 11. CYLINDER HEAD ASSEMBLY INSTALLATION | 10-32 |
| 12. CAMSHAFT/ROCKER ARM ASSEMBLY | 10-34 |
| 13. CYLINDER HEAD COVER ASSEMBLY | 10-38 |
| 14. CYLINDER HEAD COVER INSTALLATION | 10-40 |

| | | | |
|---|-------------|---|-------------|
| 11. OIL PUMP/FLYWHEEL | 11-1 | 16. STEERING ROD/REMOTE CONTROL BOX | 16-1 |
| 1. EOP SWITCH/OIL FILTER FLANGE | 11-2 | 1. STEERING ROD..... | 16-1 |
| 2. OIL PUMP | 11-6 | 2. REMOTE CONTROL BOX (OPTIONAL PART) | 16-2 |
| 3. FLYWHEEL..... | 11-12 | 3. CONTROL PANEL (OPTIONAL PART) | 16-7 |
| 12. CRANKCASE/BALANCER | 12-1 | 4. INSPECTION | 16-9 |
| 1. CRANKCASE/BALANCER CASE ASSEMBLY REMOVAL | 12-2 | 17. CABLES/SHIFT LINK BRACKET/SHIFT ARM/NEUTRAL SWITCH | 17-1 |
| 2. BALANCER CASE ASSEMBLY DISASSEMBLY | 12-5 | 1. REMOTE CONTROL CABLE/GROMMET | 17-2 |
| 3. INSPECTION | 12-6 | 2. SHIFT LINK BRACKET/NEUTRAL SWITCH | 17-11 |
| 4. BALANCER CASE ASSEMBLY ASSEMBLY | 12-7 | 3. SEAL HOLDER..... | 17-20 |
| 5. CRANKCASE/BALANCER CASE ASSEMBLY INSTALLATION | 12-8 | 18. ELECTRICAL EQUIPMENT | 18-1 |
| 13. CYLINDER BLOCK/CRANKSHAFT/PISTONS | 13-1 | 1. STARTER MOTOR..... | 18-1 |
| 1. DISASSEMBLY | 13-2 | 2. STARTER CABLE | 18-15 |
| 2. INSPECTION | 13-8 | 3. ECM/PGM-FI MAIN RELAY/FUSE BOX | 18-19 |
| 3. BEARING SELECTION | 13-15 | 4. POWER TILT RELAY/CONNECTOR BRACKET A | 18-27 |
| 4. ASSEMBLY | 13-19 | 19. OPERATION | 19-1 |
| 14. PROPELLER/GEAR CASE/EXTENSION CASE/OIL CASE | 14-1 | 1. DOHC (SWING ARM TYPE) + VTEC | 19-1 |
| 1. PROPELLER..... | 14-2 | 2. CHAIN DRIVE CAM DRIVE SYSTEM | 19-2 |
| 2. GEAR CASE ASSEMBLY [*1]..... | 14-3 | 3. INDEPENDENT CYLINDER HEAD/CYLINDER BLOCK COOLING SYSTEM..... | 19-3 |
| 3. WATER PUMP/SHIFT ROD [*1] | 14-7 | 4. AIR/FUEL RATIO O ₂ FEEDBACK CONTROL BY A/F SENSOR | 19-4 |
| 4. PROPELLER SHAFT HOLDER ASSEMBLY [*1] | 14-17 | 20. WIRING DIAGRAM/SYSTEM DIAGRAM | 20-1 |
| 5. PROPELLER SHAFT/PROPELLER SHAFT HOLDER [*1] | 14-18 | | |
| 6. VERTICAL SHAFT/BEVEL GEAR [*1]..... | 14-27 | | |
| 7. SHIM SELECTION [*1] | 14-35 | | |
| 8. SHIM POSITION [*1] | 14-40 | | |
| 9. BACKLASH ADJUSTMENT [*1] | 14-41 | | |
| 10. GEAR CASE ASSEMBLY [*2]..... | 14-42 | | |
| 11. WATER PUMP/SHIFT ROD [*2] | 14-46 | | |
| 12. PROPELLER SHAFT HOLDER ASSEMBLY [*2] | 14-56 | | |
| 13. PROPELLER SHAFT/PROPELLER SHAFT HOLDER [*2] | 14-57 | | |
| 14. VERTICAL SHAFT/BEVEL GEAR [*2]..... | 14-68 | | |
| 15. SHIM SELECTION [*2] | 14-77 | | |
| 16. SHIM POSITION [*2] | 14-84 | | |
| 17. BACKLASH ADJUSTMENT [*2] | 14-85 | | |
| 18. ANODE METAL/WATER SCREEN | 14-88 | | |
| 19. EXTENSION CASE/LOWER RUBBER MOUNT | 14-89 | | |
| 20. OIL CASE | 14-94 | | |
| 15. MOUNTING CASE/STERN BRACKET/SWIVEL CASE/POWER TRIM/TILT ASSEMBLY | 15-1 | | |
| 1. MOUNTING CASE | 15-2 | | |
| 2. STERN BRACKET/SWIVEL CASE REMOVAL/INSTALLATION | 15-10 | | |
| 3. STERN BRACKET/SWIVEL CASE/POWER TRIM/TILT ASSEMBLY | 15-14 | | |
| 4. POWER TRIM/TILT ASSEMBLY | 15-36 | | |
| 5. AIR BLEEDING | 15-48 | | |
| 6. BLOW PRESSURE INSPECTION | 15-50 | | |
| 7. POWER TILT MOTOR ASSEMBLY..... | 15-53 | | |

BF135A•BF150A

Abbreviations

| | |
|-----------|---------------------------------|
| ACG | Alternator |
| A/F | Air Fuel Ratio |
| API | American Petroleum Institute |
| Approx. | Approximately |
| Assy. | Assembly |
| ATDC | After Top Dead Center |
| ATF | Automatic Transmission Fluid |
| ATT | Attachment |
| BAT | Battery |
| BDC | Bottom Dead Center |
| BTDC | Before Top Dead Center |
| BARO | Barometric Pressure |
| CKP | Crankshaft Position |
| Comp. | Complete |
| CMP | Camshaft Position |
| CYL | Cylinder |
| DLC | Data Link Connector |
| ECT | Engine Coolant Temperature |
| ECM | Engine Control Module |
| EOP | Engine Oil Pressure |
| EX | Exhaust |
| F | Front or Forward |
| GND | Ground |
| IAB | Intake Air Bypass |
| IAC | Idle Air Control |
| IAT | Intake Air Temperature |
| I.D. | Inside Diameter |
| IG or IGN | Ignition |
| IN | Intake |
| INJ | Injection |
| L. | Left |
| MAP | Manifold Absolute Pressure |
| MIL | Malfunction Indicator Lamp |
| O.D. | Outside Diameter |
| OP | Optional Part |
| PGM-FI | Programmed-Fuel Injection |
| P/N | Part Number |
| Qty | Quantity |
| R. | Right |
| SAE | Society of Automotive Engineers |
| SCS | Service Check Signal |
| STD | Standard |
| SW | Switch |
| TDC | Top Dead Center |
| TP | Throttle Position |

| | | | | | | | |
|----|--------|---|-------|----|------------|----|-------------|
| Bl | Black | G | Green | Br | Brown | Lg | Light green |
| Y | Yellow | R | Red | O | Orange | P | Pink |
| Bu | Blue | W | White | Lb | Light blue | Gr | Gray |

1. SPECIFICATIONS

BF135A•BF150A

| | |
|-------------------|-------------------------|
| 1. SPECIFICATIONS | 2. DIMENSIONAL DRAWINGS |
|-------------------|-------------------------|

1. SPECIFICATIONS

• DIMENSIONS AND WEIGHTS

| Model | BF135A | | | | | | |
|----------------------------------|--------------------|----|------------------|--------------------|------------------|------|-----|
| Description code | BARJ | | BASJ | BARJ | | BASJ | |
| Types | LC | LD | LCD | XC | XD | XCC | XCD |
| Overall length | 845 mm (33.3 in) | | | | | | |
| Overall width | 580 mm (22.8 in) | | | | | | |
| Overall height | 1,665 mm (65.6 in) | | | 1,790 mm (70.5 in) | | | |
| Dry weight (*1) | 220 kg (485 lbs) | | 223 kg (492 lbs) | | 226 kg (498 lbs) | | |
| Operating weight (including oil) | 228 kg (503 lbs) | | 231 kg (509 lbs) | | 234 kg (516 lbs) | | |

*1: With propeller mounted.

| Model | BF150A | | | | | | |
|----------------------------------|--------------------|----|------------------|--------------------|------------------|------|-----|
| Description code | BANJ | | BAPJ | BANJ | | BAPJ | |
| Types | LC | LD | LCD | XC | XD | XCC | XCD |
| Overall length | 845 mm (33.3 in) | | | | | | |
| Overall width | 580 mm (22.8 in) | | | | | | |
| Overall height | 1,665 mm (65.6 in) | | | 1,790 mm (70.5 in) | | | |
| Dry weight (*1) | 220 kg (485 lbs) | | 223 kg (492 lbs) | | 226 kg (498 lbs) | | |
| Operating weight (including oil) | 228 kg (503 lbs) | | 231 kg (509 lbs) | | 234 kg (516 lbs) | | |

*1: With propeller mounted.

• FRAME

| Model | BF135A•BF150A | | | | | | |
|---------------------|--------------------|----|-----|------------------|----|-----|-----|
| Types | LC | LD | LCD | XC | XD | XCC | XCD |
| Transom height (*1) | 508 mm (20.0 in) | | | 635 mm (25.0 in) | | | |
| Tilting angle | 72° | | | | | | |
| Tilting stage | Stageless | | | | | | |
| Swivel angle | 30° right and left | | | | | | |
| Trim angle | - 4° to 16° | | | | | | |

*2: Transom angle is at 12°.

BF135A•BF150A

• TYPES OF Honda BF135A•BF150A OUTBOARD MOTORS

It may be necessary to refer to this chart for reference purposes when reading this manual.

| Model | BF135A•BF150A | | | | | | |
|-------------------|---------------|------|------|------|------|------|------|
| | LC | LD | LCD | XC | XD | XCC | XCD |
| Types | | | | | | | |
| Shaft length type | L | L | L | XL | XL | XL | XL |
| Remote control | (•) | (•) | (•) | (•) | (•) | (•) | (•) |
| Control panel | (•) | (•) | (•) | (•) | (•) | (•) | (•) |
| Counter rotation | | | • | | | • | • |
| Power trim/tilt | • | • | • | • | • | • | • |

L: Long shaft

XL: Extra-long shaft

(•): Optional part

• ENGINE


| Model | BF135A | BF150A |
|-----------------------------------|--|---|
| Description code | BEARJ | BEANJ |
| Type | 4-stroke, D.O.H.C., 4-cylinder | 4-stroke, D.O.H.C., VTEC, 4-cylinder |
| Displacement | 2,354 cm ³ (143.6 cu-in) | |
| Bore x stroke | 87 x 99 mm (3.4 x 3.9 in) | |
| Rated power (Full throttle range) | 100.7 kW (135 HP) at 5,000 – 6,000 min ⁻¹ (rpm) | 111.9 kW (150 HP) at 5,000 – 6,000 min ⁻¹ (rpm) |
| Maximum torque | 196 N·m (20.0 kgf·m, 145 lbf·ft) | 202 N·m (20.6 kgf·m, 149 lbf·ft) |
| Compression ratio | 9.6 : 1 | |
| Fuel consumption ratio | 350 g/kW·h (257 g/HP·h, 0.575 lb/HP·h) | 320 g/kW·h (235 g/HP·h, 0.526 lb/HP·h) |
| Cooling system | Forced water circulation by impeller pump with thermostat | |
| Ignition system | Full transistorized, battery ignition | |
| Ignition timing | 0° ± 2° at 750 min ⁻¹ (rpm) B.T.D.C. | |
| Spark plug | IZFR6K11 (NGK), SKJ20DR-M11 (DENSO) | |
| Fuel supply system | Programmed fuel injection | |
| Fuel injection system | Electronic control | |
| Fuel injection nozzle | Multi-hole type | |
| Fuel pipe | Rubber tubes | |
| Lubrication system | Pressure lubrication by trochoid pump | |
| Lubrication capacity | 7.35 _r (7.8 US qt, 6.5 Imp qt) [with oil filter replacement: 6.7 _r (7.1 US qt, 5.9 Imp qt)] [without oil filter replacement: 6.5 _r (6.9 US qt, 5.7 Imp qt)] | |
| Starting system | Electric starter | |
| Stopping system | Primary circuit ground | |
| Fuel used | Unleaded gasoline with a pump octane number 86 or higher | |
| Fuel pump | Electric and mechanical plunger type | |
| Exhaust system | Underwater type | |
| Recommended oil | SAE 10W-30 | |

• LOWER UNIT

| | |
|------------------------------|--|
| Clutch | Dog clutch (Forward – Neutral – Reverse) |
| Gear ratio | 0.467 (14/30) |
| Reduction | Spiral bevel |
| Gear case oil capacity | 0.98 _r (1.04 US qt, 0.86 Imp qt) |
| Propeller rotating direction | Clockwise (viewed from rear): LC, LD, XC and XD types Counterclockwise (viewed from rear): LDC, XCC and XCD types |
| Propeller driving system | Spline |


2. DIMENSIONAL DRAWINGS

[]: Extra-long shaft type



BF135A·BF150A

• PROPELLER SHAFT



2. SERVICE INFORMATION

BF135A•BF150A

- | | |
|---------------------------------------|---------------------------|
| 1. THE IMPORTANCE OF PROPER SERVICING | 7. TORQUE VALUES |
| 2. IMPORTANT SAFETY PRECAUTIONS | 8. SPECIAL TOOLS |
| 3. SERVICE RULES | 9. TROUBLESHOOTING |
| 4. SYMBOLS USED IN THIS MANUAL | 10. CABLE/HARNESS ROUTING |
| 5. SERIAL NUMBER LOCATIONS | 11. TUBE ROUTING |
| 6. MAINTENANCE STANDARDS | 12. LUBRICATION |

1. THE IMPORTANCE OF PROPER SERVICING

Proper servicing is essential to the safety of the operator and the reliability of the outboard motor. Any error or oversight made by the technician while servicing can easily result in faulty operation, damage to the outboard motor or injury to the operator.

Some of the most important precautions are given below. However, we cannot warn you of every conceivable hazard that can arise in performing maintenance or repairs. Only you can decide whether or not you should perform a given task.

2. IMPORTANT SAFETY PRECAUTIONS

Make sure you have a clear understanding of all basic shop safety practices and that you are wearing appropriate clothing and using safety equipment. When performing any service task, be especially careful of the following:

- Read all of the instructions before you begin, and make sure you have the tools, the replacement or repair parts, and the skills required to perform the tasks safely and completely.
- Protect your eyes by using proper safety glasses, goggles, or face shields any time you hammer, drill, grind, or work around pressurized air or liquids, and springs or other stored-energy components. If there is any doubt, put on eye protection.
- Use other protective wear when necessary, for example, gloves or safety shoes. Handling hot or sharp parts can cause severe burns or cuts. Before you grab something that looks like it can hurt you, stop and put on gloves.
- Protect yourself and others whenever you have engine-powered equipment up in the air. Any time you lift an outboard motor with a hoist, make sure that the hoist hook is securely attached to the outboard motor.

Make sure the engine is off before you begin any servicing procedures, unless the instruction tells you to do otherwise. This will help eliminate several potential hazards:

- Carbon monoxide poisoning from engine exhaust. Be sure there is adequate ventilation whenever you run the engine.
- Burns from hot parts. Let the engine and exhaust system cool before working in those areas.
- Injury from moving parts. If the instruction tells you to run the engine, be sure your hands, fingers, and clothing are out of the way.

Gasoline vapors and hydrogen gasses from batteries are explosive. To reduce the possibility of a fire or explosion, be careful when working around gasoline or batteries.

- Use only a nonflammable solvent, not gasoline, to clean parts.
- Never drain or store gasoline in an open container.
- Keep all cigarettes, sparks, and flames away from the battery and all fuel-related parts.

⚠ WARNING

Improper servicing can cause an unsafe condition that can lead to serious injury or death.

Follow the procedures and precautions in this shop manual carefully.

⚠ WARNING

Failure to properly follow maintenance instructions and precautions can cause you to be seriously hurt or killed.

Follow the procedures and precautions in this shop manual carefully.

3. SERVICE RULES


1. Use genuine Honda or Honda-recommended parts and lubricants or their equivalents. Parts that do not meet Honda's design specifications may damage the unit.
2. Use the special tools designed for the product.
3. Install new gaskets, O-rings, etc. when reassembling.
4. When torquing bolts or nuts, begin with larger-diameter or inner bolts first and tighten to the specified torque diagonally, unless a particular sequence is specified.
5. Clean parts in cleaning solvent upon disassembly. Lubricate any sliding surfaces before reassembly.
6. After reassembly, check all parts for proper installation and operation.
7. Many screws used in this machine are self-tapping. Be aware that cross-threading or overtightening these screws will strip the threads and ruin the hole.
8. Use only metric tools when servicing this unit. Metric bolts, nuts and screws are not interchangeable with non-metric fasteners. The use of incorrect tools and fasteners will damage the unit.

4. SYMBOLS USED IN THIS MANUAL

As you read this manual, you may find the following symbols with the instructions.

 A special tool is required to perform the procedure.

 Apply grease.


(Molybdenum : Use molybdenum oil solution (mixture of the engine oil and molybdenum grease with the ratio 1 : 1).
disulfide oil)


 Apply oil.

• x • •(• } Indicates the diameter, length, and quantity of metric flange bolts used.


P. 1-1 Indicates the reference page.

5. SERIAL NUMBER LOCATIONS

The engine serial number is stamped on the right side of the cylinder block and the product identification number is located on the right side of the stern bracket. Always specify these numbers when inquiring about the engine or when ordering parts in order to obtain the correct parts for the outboard motor being serviced.



ENGINE SERIAL NUMBER



PRODUCT IDENTIFICATION NUMBER

6. MAINTENANCE STANDARDS

• ENGINE

Unit: mm (in)

| Parts | Item | | Standard | Service limit |
|-------------------------|--|---------------------------------|---|-------------------|
| Engine | Idle speed (in neutral) | | 750 ± 50 min ⁻¹ (rpm) | - |
| | Trolling speed | | 650 ± 50 min ⁻¹ (rpm) | - |
| | Cylinder compression [kPa (kgf/cm ² , psi) at 200 min ⁻¹ (rpm)] | | 1,532 – 1,728 (15.6 – 17.6, 222 – 250) | 930 (9.5, 135) |
| | Compression gap between cylinders [kPa (kgf/cm ² , psi)] | | - | 200 (2.0, 28) |
| Spark plugs | Gap | | 1.0 – 1.1 (0.039 – 0.043) | 1.3 (0.051) |
| Valves | Valve clearance | IN | 0.21 – 0.25 (0.008 – 0.010) | - |
| | | EX | 0.28 – 0.32 (0.011 – 0.013) | - |
| | Overall length | IN | 108.7 – 109.5 (4.28 – 4.31) | - |
| | | EX | 108.3 – 109.1 (4.26 – 4.30) | - |
| | Valve O.D. | IN | 34.85 – 35.15 (1.372 – 1.384) | - |
| | | EX | 29.85 – 30.15 (1.175 – 1.187) | - |
| | Stem O.D. | IN | 5.475 – 5.485 (0.2156 – 0.2159) | 5.445 (0.2144) |
| | | EX | 5.450 – 5.460 (0.2146 – 0.2150) | 5.420 (0.2134) |
| Stem-to-guide clearance | IN | 0.030 – 0.055 (0.0012 – 0.0022) | 0.08 (0.003) | |
| | EX | 0.055 – 0.080 (0.0022 – 0.0031) | 0.11 (0.004) | |
| Valve seats | Seat width | IN/EX | 1.25 – 1.55 (0.049 – 0.061) | 2.0 (0.08) |
| | Seat installation height | IN/EX | 44.0 – 44.6 (1.73 – 1.76) | - |
| Valve guides | Guide I.D. | IN/EX | 5.51 – 5.53 (0.217 – 0.218) | 5.55 (0.219) |
| | Guide extrusion amount | IN | 15.2 – 16.2 (0.60 – 0.64) | - |
| | | EX | 15.5 – 16.5 (0.61 – 0.65) | - |
| Valve springs | Free length | IN | 49.64 (1.954) | - |
| | | EX | 49.64 (1.954) | - |
| Rocker arms | Rocker arm I.D. | IN | 17.019 – 17.035 (0.6700 – 0.6707) | - |
| | | EX | 17.012 – 17.039 (0.6698 – 0.6708) | - |
| | Rocker arm shaft O.D. | IN/EX | 16.983 – 16.994 (0.6686 – 0.6690) | - |
| | Rocker arm-to-rocker arm shaft clearance | IN | 0.025 – 0.052 (0.0010 – 0.0020) | 0.08 (0.003) |
| EX | | 0.018 – 0.056 (0.0007 – 0.0022) | 0.08 (0.003) | |
| Pistons | Skirt O.D. | A | 86.98 – 86.99 (3.4244 – 3.4248) | 86.93 (3.4224) |
| | | B | 86.97 – 86.98 (3.4240 – 3.4244) | 86.92 (3.4220) |
| | Piston-to-cylinder clearance | | 0.02 – 0.04 (0.001 – 0.002) | 0.05 (0.002) |
| | Piston pin bore I.D. | | 21.960 – 21.963 (0.8646 – 0.8647) | - |

BF135A•BF150A

Unit: mm (in)

| Parts | Item | | Standard | Service limit | |
|-----------------|---|---------------------------------|-------------------------------------|-----------------------------------|---|
| Pistons | Ring groove width | Top | 1.23 – 1.24 (0.0484 – 0.0488) | 1.25 (0.0492) | |
| | | Second | 1.24 – 1.25 (0.0488 – 0.0492) | 1.25 (0.0492) | |
| | | Oil | 2.005 – 2.025 (0.0789 – 0.0797) | 2.05 (0.081) | |
| Piston pins | Pin O.D. | | 21.961 – 21.965 (0.8646 – 0.8648) | 21.953 (0.8643) | |
| | Pin-to-pin bore clearance | | -0.005 – +0.002 (-0.0002 – +0.0001) | 0.005 (0.0002) | |
| Piston rings | Ring side clearance | Top | 0.045 – 0.070 (0.0018 – 0.0028) | 0.13 (0.005) | |
| | | Second | 0.040 – 0.065 (0.0016 – 0.0026) | 0.13 (0.005) | |
| | Ring end gap | Top | 0.20 – 0.35 (0.008 – 0.014) | 0.6 (0.02) | |
| | | Second | 0.50 – 0.65 (0.020 – 0.026) | 0.75 (0.030) | |
| | | Oil | 0.20 – 0.70 (0.008 – 0.028) | 0.8 (0.031) | |
| | Ring thickness | Top | 1.170 – 1.185 (0.0461 – 0.0467) | - | |
| Second | | 1.175 – 1.190 (0.0463 – 0.0469) | - | | |
| Cylinder head | Warpage | | - | 0.05 (0.002) Min. | |
| | Camshaft journal I.D. | | 29.000 – 29.024 (1.1417 – 1.1427) | - | |
| | Head height | | 103.95 – 104.05 (4.093 – 4.096) | - | |
| Cylinder block | Cylinder sleeve I.D. | A or I | 87.01 – 87.02 (3.4256 – 3.4260) | 87.07 (3.4279) | |
| | | B or II | 87.00 – 87.01 (3.4252 – 3.4256) | 87.07 (3.4279) | |
| | Gap between upper and lower points – of sleeve I.D. | | - | 0.05 (0.002) | |
| | Warpage | | 0.07 (0.003) Max. | 0.10 (0.004) | |
| Connecting rods | Small end I.D. | | 23.969 – 23.982 (0.9437 – 0.9442) | - | |
| | Small end-to-piston pin clearance | | 0.005 – 0.015 (0.0002 – 0.0006) | 0.02 (0.001) | |
| | Big end axial clearance | | 0.15 – 0.35 (0.006 – 0.014) | 0.4 (0.02) | |
| | Connecting rod bearing oil clearance | | 0.032 – 0.066 (0.0013 – 0.0026) | 0.077 (0.0030) | |
| Crankshaft | Journal O.D. | Main | No. 1, 2, 4, 5 | 54.984 – 54.992 (2.1647 – 2.1650) | - |
| | | | No. 3 | 54.976 – 55.000 (2.1644 – 2.1654) | - |
| | Pin | | 47.976 – 48.000 (1.8888 – 1.8898) | - | |
| | Journal cylindricity | | 0.005 (0.0002) Max. | 0.010 (0.0004) | |
| | Journal roundness | | 0.005 (0.0002) Max. | 0.010 (0.0004) | |
| | Crankshaft runout | | 0.03 (0.001) Max. | 0.04 (0.002) | |
| | Crankshaft axial clearance | | 0.10 – 0.35 (0.004 – 0.014) | 0.45 (0.018) | |
| | Main bearing oil clearance | No. 1, 2, 4, 5 | 0.017 – 0.041 (0.0007 – 0.0016) | 0.05 (0.002) | |
| | | No. 3 | 0.025 – 0.049 (0.0010 – 0.0019) | 0.055 (0.0022) | |
| | Thrust metal side clearance | | 0.10 – 0.35 (0.004 – 0.014) | 0.45 (0.018) | |

Unit: mm (in)

| Parts | Item | Standard | Service limit | |
|-----------------|--|--|---|--------------|
| Camshaft | Camshaft axial clearance | 0.05 – 0.20 (0.002 – 0.008) | 0.4 (0.02) | |
| | Camshaft runout | 0.03 (0.001) Max. | 0.4 (0.02) | |
| | Journal O.D. | No. 1 | 28.955 – 28.970 (1.1400 – 1.1405) | - |
| | | No. 2 – No. 5 | 28.925 – 28.940 (1.1388 – 1.1394) | - |
| | Cam height | IN:PRI/SEC | 32.626 – 32.931 (1.2845 – 1.2965) | - |
| | | IN:MID | 35.369 – 35.654 (1.3925 – 1.4037) | - |
| | | EX | 33.927 – 34.212 (1.3357 – 1.3469) | - |
| | Camshaft oil clearance | No. 1 | 0.030 – 0.069 (0.0012 – 0.0027) | 0.15 (0.006) |
| No. 2 – No. 5 | | 0.060 – 0.099 (0.0024 – 0.0039) | 0.15 (0.006) | |
| Oil pump | Body I.D. | 84.000 – 84.030 (3.3071 – 3.3083) | - | |
| | Inner rotor-to-outer rotor clearance | 0.04 – 0.16 (0.002 – 0.006) | 0.20 (0.008) | |
| | Outer rotor-to-oil pump body clearance | 0.02 – 0.07 (0.001 – 0.003) | 0.12 (0.005) | |
| | Outer rotor height | 9.480 – 9.500 (0.3732 – 0.3740) | - | |
| | Pump body depth | 9.520 – 9.550 (0.3748 – 0.3760) | - | |
| | Outer rotor-to-oil body side clearance | 0.14 – 0.19 (0.006 – 0.007) | 0.20 (0.008) | |
| Vapor separator | Float height | 28.5 – 33.5 (1.12 – 1.32) | - | |
| Fuel pump | Discharge volume [with pump operated for 2 sec. at 12V] | 45 mR (1.5 Us oz, 1.6 Imp oz) or more | - | |
| Fuel line | Fuel pressure [kPa (kgf/cm ² , psi)] | 270 – 320 (2.8 – 3.3, 40 – 47) | - | |
| Alternator | Brush length | 10.5 (0.41) | 8.4 (0.33) | |
| | Brush spring pressure | 3.2 N (0.33 kgf, 0.73 lbf) | - | |
| | Rotor coil resistance | 2.9 Ω | - | |
| | Slip ring O.D. | 14.4 (0.57) | 14.0 (0.55) | |
| | Belt tension Measured at the center of belt between the pulleys with belt tension gauge. | Used belt | 392 – 490 N (40 – 50 kgf, 88 – 100 lbf) | - |
| | | New belt | 490 – 588 N (50 – 60 kgf, 110 – 132 lbf) | - |
| | Belt deflection Measured with 98 N (10 kgf, 22 lbf) of force applied to the center of belt between the pulleys) | Used belt | 10.6 – 11.1 (0.42 – 0.44) | - |
| New belt | | 10.1 – 10.6 (0.40 – 0.42) | - | |
| Starter motor | Brush length | 12.3 (0.48) | 7.0 | |
| | Insulator length (Mica depth) | 0.4 – 0.5 (0.016 – 0.020) | 0.2 (0.008) | |
| | Commutator O.D. | 29.4 (1.16) | 28.8 (1.13) | |
| | Commutator runout | - | 0.1 (0.004) | |

PRI: Primary, MID: Mid, SEC: Secondary

BF135A•BF150A

• FRAME

Unit: mm (in)

| Parts | Item | | Standard | Service limit |
|-----------------|--------------------------------|---|-----------------------------------|-----------------|
| Propeller shaft | Shaft O.D. | At forward bevel gear (LC, LD, XC and XD types) | 24.987 – 25.000 (0.9837 – 0.9843) | 24.966 (0.9829) |
| | | At reverse bevel gear (LCD, XCC and XCD types) | 24.987 – 25.000 (0.9837 – 0.9843) | 24.966 (0.9829) |
| | | At needle bearing | 30.007 – 30.020 (1.1814 – 1.1819) | 29.990 (1.1807) |
| Vertical shaft | Shaft O.D. (at needle bearing) | | 28.556 – 28.575 (1.1242 – 1.1250) | 28.545 (1.1238) |

7. TORQUE VALUES

| Item | Thread dia. (mm) and pitch (length) | Torque value | | | |
|---|--|--------------|-------|--------|----|
| | | N·m | kgf·m | lbf·ft | |
| • ENGINE | | | | | |
| Lower block bolt (*1) | M11 x 1.5 | 29 | 3.0 | 22 | |
| | M8 x 1.25 | 26 | 2.7 | 20 | |
| Crankcase bolt | M6 x 1.0 | 12 | 1.2 | 9 | |
| Oil case bolt | M10 x 1.25 | 34 | 3.5 | 25 | |
| Lower block orifice | M10 x 1.0 | 10 | 1.0 | 7 | |
| Oil jet bolt | M8 x 0.75 (Special bolt) | 16 | 1.6 | 12 | |
| No.1 camshaft holder 10 mm sealing bolt | M10 x 1.0 (Special bolt) | 20 | 2.0 | 14 | |
| Cylinder head bolt (*2) | M11 x 1.5 | 39 | 4.0 | 29 | |
| Cylinder head cover nut | M6 x 1.0 | 12 | 1.2 | 9 | |
| Spark plug | M14 x 1.25 | 18 | 1.8 | 13 | |
| Connecting rod bolt (*3) | M8 x 0.75 (Special bolt) | 20 | 2.0 | 14 | |
| Crankshaft pulley bolt | M16 x 1.5 | 245 | 25.0 | 181 | |
| Balancer chain guide bolt | M6 x 1.0 | 12 | 1.2 | 9 | |
| Balancer driven sprocket bolt | M10 x 1.25 | 44 | 4.5 | 33 | |
| Balancer case assembly bolt (8 x 50 mm/8 x 75 mm) | M8 x 1.25 | 22 | 2.2 | 16 | |
| | (8 x 55 mm) | M8 x 1.25 | 27 | 2.8 | 20 |
| | (10 x 105 mm) | M10 x 1.25 | 44 | 4.5 | 33 |
| Balancer holder bolt | M6 x 1.0 | 12 | 1.2 | 9 | |
| | M8 x 1.25 | 27 | 2.8 | 20 | |
| Chain case special bolt | M6 x 1.0 (Special bolt) | 12 | 1.2 | 9 | |
| Chain case bolt | M6 x 1.0 | 12 | 1.2 | 9 | |
| | M6 x 1.0 (SH bolt) | 12 | 1.2 | 9 | |
| Chain case cover bolt | M6 x 1.0 | 12 | 1.2 | 9 | |
| Cam chain tensioner bolt | M6 x 1.0 | 12 | 1.2 | 9 | |
| Cam chain guide bolt | M6 x 1.0 | 12 | 1.2 | 9 | |
| Cam chain guide B bolt | M8 x 1.25 | 22 | 2.2 | 16 | |
| Cam chain tensioner arm bolt | M8 x 1.25 (Special bolt) | 22 | 2.2 | 16 | |
| Exhaust camshaft sprocket bolt | M10 x 1.25 | 72 | 7.3 | 53 | |
| VTC flange bolt | M12 x 1.25 (Special bolt) | 113 | 11.5 | 83 | |
| Camshaft holder bolt | M8 x 1.25 | 22 | 2.2 | 16 | |
| | M6 x 1.0 | 12 | 1.2 | 9 | |
| Camshaft collar bolt | M14 x 1.0 (Special bolt) | 39 | 4.0 | 29 | |
| CMP pulse plate bolt | M14 x 1.0 (Special bolt) | 39 | 4.0 | 29 | |
| Valve adjusting lock nut (IN side) | M7 x 0.75 | 20 | 2.0 | 14 | |
| Valve adjusting lock nut (EX side) | M7 x 0.75 | 14 | 1.4 | 10 | |
| Oil filter | M20 x 1.5 | 12 | 1.2 | 9 | |
| Oil drain plug bolt | M12 x 1.5 | 23 | 2.3 | 17 | |
| Throttle body bolt | M8 x 1.25 | 22 | 2.2 | 16 | |
| IAC valve bolt | M8 x 1.25 | 22 | 2.2 | 16 | |
| Injector base bolt, nut | M8 x 1.25 | 24 | 2.4 | 17 | |
| Fuel pipe bolt | M8 x 1.25 | 22 | 2.2 | 16 | |
| Pressure regulator nut | M18 x 1.0 | 27 | 2.8 | 20 | |
| IAB control valve bolt | M5 x 0.8 | 5.4 | 0.55 | 4.0 | |

*1: Tighten the lower block bolts to 29 N·m (3.0 kgf·m, 22 lbf·ft) first, then tighten them to additional 56° (Angle method).

*2: Tighten the new cylinder head bolts to 39 N·m (4.0 kgf·m, 29 lbf·ft) (Snag torque), then tighten them to additional 278°.
(Tighten to 90° at first, then to 90°, and to 98° in this order) (Angle method).

At assembly, tighten the lower block bolts to 39 N·m (4.0 kgf·m, 29 lbf·ft) (Snag torque), then tighten them to additional 180°. (Tighten to 90° at first, then to 90° in this order) (Angle method).

*3: Tighten the connecting rod bolts to 20 N·m (2.0 kgf·m, 14 lbf·ft) (Snag torque), then tighten them to additional 90° (Angle method).

• SH bolt: Small head bolt.

BF135A•BF150A

| Item | Thread dia. (mm) and pitch (length) | Torque value | | |
|--|--|--------------|-------|--------|
| | | N·m | kgf·m | lbf·ft |
| • ENGINE | | | | |
| Mounting case bolt | M12 x 1.25 | 64 | 6.5 | 47 |
| | M10 x 1.25 | 44 | 4.5 | 33 |
| | M8 x 1.25 | 26 | 2.7 | 20 |
| Mounting case nut | M10 x 1.25 | 44 | 4.5 | 33 |
| Plug hole coil bolt | M6 x 1.0 | 12 | 1.2 | 9 |
| Flywheel boss bolt | M8 x 1.25 | 32 | 3.3 | 24 |
| Flywheel bolt | M12 x 1.0 | 118 | 12.0 | 87 |
| Alternator bolt | M10 x 1.25 | 44 | 4.5 | 33 |
| nut | M8 x 1.25 | 26 | 2.7 | 20 |
| Alternator pulley lock nut | M14 x 1.5 | 110 | 11.2 | 81 |
| Starter motor bolt | M10 x 1.25 | 44 | 4.5 | 33 |
| Starter motor front bracket screw | M5 screw | 2.5 | 0.25 | 1.8 |
| Starter motor bolt screw | M5 | 5 | 0.5 | 3.6 |
| Starter solenoid switch screw | M6 screw | 6 | 0.6 | 4.3 |
| EOP switch (Low pressure side) | PT 1• 8 | 8 | 0.8 | 5.8 |
| EOP switch (High pressure side) | M10 x 1.25 | 22 | 2.2 | 16 |
| ECT sensor | M10 x 1.25 | 12 | 1.2 | 9 |
| A/F sensor | M18 x 1.5 | 42 | 4.3 | 31 |
| Knock sensor | M12 x 1.25 | 31 | 3.2 | 23 |
| MAP sensor bolt | M5 x 0.8 | 3.4 | 0.35 | 2.5 |
| ECM bolt | M6 x 1.0 | 5 | 0.5 | 3.6 |
| Intake manifold bolt, nut | M8 x 1.25 | 26 | 2.7 | 20 |
| Exhaust manifold bolt | M10 x 1.25 | 39 | 4.0 | 29 |
| Exhaust guide bolt | M8 x 1.25 | 26 | 2.7 | 20 |
| Water separator body screw | M5 screw | 3.4 | 0.35 | 2.5 |
| Fuel strainer body screw | M5 screw | 3.4 | 0.35 | 2.5 |
| Fuel pump (low pressure side) bolt | M6 x 1.0 | 12 | 1.2 | 9 |
| Vapor separator assembly bolt | M8 x 1.25 | 26 | 2.7 | 20 |
| Vapor separator stay bolt | M8 x 1.25 | 26 | 2.7 | 20 |
| Service check bolt | M6 x 1.0 | 12 | 1.2 | 9 |
| Vapor separator cover screw | M5 screw | 3.4 | 0.35 | 2.5 |
| Water jacket cover screw | M5 screw | 3.4 | 0.35 | 2.5 |
| Strainer cover screw | M5 screw | 3.4 | 0.35 | 2.5 |
| Pump cover screw | M5 screw | 3.4 | 0.35 | 2.5 |
| Pump harness assembly screw | M4 screw | 2.1 | 0.21 | 1.5 |
| Float pin screw | — | 2.1 | 0.21 | 1.5 |
| Fuel pump case bolt | M6 x 1.0 | 12 | 1.2 | 9 |
| Plate stay A bolt | M6 x 1.0 | 12 | 1.2 | 9 |
| • GEAR CASE | | | | |
| Propeller shaft holder bolt | M10 x 1.25 | 34 | 3.5 | 25 |
| 18 mm castle nut (*1) | M18 x 1.5 | 1 | 0.1 | 0.7 |
| Gear case bolt | M10 x 1.25 | 34 | 3.5 | 25 |
| Oil level bolt | M8 x 1.25 | 3.4 | 0.35 | 2.5 |
| Oil drain bolt | M8 x 1.25 | 3.4 | 0.35 | 2.5 |
| Water screen screw | M5 x 0.8 | 1 | 0.1 | 0.7 |
| Sensor nipple | M8 x 1.0 | 3 | 0.3 | 2.2 |
| Bearing holder (LCD, XCC and XCD types only) | M100 x 2.0 | 191 | 19.5 | 141 |
| Impeller housing bolt | M8 x 1.25 | 19.7 | 2.0 | 14 |
| 64 mm lock nut | M64 x 1.5 | 123 | 12.5 | 90 |
| Pinion gear nut | M18 x 1.0 | 142 | 14.5 | 105 |
| • EXTENSION CASE/MOUNTING CASE | | | | |
| Extension case bolt | M10 x 1.25 | 39 | 4.0 | 29 |
| Lower rubber mounting bolt | M12 x 1.25 | 83 | 8.5 | 61 |
| Upper rubber mounting bolt | M12 x 1.25 | 83 | 8.5 | 61 |

*1: If the split pin cannot be set by tightening the 18 mm castle nuts to 1 N·m (0.1 kgf·m, 0.7 lbf·ft), tighten the 18 mm castle nut until the split pin can be set. Note that the maximum torque of the 18 mm castle nut is 44 N·m (4.5 kgf·m, 33 lbf·ft).

| Item | Thread dia. (mm) and pitch (length) | Torque value | | |
|--|--|--|--|---|
| | | N·m | kgf·m | lbf·ft |
| • STERN BRACKET 7/8-14 UNF self-locking nut 25 x 2.0 mm self-locking nut 10 mm self-locking nut | 7/8-14 UNF M25 x 2.0 M10 x 1.25 | 34 34 34 | 3.5 3.5 3.5 | 25 25 25 |
| • POWER TRIM/TILT ASSEMBLY Cylinder cap comp. Rod guide comp. Manual valve Socket bolt A/B Power tilt motor assembly bolt Power tilt motor assembly code holder screw Oil tank bolt Oil tank cap | _____ _____ M14 x 1.5 _____ 1/4-20 UNF M4 screw _____ _____ | 162 78 3.5 8.5 5 1.4 5 2.5 | 16.5 8.0 0.35 0.85 0.5 0.14 0.5 0.25 | 119 58 2.5 6.1 3.6 1.0 3.6 1.8 |
| • FRAME/ELECTRICAL Grease fitting Neutral switch nut Starter motor B terminal washer-nut Alternator B terminal washer-nut Alternator fuse box B terminal washer-nut Alternator fuse box bolt Fuse box bracket bolt PGM-FI main relay bolt ECM bracket bolt L./R. engine under cover screw Starter motor bolt | M6 x 1.0 M20 x 1.0 M8 x 1.25 M6 x 1.0 M6 x 1.0 M6 x 1.0 M6 x 1.0 M6 x 1.0 M6 x 1.0 M6 x 1.0 M6 screw M10 x 1.25 | 3 2.5 11 8 8 5 5 5 5 5 4.5 44 | 0.3 0.25 1.1 0.8 0.8 0.5 0.5 0.5 0.5 0.5 0.45 4.5 | 2.2 1.8 8 5.8 5.8 3.6 3.6 3.6 3.6 3.6 3.3 33 |

• Use the standard torque values for the bolts, nuts and screws that are not listed in this table.

STANDARD TORQUE VALUES

| Item | Thread dia. (mm) and pitch (length) | Torque value | | |
|---------------------|--|--------------|-------|--------|
| | | N·m | kgf·m | lbf·ft |
| Screw | 5 mm | 4.2 | 0.42 | 3.0 |
| | 6 mm | 9 | 0.9 | 6.5 |
| Bolt and nut | 5 mm | 5.2 | 0.52 | 3.8 |
| | 6 mm | 10 | 1.0 | 7 |
| | 8 mm | 21.5 | 2.15 | 16 |
| | 10 mm | 34 | 3.5 | 25 |
| | 12 mm | 54 | 5.5 | 40 |
| Flange bolt and nut | 6 mm (SH bolt) | 9 | 0.9 | 6.5 |
| | 6 mm (CT bolt) | 12 | 1.2 | 9 |
| | 6 mm | 12 | 1.2 | 9 |
| | 8 mm | 26 | 2.7 | 20 |
| | 10 mm | 39 | 4.0 | 29 |

- CT bolt: Self-tapping bolt
- SH bolt: Small head bolt


8. SPECIAL TOOLS

• Special tools applicable to the parts except gear case

| | Tool name | Tool number | Application |
|----|-------------------------------------|---------------|--|
| 1 | Ring gear holder | 070PB-ZY60100 | Flywheel boss, flywheel removal/installation |
| 2 | SCS service check connector | 070PZ-ZY30100 | ECU troubleshooting, idling adjustment |
| 3 | Test harness | 070PZ-ZY60100 | ECU troubleshooting |
| 4 | Float level gauge | 07401-0010000 | Vapor separator float level inspection |
| 5 | Oil pressure gauge attachment | 07406-0030000 | Oil pressure test |
| 6 | Fuel pressure gauge set | 07406-0040003 | Fuel pressure inspection |
| 7 | Oil pressure gauge set | 07506-3000001 | Oil pressure test |
| 8 | Valve guide driver, 5.5 mm | 07742-0010100 | Valve guide removal/installation |
| 9 | Pin driver, 6.0 mm | 07744-0010500 | Balancer shaft hold |
| 10 | Attachment, 32 x 35 mm | 07746-0010100 | 22 x 35 x 7 mm water seal installation, Lower mount center hosing removal |
| 11 | Attachment, 37 x 40 mm | 07746-0010200 | Alternator front bearing installation |
| 12 | Attachment, 52 x 55 mm | 07746-0010400 | Alternator rear bearing, Chain case oil seal installation |
| 13 | Attachment, 24 x 26 mm | 07746-0010700 | Alternator front bearing removal, 14 x 26 x 8 mm water seal installation |
| 14 | Driver, 22 mm I.D. | 07746-0020100 | Alternator rear bearing installation |
| 15 | Attachment, 15 mm I.D. | 07746-0020200 | Alternator rear bearing installation |
| 16 | Driver, 40 mm I.D. | 07746-0030100 | Lower mount center housing installation |
| 17 | Pilot, 12 mm | 07746-0040100 | 14 x 26 x 8 mm water seal installation |
| 18 | Pilot, 15 mm | 07746-0040300 | Alternator front bearing removal/installation |
| 19 | Pilot, 20 mm | 07746-0040500 | Mounting case needle bearing installation |
| 20 | Pilot, 30 mm | 07746-0040700 | Lower mount center housing removal |
| 21 | Pilot, 22 mm | 07746-0041000 | 22 x 35 x 7 mm water seal installation |
| 22 | Driver | 07749-0010000 | Driver for 10 through 13, 17 through 21, 33 through 35 and 48 |
| 23 | Valve spring compressor | 07757-0010000 | ┌ Valve keeper removal/installation |
| 24 | Valve spring compressor attachment | 07757-PJ10100 | |
| 25 | Valve seat cutter, 45° 35 mm | 07780-0010400 | Valve seat reconditioning (IN) |
| 26 | Valve seat cutter, 45° 33 mm | 07780-0010800 | Valve seat reconditioning (EX) |
| 27 | Valve seat cutter, 32° 38.5 mm | 07780-0012400 | Valve seat reconditioning (IN) |
| 28 | Valve seat cutter, 32° 33 mm | 07780-0012900 | Valve seat reconditioning (EX) |
| 29 | Valve seat cutter, 60° 30 mm | 07780-0014000 | Valve seat reconditioning (EX) |
| 30 | Valve seat cutter, 60° 37.5 mm | 07780-0014100 | Valve seat reconditioning (IN) |
| 31 | Cutter holder, 5.5 mm | 07781-0010101 | Valve seat reconditioning (IN/EX) |
| 32 | Sensor socket wrench, 22 x 150L | 07906-PD10000 | A/F sensor removal/installation |
| 33 | Attachment, 28 x 30 mm | 07946-1870100 | Mounting case needle bearing installation |
| 34 | Oil seal driver attachment, 72 mm | 07947-6340201 | Oil pump body oil seal installation |
| 35 | Oil seal driver | 07947-SB00100 | Oil pump cover oil seal installation |
| 36 | Oil filter wrench | 07HAA-PJ70101 | Oil filter removal/installation |
| 37 | Valve guide reamer, 5.525 mm | 07HAH-PJ70100 | Valve guide reaming |
| 38 | Socket wrench, 19 mm | 07JAA-001020A | ┌ Crankshaft pulley bolt removal/installation |
| 39 | Handle | 07JAB-001020B | |
| 40 | Pulley holder attachment, HEX 50 mm | 07JAB-0010400 | |
| 41 | Belt tension gauge | 07JGG-0010101 | Alternator belt tension inspection |
| 42 | Air supply | 07LAJ-PR30102 | VTEC system, VTEC valve inspection |
| 43 | Stem seal driver | 07PAD-0010000 | Valve stem seal A/B installation |

BF135A•BF150A

| Tool name | | Tool number | Application |
|-----------|--------------------------------|---------------|--|
| 44 | Pin wrench, 6 mm | 07SPA-ZW10100 | Piston rod comp. removal/installation Rod guide comp. removal/installation Power trim/tilt assembly blow pressure inspection |
| 45 | Pin wrench, 4 mm | 07SPA-ZW10200 | |
| 46 | Oil pressure gauge joint A | 07SPJ-ZW10100 | |
| 47 | Oil pressure gauge joint B | 07SPJ-ZW10200 | Crankshaft oil seal installation VTEC system, VTEC valve inspection |
| 48 | Oil seal driver attachment, 96 | 07ZAD-PNA0100 | |
| 49 | VTEC air adapter | 07ZAJ-PNA0101 | |
| 50 | VTEC air stopper | 07ZAJ-PNA0200 | |
| 51 | Air joint adapter | 07ZAJ-PNA0300 | |



• Special tools applicable to all types of gear case

| | Tool name | Tool number | Application |
|----|--|---------------|---|
| 1 | Outer driver attachment, 30 x 37 | 070PD-ZY60200 | 30 x 37 x 26 mm needle bearing installation |
| 2 | Gauge adapter, 110 mm | 070PJ-ZY30100 | Vertical shaft pinion gear shim adjustment |
| 3 | Attachment, 32 x 35 mm | 07746-0010100 | 23 x 36 x 6 mm water seal installation |
| 4 | Attachment, 62 x 68 mm | 07746-0010500 | 30 x 37 x 26 mm needle bearing installation |
| 5 | Pilot, 35 mm | 07746-0040800 | Needle bearing (outer race) removal |
| 6 | Driver | 07749-0010000 | Driver for 3 and 12 |
| 7 | Lock nut wrench, 30/64 mm | 07916-MB00002 | Vertical shaft lock nut removal/installation |
| 8 | Remover weight | 07741-0010201 | 30 x 37 x 26 mm needle bearing removal |
| 9 | Remover handle | 07936-3710100 | |
| 10 | Bearing remover, 30 mm | 07936-8890300 | |
| 11 | Oil seal driver | 07947-SB00100 | 30 x 45 x 7 mm water seal installation |
| 12 | Oil seal driver attachment, 21 mm | 07947-ZV00100 | 12 x 21 x 6 mm oil seal installation |
| 13 | Oil seal driver attachment, 27.5 x 44 mm | 07948-9540000 | Needle bearing installation |
| 14 | Driver handle, 15 x 280 mm | 07949-3710001 | Needle bearing (outer race) removal |
| 15 | Driver shaft, B | 07964-MB00200 | 30 x 62 x 40 mm taper roller bearing installation |
| 16 | Attachment, 78 x 90 mm | 07GAD-SD40101 | Needle bearing installation |
| 17 | Vertical shaft holder | 07SPB-ZW10200 | Vertical shaft pinion gear nut removal/installation |
| 18 | Puller jaws | 07SPC-ZW0010Z | Forward bevel gear backlash inspection |
| 19 | Puller bolt | 07SPC-ZW0011Z | |
| 20 | Backlash indicator tool | 07SPJ-ZW0030Z | |
| 21 | Backlash indicator attachment | 07SPK-ZW10100 | Needle bearing installation |
| 22 | Shaft installer, 15 x 370 mm | 07VMF-KZ30200 | |
| 23 | Bearing driver attachment, 37 mm | 07ZMD-MBW0200 | |

• Special tools applicable to LC, LD, XC and XD types of gear case

| | Tool name | Tool number | Application |
|----|------------------------------------|--------------------------------------|---|
| 24 | Driver handle, 480 mm | 070GD-0010100 | 50 x 90 x 28 mm taper bearing (outer race) installation |
| 25 | Taper bearing installer attachment | 070PF-ZY60100 | |
| 26 | Remover weight | 07741-0010201 | 50 x 90 x 28 mm taper bearing (outer race) removal |
| 27 | Remover handle | 07936-3710100 | |
| 28 | Bearing race puller | 070PC-ZY3A100 | Reverse bevel gear installation |
| 29 | Attachment, 62 x 68 mm | 07746-0010500 | |
| 30 | Pilot, 35 mm | 07746-0040800 | |
| 31 | Attachment, 27.2 | 07747-0010300 | Reverse bevel gear removal/installation |
| 32 | Driver | 07749-0010000 | Driver for 29, 30, 31 and 33 |
| 33 | Oil seal driver, 52 x 55 mm | 07NAD-P200100 or 07NAD-P20A100 | 50 x 90 x 28 mm taper bearing (inner race) installation |


• Special tools applicable to LCD, XCC and XCD types of gear case

| | Tool name | Tool number | Application |
|----|---------------------------------|---------------|--|
| 34 | Remover weight | 07741-0010201 | Reverse bevel gear, 50 x 90 x 28 mm radial ball bearing removal [Puller jaws of the bearing race puller (07LPC-ZV30100) are removed and replaced with the puller jaws of part number 07WPC-ZW50100.] |
| 35 | Remover handle | 07936-3710100 | |
| 36 | Bearing race puller | 070PC-ZY3A100 | |
| 37 | Puller jaws, 25 mm | 07WPC-ZW50100 | |
| 38 | Taper bearing driver attachment | 070PD-ZY60100 | 50 x 90 x 28 mm taper bearing (outer race) removal |
| 39 | Attachment, 62 x 68 mm | 07746-0010500 | 50 x 90 x 28 mm taper bearing (inner race/outer race) installation |

BF135A·BF150A

• Special tools applicable to LCD, XCC and XCD types of gear case

| Tool name | | Tool number | Application |
|-----------|-------------------------------|--------------------------------------|--|
| 40 | Pilot, 35 mm | 07746-0040800 | Forward bevel gear removal |
| 41 | Attachment, 27.2 | 07747-0010300 | Forward bevel gear removal |
| 42 | Driver | 07749-0010000 | Driver for 38, 39, 40 and 41 |
| 43 | Oil seal driver, 65 mm | 07JAD-PL90100 or 07JAD-PL9A100 | 50 x 90 x 20 mm radial ball bearing installation |
| 44 | Backlash indicator tool | 07SPJ-ZW0030Z | Reverse bevel gear backlash inspection |
| 45 | Backlash indicator attachment | 07SPK-ZW10100 | |
| 46 | Pin spanner wrench, 110 mm | 07WAA-S1G0100 | Bearing holder assembly removal/installation |




9. TROUBLESHOOTING

a. ENGINE

• HARD STARTING

- Use a known-good battery for troubleshooting.





BF135A•BF150A

• CYLINDER COMPRESSION TEST

- 1) Move the remote control lever to the “N” (Neutral) position.
- 2) Remove the clip of the emergency stop switch.
- 3) Remove the engine cover and disconnect the fuel injector connectors of each cylinder.
- 4) Disconnect the ignition coil connector of each cylinder and remove the spark plugs.
- 5) Disconnect the throttle control cable from the throttle arm.
- 6) Install a compression gauge in the No. 1 plug hole.
- 7) Set the throttle in the full throttle position by pulling the throttle arm against the full throttle stopper with hand as shown.
- 8) Set the ignition switch in the “START” position and turn the starter motor. Measure the cylinder compression.
- 9) Check the compression on all cylinders.


| | |
|----------------------|---|
| Cylinder compression | 1,352 - 1,728 kPa (15.6 - 17.6 kgf/cm ² , 222 - 250 psi) at 200 min ⁻¹ (rpm) |
|----------------------|---|




• ENGINE DOES NOT RUN SMOOTHLY


- Perform “g. ALERT SYSTEM” (P. 2-32) troubleshooting when the warning buzzer sounds.


Perform the following troubleshooting when the warning buzzer does not sound but the engine does not run smoothly.



BF135A•BF150A









b. IGNITION (POWER) SYSTEM

• ENGINE DOES NOT START





• FUSE LOAD CHART



• FUSE BOX CONNECTION TABLE


| Fuse No. | Fuse capacity | Connect to |
|----------|---------------|---|
| 1 | 30A | A/F sensor heater |
| 2 | 10A | High pressure side fuel pump |
| 3 | 10A | Power trim/tilt relay, Alternator (detection terminal), Ignition switch, PGM-FI main relay, Warning buzzer, Indicator light (oil, overheat), Meters |
| 4 | 15A | ECM, Fuel injector, CMP sensor, CKP sensor |
| 5 | 10A | Alternator (IG terminal), A/F relay, Indicator light (MIL, ACG), IAB control valve, data link connector |
| 6 | 15A | Ignition coil |
| 7 | 30A | PGM-FI main relay |




c. STARTING SYSTEM

• ENGINE DOES NOT START

- Before starting troubleshooting, check each wire for connection and correct as necessary.







d. IGNITION SYSTEM


• ENGINE IS HARD TO START

* Before troubleshooting, turn the ignition switch ON and check whether the MIL comes ON for 2 seconds and the warning buzzer sounds twice intermittently.

If the MIL does not come ON or the warning buzzer does not sound, perform power system troubleshooting (P. 2-20).









e. FUEL SYSTEM

• ENGINE IS HARD TO START


- When the gasoline is flowing out of the vapor separator, check the vapor separator (P. 5-112 thru. 5-120).






f. CHARGING SYSTEM

• BATTERY UNDER CHARGED



• ALTERNATOR INDICATOR LINE INSPECTION



g. ALERT SYSTEM

• OIL ALERT SYSTEM

When the oil pressure switch (low pressure side) detects low oil pressure, the ECM receives the signal from the oil pressure switch and decreases the engine speed gradually to 1,800 min⁻¹ (rpm). The warning buzzer sounds and the oil indicator light goes OFF this time. When the problem is removed, the engine speed increases gradually and the engine is restored to the normal running.

• OVERHEAT ALERT SYSTEM

When the ECM detects overheat by receiving the signal from the thermo sensor, it decreases the engine speed gradually to 1,800 min⁻¹ (rpm). The warning buzzer sounds and the overheat indicator light comes ON. When the problem is not removed within 20 seconds, the ECM decreases the engine speed further until it stops. When the problem is removed during this control, the ECM increases the engine speed gradually until the engine is restored to the normal running.

• ALTERNATOR WARNING SYSTEM

The IC regulator is equipped in the alternator to detect the disconnected sensor terminal, disconnected output terminal, overcharge and undercharge when generation stops. When a problem is detected, the IC regulator turns the alternator indicator light ON and the ECM sounds the warning buzzer (intermittent prolonged sound) by receiving the signal from the IC regulator.

• FULL WATER (IN WATER SEPARATOR) WARNING SYSTEM

When the water level in the water separator is above the specified level, the water level sensor detects the condition and transmits the signal to the ECM to sound the warning buzzer.

• MIL WARNING SYSTEM

The MIL indicator light comes ON and the buzzer sounds (intermittent prolonged sound) when the ECM detects a problem by its diagnostic function.

• WARNING SYSTEM

| Condition | Indicator light | | Warning indicator light | | Warning buzzer |
|---|-----------------------------|--------------------------------|---------------------------|---------------|------------------------------|
| | Oil indicator light (Green) | Overheat indicator light (Red) | ACG indicator light (Red) | MIL (Red) | |
| Ignition switch ON (Initial check) | ON for 2 sec. | ON for 2 sec. | ON | ON for 2 sec. | Sounds twice |
| 2 sec. after turning ignition switch ON | OFF | OFF | ON | OFF | Stop |
| Normal operation | ON | OFF | OFF | OFF | Stop |
| Engine oil pressure dropped | OFF | OFF | OFF | OFF | Continuous sound |
| Overheat | ON | ON | OFF | OFF | Continuous sound |
| MIL faulty | ON*1 | OFF*2 | OFF | ON | Intermittent prolonged sound |
| Alternator faulty | ON | OFF | ON | OFF | Intermittent prolonged sound |
| Water separator full | ON | OFF | OFF | OFF | Intermittent short sound |

When two or more problems occur simultaneously, warning for each problem is indicated simultaneously.

When a problem occurred simultaneously with the malfunction of the MIL:

*1: The oil indicator light blinks when a problem with the high pressure oil pressure switch is detected.


*2: The overheat indicator light blinks when a problem with the overheat sensor is detected.


The warning buzzer of the prolonged sound takes precedence over the short sound.

Example: When the problems with the alternator and full water separator are detected simultaneously, the warning buzzer is the intermittent prolonged sound.

Example: When the overheat and a problem with the alternator are detected simultaneously, the warning buzzer is the continuous sound.

• WARNING BUZZER SOUNDS CONTINUOUSLY







Download the full PDF manual instantly.

Our customer service e-mail:

aservicemanualpdf@yahoo.com