

# Workshop Manual VW Marine Boat Engine

Engine code	<b>BKS</b>				
<b><i>Booklet</i> 6-Cyl. Diesel Engine</b>					

**Edition 12.06**

<b>Safety Precautions and Technical Data</b> .....	<b>00-1</b>
- Safety precautions .....	00-1
- Technical Data .....	00-5
- Engine data .....	00-6
<b>Self-diagnosis</b> .....	<b>01-1</b>
- Properties of the self-diagnosis .....	01-1
- Technical data for the self diagnosis .....	01-2
- Connecting the fault reader .....	01-4
<b>Fault memory</b> .....	<b>01-9</b>
- Interrogate fault memory .....	01-9
- Erasing the fault memory .....	01-11
<b>Fault table: P0 codes</b> .....	<b>01-13</b>
<b>Fault table: SAE P1 codes</b> .....	<b>01-27</b>
<b>Control element diagnosis</b> .....	<b>01-42</b>
- Performing a control element diagnosis .....	01-42
<b>Measurement blocks</b> .....	<b>01-45</b>
- Safety measures .....	01-45
- Read measurement block .....	01-45
- Evaluation of measurement blocks at full load .....	01-64
<b>Removing and installing engine</b> .....	<b>10-1</b>
- Removing engine .....	10-3
- Mount the engine on the engine and gearbox support -VAS 6095- .....	10-11
- Notes on installation .....	10-13
- Tightening torques .....	10-19
- Unit mounting/engine mount .....	10-20
- Mounting the gearbox bell housing (Z-drive Mercruiser) to the engine .....	10-21
- Mounting the gearbox bell housing (Reverse gear) to the engine .....	10-21
<b>Overhaul work - Belt pulley end</b> .....	<b>13-1</b>
- V-ribbed belt drive for alternator, coolant pump, power steering pump and seawater pump .....	13-1

- V-ribbed belt drive -Assembly- .....	13-2
- Removing and installing V-ribbed belt .....	13-6
- Removing and installing the V-ribbed belt tensioner .....	13-10
- Removing and installing the vibration damper .....	13-11
- Replacing the crankshaft sealing ring-on the pulley end- .....	13-13
- Removing and installing the front sealing flange .....	13-17
<b>Overhaul work - timing chain end .....</b>	<b>13-22</b>
- Driving plate - Component overview .....	13-22
- Removing and installing the dual-mass flywheel .....	13-24
- Replacing the crankshaft sealing ring -timing chain end- .....	13-26
- Timing chain covers -Assembly- .....	13-30
- Removing and installing the covers for the timing chains .....	13-33
- Balance shaft -Assembly- .....	13-41
- Balance shaft -Assembly- .....	13-43
- Removing and installing the drive chain for the timing gear .....	13-47
- Chain for oil pump and balance shaft -Assembly- .....	13-51
- Removing and installing the chain for oil pump and balance shaft .....	13-53
- Balance shaft -Assembly- .....	13-60
- Removing and installing the balance shaft .....	13-62
<b>Removing and installing the crankshaft .....</b>	<b>13-68</b>
- Crankshaft - Assembly .....	13-69
- Crankshaft dimensions .....	13-75
- Measuring the axial clearance .....	13-76
- Measuring the radial clearance .....	13-78
<b>Piston and connecting rod .....</b>	<b>13-80</b>
- Piston and connecting rod - Assembly .....	13-81
- Checking piston protrusion at TDC .....	13-91
- Piston and cylinder dimensions .....	13-93
- Measuring connecting rod radial clearance .....	13-93

<b>Cylinder head</b> .....	<b>15-1</b>
- Cylinder head - Assembly .....	15-2
- Cylinder head cover - Assembly .....	15-8
- Removing and installing the cylinder head cover .....	15-15
- Removing and installing the cylinder head .....	15-25
- Checking compression pressure .....	15-37
<b>Valve train -Assembly</b> .....	<b>15-40</b>
- Replacing the camshaft sealing ring .....	15-48
- Removing and installing the camshafts .....	15-52
- Replacing valve stem seals .....	15-64
- Checking hydraulic compensating elements .....	15-71
- Valve dimensions .....	15-73
- Checking the valve guides .....	15-74
- Camshaft timing chain, left -Assembly- .....	15-77
- Camshaft timing chain, right -Assembly- .....	15-79
- Removing and installing the camshaft timing chains .....	15-81
- Removing the camshaft timing chains from the camshafts .....	15-98
<b>Engine oil</b> .....	<b>17-1</b>
- Draining the engine oil .....	17-4
- Lubrication system components .....	17-6
- Oil pump, bottom part of the oil sump - Assembly .....	17-7
- Removing and installing the bottom part of the oil sump .....	17-11
- Removing and installing the oil pump. ....	17-17
- Top part of the oil sump - Assembly .....	17-24
- Removing and installing the top part of the oil sump .....	17-27
- Oil cooler, pressure control valve and oil filter housing .....	17-32
- Oil cooler, pressure control valve and oil filter housing - Assembly .....	17-33
- Removing and installing the oil cooler .....	17-38
- Removing and installing the oil filter housing .....	17-39

- Removing and installing the cyclone separator with pressure control valve for crankcase venting . . . . .	17-42
- Removing and installing the mounting plate for oil cooler, cyclone separator with pressure control valve for crankcase venting . . . . .	17-44
- Removing and installing the oil pressure switch -F1- . . . . .	17-46
- Oil pressure check . . . . .	17-47

**Cooling system . . . . . 19-1**

- Cooling system components . . . . .	19-1
- Checking the cooling system for leaks . . . . .	19-3
- Cooling system components . . . . .	19-6
- Dismantling and assembling the main heat exchanger . . . . .	19-11
- Components of the power steering/gearbox oil cooler . . . . .	19-13
- Intercooler components . . . . .	19-15
- Dismantling and assembling the seawater filter . . . . .	19-19
- Connection diagram for coolant hoses . . . . .	19-21
- Draining and filling the coolant . . . . .	19-23
- Coolant pump and thermostat - Assembly . . . . .	19-29
- Removing and installing the coolant pump . . . . .	19-30
- Removing and installing the thermostat . . . . .	19-33
- Removing and installing the coolant temperature sender -G62- . . . . .	19-35
- Seawater pump with attached parts - Assembly . . . . .	19-36
- Removing and installing the seawater pump . . . . .	19-38
- Dismantling and assembling the seawater pump . . . . .	19-41

**Removing and installing fuel system components . . . . . 20-1**

- Safety precautions when working on fuel supply system . . . . .	20-2
- Rules for cleanliness . . . . .	20-4
- Fine-mesh fuel filter - Assembly . . . . .	20-5
- Check the fuel system for leaks . . . . .	20-7
- Circulation filter - Assembly . . . . .	20-8
- Throttle controls - Assembly . . . . .	20-10
- Checking the accelerator pedal position sender . . . . .	20-12

- Adjusting the accelerator pedal position sender .....	20-17
<b>Charge air system with turbocharger .....</b>	<b>21-1</b>
- Removing and installing turbocharger with attached parts .....	21-1
- Assembly - Turbocharger .....	21-3
- Air cooling for turbocharger 1 control unit (J724) .....	21-7
- Rules for cleanliness .....	21-8
<b>Checking the charge air system .....</b>	<b>21-9</b>
- Checking the turbocharger .....	21-9
- Checking the turbocharger 1 control unit .....	21-11
<b>Servicing the diesel direct injection system .....</b>	<b>23-1</b>
- Rules of cleanliness and instructions for working on the fuel system .....	23-2
- Overview of installation points .....	23-4
- Schematic overview of fuel system .....	23-10
- Fuel system - Assembly .....	23-14
- Intake manifold - Assembly .....	23-21
- Removing and installing the injection units (piezo injectors) .....	23-24
- Removing and fitting the fuel pressure regulating valve .....	23-32
- Removing and installing the fuel pressure sender .....	23-36
- Toothed belt for high pressure pump - Assembly .....	23-39
- Removing and installing the toothed belt for the high-pressure pump .....	23-43
- High-pressure pump -Assembly- .....	23-51
- Removing and fitting the high-pressure pump .....	23-55
- Air filter - Assembly .....	23-60
- Adjusting the idling speed .....	23-61
<b>Checking components and functions .....</b>	<b>23-64</b>
- Checking the power supply for the diesel direct injection system .....	23-64
- Checking the engine speed sender .....	23-70
- Checking the coolant temperature sender .....	23-74
- Checking the fuel temperature sender .....	23-78
- Checking the intake air temperature sender .....	23-82

- Checking the charge pressure sender .....	23-86
- Checking the exhaust gas temperature sender 1 .....	23-90
- Checking the Hall sender .....	23-95
- Checking the fuel pressure sender .....	23-99
- Checking the fuel pressure regulating valve .....	23-102
- Checking the injectors .....	23-107
- Reading out the stored adjustment values of the injectors .....	23-110
- Carrying out the balancing of the injection quantity adjustment value. ....	23-112
<b>Engine control unit .....</b>	<b>23-117</b>
- Replacing the engine control unit .....	23-117
- Checking the terminating resistor for the data bus .....	23-119
<b>Exhaust system components .....</b>	<b>26-1</b>
- Exhaust manifold - Assembly .....	26-2
- Exhaust pipe -Assembly- .....	26-4
<b>Starter .....</b>	<b>27-1</b>
- Removing and installing the starter .....	27-1
<b>Three-phase alternator .....</b>	<b>27-4</b>
- General information .....	27-4
- Removing and installing the three-phase alternator .....	27-6
- Removing and installing the voltage regulator; Manufacturer: Bosch .....	27-17
- Removing and installing the voltage regulator; Manufacturer: Valeo .....	27-19
- Tightening torques: Three-phase alternator .....	27-22
- Three phase alternator - Assembly .....	27-23
- Removing and installing the three-phase alternator mounting .....	27-26
- Removing and installing the idler pulleys in three-phase alternator mounting .....	27-28
- Ribbed V-belt drive - Assembly .....	27-30
- Checking the V-ribbed belt .....	27-31
- Removing and installing V-ribbed belt .....	27-32
<b>Hydraulic system components .....</b>	<b>48-1</b>
- Function overview: Hydraulic pump, oil cooler, hydraulic lines, reservoir tank .....	48-2

- Assembly: Hydraulic pump, hydraulic lines, reservoir tank .....	48-4
- Checking the delivery pressure on the hydraulic pump .....	48-7
<b>Instrument panel .....</b>	<b>90-1</b>
- General information .....	90-1
- Overview of customised instrumentation operating unit .....	90-3
- Overview of the operating unit with customised instrumentation .....	90-4
- Overview of the contact configuration of the customised instrumentation multi-pin connectors with customised instrumentation .....	90-7
- Connection of customised instrumentation to engine .....	90-13
- Changing a fuse on the customised instrumentation .....	90-14
- Overview of the standard instrumentation .....	90-15
- Connection of the standard instrumentation to the engine .....	90-16
- Overview of the pin configuration on the terminal strip -A- of the standard instrumentation .....	90-16
- Overview of the multiway connectors on the standard instrumentation .....	90-17
- Connection variants for the standard instrumentation .....	90-17
- DIP switches on the standard instrumentation .....	90-19
<b>Main electrical panel .....</b>	<b>97-1</b>
- Removing and installing the main electrical panel .....	97-1
- Installing and removing the component board of the main electrical panel .....	97-7
- Pin assignments on the main electrical panel .....	97-9
- Removing and installing the engine control unit .....	97-12
- Diagnostics connection for the system tester .....	97-16
- Wiring harness versions .....	97-18
<b>Wiring harness and connector repair .....</b>	<b>97-19</b>



# **Safety Precautions and Technical Data**

## **Safety precautions**

### **Introduction**

This Workshop Manual contains technical data, descriptions and repair instructions for the 6-cylinder Volkswagen Marine TDI boat engine. The individual repair groups of the Volkswagen Marine boat engine are listed in the table of contents.

### **General information**

Spare parts for electrical systems and fuel systems are subject to legal provisions. Genuine Volkswagen Marine parts comply with these provisions. Injuries and damage caused by the use of non-genuine spare parts are excluded from the warranty.

The Volkswagen Marine boat engine is certified in accordance with BSO 2 under the certificate number:

M 103 305 15.

## Important

**Read the safety precautions carefully before reading the repair instructions. The hazards and safety measures that should always be observed when operating and performing maintenance on the engine are listed below:**

- *Stop the engine by switching off the power supply to the engine using the stop switch on the main electrical panel.*
- *Always conduct maintenance work with the engine switched off. However, certain adjustment tasks must be carried out with the engine running. When the engine is running, ensure that loose clothing, long hair or tools cannot get caught in rotating parts and cause serious injuries.*
- *During maintenance work or test drives, be sure to wear appropriate shoes (deck shoes) and work clothing.*
- *Stop the engine and close the seawater valve when working on the cooling system.*

- *Open the sealing cap of the cooling system extremely carefully when the engine is hot (danger of scalding) and do not remove the cap until the pressure is completely released.*
- *Connect and disconnect the cables of the glow plug and fuel injection system - including measurement device cables - only when the ignition is switched off.*
- *If the engine is to be run at starting speed without actually starting, e.g. during a compression test, disconnect the plug connector for the injection pump.*
- *Only use motor oils approved by Volkswagen Marine (⇒ Operating Manual for Volkswagen Marine Boat Engine).*
- *Only start the engine in a well-ventilated area. When operating the engine in an enclosed area, make sure that the exhaust gases are routed out of the working area by means of a suitable ventilation system.*
- *Exercise extreme caution in case of leaks in the fuel system. Wear protective goggles when testing the fuel injectors. Jets of fuel at high fuel injection pressures may cause severe injuries.*

- *Incorrect connection of the battery can lead to sparks, which in turn can cause an explosion. Avoid open flames and welding work near the battery.*
- *Hydrogen gas escapes during battery charging. Hydrogen gas forms highly explosive oxyhydrogen gas when mixed with oxygen. Therefore, wear protective goggles and appropriate protective clothing. Since the mixture is heavier than air, it can collect in the bilge. Use only onboard chargers and, if possible, gel batteries.*

### **Torques**


- *To ensure that the correct tightening torques are applied, tighten all screw connections with a torque spanner. All torques listed in this Workshop Manual refer to cleaned threads, screw/bolt heads and contact surfaces.*
- *When tightening components, first apply the specified torque with a torque wrench, then tighten further by turning through the specified angle.*

## Technical Data

### Engine number

- ◀ The engine number ("engine code letters" and "serial number") is located on the front left hand side underneath the toothed belt of the injection pump -Arrow-.

In addition, an adhesive label with "engine code letters" and "serial number" is located on the toothed belt guard.



## Engine data

Code letters	BSP
Manufactured	03.06 ►
Exhaust values as per	BSO 2
Displacement litres	2.967
Output kW at rpm	165/4000
Torque Nm at rpm	450/2000
Bore Ø mm	83.0
Stroke mm	91.4
Compression ratio	17.5
CN at least	51
Firing order	3-6-1-4-2-5
Turbocharging	yes
Self-diagnosis	yes
Intercooling	yes

<b>Code letters</b>	<b>BSP</b>
Weight (dry, with auxiliary equipment, cooling system and coupling flange) kg	330
Certificate No. as per BSO 2	M 103 305 15

# Self-diagnosis

## Properties of the self-diagnosis

The control unit for the diesel direct injection system is equipped with a fault memory.

If any faults occur in the sensors or components monitored, these are stored in the fault memory together with details on the type of fault.

Sporadically occurring faults are also printed out with the supplement "sporadically occurring fault". On the display, these faults are indicated by the additional characters "/SP". The cause of sporadic faults can be, for example, a loose connection or a brief break in the line. A sporadic fault will be deleted from the fault memory if 50 warm-up cycles are carried out without this fault.

If faults are detected, which affect the handling, the word "Service" is displayed on the multi-function display.

Previously stored faults can be read out with the ScanDi Tool ⇒ Page 01-9.

The fault memory must be erased after the fault(s) has (have) been resolved ⇒ Page 01-11.



**Note:**

*General information on self-diagnosis can be found in the ScanDi Tool operating manual.*

**Technical data for the self diagnosis****Equipment**

◆ Fault memory: Permanent and volatile memory<sup>1)</sup>

<sup>1)</sup> Erased after the 50th warm-up cycle, if the fault has not recurred.

**Query control unit version**

The control unit version is shown when connecting the ScanDi Tool and selecting the control unit for the engine electronics ⇒ Page 01-4.

## Selectable functions when using the tester ScanDi Tool under address word 01, engine electronics

### **Note:**

Please consult the following table to see the conditions for selecting the desired functions.

<b>Function</b>		<b>Condition</b>		
<b>Functions on ScanDi Tool/VAS 5052</b>		<b>Engine stopped, ignition switched on</b>	<b>Engine idling</b>	<b>Boat in driving mode</b>
01	Query control unit version	yes	yes	yes
02	Interrogate fault memory	yes <sup>1)</sup>	yes	yes
03	Final control diagnosis	yes	no	no
05	Erase fault memory	yes	yes	yes
06	End output	yes	yes	yes
08	Read measurement block	yes	yes	yes
34	Adaptation	yes	yes	no

<sup>1)</sup> Perform only with ignition switched on, if engine fails to start.

## ScanDi Tool



Y01-0005

## Connecting the fault reader

All functions available on the ScanDi Tool tester are also available on the tester VAS 5052.

### Connecting the ScanDi Tool

Connecting the VAS 5052 ⇒ Page 01-7

### Special tools, workshop equipment, test and measuring equipment and accessories required


- ◆ ScanDi Tool

### Test conditions:

- The battery voltage must be at least 11.5 V.
- Fuse 190 OK.

### Operating procedure

- Unscrew the cover for the diagnostics connection on the main operating unit.
- ◀ - Connect the ScanDi tool.



Y01-0006

**Note:**

*You can also connect the ScanDi Tool to the diagnostics connector in the main electrical panel  
⇒ Overview of installation points, Page 23-4.*

- Depending on the function desired, you must:  
switch on the ignition  
or  
start the engine ⇒ Page 01-3, Table "Selectable functions".

**Notes:**

- ◆ *If the display remains dark, check the power supply for the diagnostics plug using the circuit diagram:  
⇒ Circuit diagrams, Electrical fault finding and Installation points*
- ◆ *If the displays shown in the operating procedure do not appear on the display or if "Connection problem" is shown:  
⇒ ScanDi Tool operating manual*

VW-Marine v1.71

+/- Q

Enter address word XX



Display:

- Operate the ScanDi Tool taking into account the information shown on the display:
- Press the keys 0 and 1 for the "Engine electronics" address word and confirm your entry with the Q key.

06V910401 TDI 225-6 MD 000AG 0010 →
Coding xxxxxxxx                      WSC xxxxx

◀ The control unit identification is shown on the ScanDi Tool display, e.g.:


- ◆ 06V910401 = Part no. of the control unit (for current control unit version, see Spare Parts Catalogue)
- ◆ TDI = Turbo Diesel Injection
- ◆ MD 0000AG = Injection system (Marine Diesel Electronic Control)
- ◆ 0010 = Software version of control unit
- ◆ Coding xxxxxxxx (ignore)
- ◆ WSC xxxxx = Dealership identifier

- Press the → key.

01 engine electronics	+/- Q
Select function XX	K-Ltg 2000

◀ Display:

- See repair procedures for further steps



## Connecting the VAS 5052

### Special tools, workshop equipment, test and measuring equipment and accessories required

- ◆ - Fault reader VAS 5052

### Test conditions:

- The battery voltage must be at least 11.5 V.
- Fuse 190 OK.

### Operating procedure

- Unscrew the cover for the diagnostics connection on the main operating unit.


- ◀ - Connect the fault reader VAS 5052.

### Note:

*You can also connect the VAS 5052 to the diagnostics plug in the main electrical panel ⇒ Overview of installation points, page 23-4.*

### Select operating mode:

- Press the " "Vehicle Self-diagnosis" button on the display.



### **Select vehicle system:**

- Press the "01 - Engine electronics" button on the display.

The control unit identification of the engine control unit is shown on the display.

### **Selecting the diagnosis function:**

All executable diagnosis functions are available on the display.

- Press the button for the desired function on the display.

### **Notes:**

*The display fields in the functions 04 - Basic setting and 08 - Read measurement block, are shown from top to bottom.*

*The following test procedures are described for the ScanDi Tool.*

# Fault memory

## Interrogate fault memory

**Special tools, workshop equipment, test and measuring equipment and accessories required**

- ◆ ScanDi Tool or VAS 5052 fault reader

### Operating procedure

- Connect the ScanDi Tool or the VAS 5052 fault reader and select the engine control unit with the "address word" 01. The engine must be idling. (Connecting the fault reader and selecting the engine control unit ⇒ Page 01-4)

*Only if the engine does not start:*

- Switch on the ignition.

◀ Display:

- Operate the fault reader taking into account the information shown on the display:
- Press the keys 0 and 2 for the function "Interrogate fault memory" and confirm your entry using the Q key.

◀ The display shows the number of faults stored or, alternatively, "No faults detected".

ScanDi Tool



Y01-0005

01 engine electronics	+/- Q
Select function XX	K-Ltg 2000

X faults detected
-------------------



### **If one or more faults are stored:**

By pressing the → key, you can now display the individual fault numbers, together with the corresponding text.

01 engine electronics	+/- Q
Select function XX	K-Ltg 2000



Display:

- Remedy the fault using the fault table:  
SAE P0 codes ⇒ Page 01-13  
SAE P1 codes ⇒ Page 01-27
- Then erase the fault memory ⇒ Page 01-11

### **If no faults are stored:**

- Press the → key.

01 engine electronics	+/- Q
Select function XX	K-Ltg 2000



Display:

- Press keys 0 and 6 for the “End data transfer” function and confirm your entry with the Q key.

## Erasing the fault memory

### Special tools, workshop equipment, test and measuring equipment and accessories required

- ◆ ScanDi Tool or VAS 5052 fault reader

### Test condition

- Fault rectified

### Note:

*After the fault has been cleared, the fault memory must again be interrogated as described below and then erased.*

### Operating procedure

- Connect the ScanDi Tool or the VAS 5052 fault reader and select the engine control unit with the "address word" 01. The engine must be idling. (Connecting the fault reader and selecting the engine control unit ⇒ Page 01-4)

◀ Display:

- Press the keys 0 and 2 for the function "Interrogate fault memory" and confirm your entry using the Q key.

ScanDi Tool



Y01-0005

01 engine electronics

+/- Q

Select function XX

K-Ltg 2000

01 engine electronics	+/- Q
Select function XX	K-Ltg 2000

- Press the → key repeatedly until all the previously stored faults have been displayed and the display is as follows:

05 Erasing the fault memory	→
Fault memory erased	

◀ Display:

- Press the keys 0 and 5 for the function “Erasing the fault memory” and confirm your entry using the Q key.

- If the fault memory cannot be erased, there is still a fault to be rectified.

- Press the → key.

no fault found	→
----------------	---

◀ Display:

- Press the → key.

01 engine electronics	+/- Q
Select function XX	K-Ltg 2000

◀ Display:

- Press keys 0 and 6 for the “End data transfer” function and confirm your entry with the Q key.



**Download the full PDF manual instantly.**

**Our customer service e-mail:**

**[aservicemanualpdf@yahoo.com](mailto:aservicemanualpdf@yahoo.com)**