



























EK25BMH

SERVICE MANUAL

290404

69T-28197-ZA-11

① GEN INFO 	② SPEC 
③ CHK ADJ 	④ FUEL 
⑤ POWR 	⑥ LOWR 
⑦ BRKT 	⑧ ELEC 
⑨ TRBL ANLS 	⑩ 
⑪ 	⑫ 
⑬ 	⑭ 
⑮ 	⑯ 
⑰ 	⑱ 
⑲ 	⑳ 
㉑ 	㉒ 
㉓ 	㉔ 
㉕ 	㉖ 

SYMBOLS

Symbols ① to ⑨ are designed as thumb-tabs to indicate the content of a chapter.

- ① General information
- ② Specifications
- ③ Periodic check and adjustments
- ④ Fuel system
- ⑤ Power unit
- ⑥ Lower unit
- ⑦ Bracket unit
- ⑧ Electrical systems
- ⑨ Trouble analysis

Symbols ⑩ to ⑮ indicate specific data.

- ⑩ Special tool
- ⑪ Specified liquid
- ⑫ Specified engine speed
- ⑬ Specified torque
- ⑭ Specified measurement
- ⑮ Specified electrical value
[Resistance (Ω), Voltage (V), Electric current (A)]










Symbol ⑯ to ⑳ in an exploded diagram indicate the grade of lubricant and the location of the lubrication point.

- ⑯ Apply Yamaha 2-stroke motor oil
- ⑰ Apply water resistant grease (Yamaha grease A, Yamaha marine grease)
- ⑱ Apply water resistant grease (Yamaha grease C, Yamaha marine grease)
- ⑲ Apply water resistant grease (Yamaha grease D, Yamaha marine grease)
- ⑳ Apply molybdenum disulfide grease

Symbols ㉑ to ㉖ in an exploded diagram indicate the grade of the sealing or locking agent and the location of the application point.

- ㉑ Apply Gasket Maker[®]
- ㉒ Apply Yamabond #4 (Yamaha bond number 4)
- ㉓ Apply LOCTITE[®] No.271 (Red LOCTITE)
- ㉔ Apply LOCTITE[®] No.242 (Blue LOCTITE)
- ㉕ Apply LOCTITE[®] No.572
- ㉖ Apply silicon sealant

CONTENTS



GENERAL INFORMATION	 GEN INFO	1
SPECIFICATIONS	 SPEC	2
PERIODIC CHECK AND ADJUSTMENT	 CHK ADJ	3
FUEL SYSTEM	 FUEL	4
RECOIL STARTER	 POWR	5
LOWER UNIT	 LOWR	6
BRACKET UNIT	 BRKT	7
ELECTRICAL SYSTEM	 ELEC	8
TROUBLE ANALYSIS	 TRBL ANLS	9

CHAPTER 1

GENERAL INFORMATION



IDENTIFICATION	1-1
SERIAL NUMBER	1-1
STARTING SERIAL NUMBERS	1-1
SAFETY WHILE WORKING	1-2
FIRE PREVENTION	1-2
VENTILATION	1-2
SELF-PROTECTION	1-2
OILS, GREASES AND SEALING FLUIDS	1-2
GOOD WORKING PRACTICES	1-3
DISASSEMBLY AND ASSEMBLY	1-4
SPECIAL TOOLS	1-5
MEASURING	1-5
REMOVING AND INSTALLING	1-7
FEATURES AND BENEFITS	1-9
POWER UNIT	1-9
IGNITION SYSTEM	1-10
COOLING SYSTEM	1-11
TILLER HANDLE	1-13
BRACKET AND BOTTOM COWLING	1-14



IDENTIFICATION

SERIAL NUMBER

The outboard motor's serial number is stamped on a label which is attached to the port clamp bracket.

NOTE:

As an antitheft measure, a special label on which the outboard motor's serial number is stamped is bonded to the port clamp bracket. The label is specially treated so that peeling it off causes cracks across the serial number.

- ① Model name
- ② Approval model code
- ③ Transom height
- ④ Serial number

STARTING SERIAL NUMBERS


The starting serial number blocks are as follows:

Model name	Approval model code	Starting serial number
Worldwide		
EK25BMH	62C	S:100101
		L:400101
		Y:750101




SAFETY WHILE WORKING

The procedures given in this manual are those recommended by Yamaha to be followed by Yamaha dealers and their mechanics.




FIRE PREVENTION

Gasoline (petrol) is highly flammable. Petroleum vapor is explosive if ignited. Do not smoke while handling gasoline and keep it away from heat, sparks and open flames.




VENTILATION

Petroleum vapor is heavier than air and is deadly if inhaled in large quantities. Engine exhaust gases are harmful to breathe. When test-running an engine indoors, maintain good ventilation.



SELF-PROTECTION

Protect your eyes with suitable safety glasses or safety goggles, when grinding or when doing any operation which may cause particles to fly off. Protect hands and feet by wearing safety gloves or protective shoes if appropriate to the work you are doing.



OILS, GREASES AND SEALING FLUIDS

Use only genuine Yamaha oils, greases and sealing fluids or those recommended by Yamaha.




Under normal conditions or use, there should be no hazards from the use of the lubricants mentioned in this manual, but safety is all-important, and by adopting good safety practices, any risk is minimized. A summary of the most important precautions is as follows:

1. While working, maintain good standards of personal and industrial hygiene.
2. Clothing which has become contaminated with lubricants should be changed as soon as practicable, and laundered before further use.
3. Avoid skin contact with lubricants; do not, for example, place a soiled wiping-rag in your pocket.
4. Hands and any other part of the body which have been in contact with lubricants or lubricant-contaminated clothing, should be thoroughly washed with hot water and soap as soon as practicable.
5. To protect the skin, the application of a suitable barrier cream to the hands before working, is recommended.
6. A supply of clean lint-free cloths should be available for wiping purposes.




GOOD WORKING PRACTICES

1. The right tools
Use the recommended special tools to protect parts from damage. Use the right tool in the right manner - do not improvise.
2. Tightening torque
Follow the tightening torque instructions. When tightening bolts, nuts and screws, tighten the large sizes first, and tighten inner-positioned fixings before outer-positioned ones.




3. Non-reusable items
Always use new gaskets, packings, O-rings, split-pins, circlips, etc., on reassembly.



DISASSEMBLY AND ASSEMBLY

1. Clean parts with compressed air when disassembling.
2. Oil the contact surfaces of moving parts before assembly.




3. After assembly, check that moving parts operate normally.

4. Install bearings with the manufacturer's markings on the side exposed to view, and liberally oil the bearings.
5. When installing oil seals, apply a light coating of water-resistant grease to the outside diameter.




SPECIAL TOOLS

Using the correct special tools recommended by Yamaha, will aid the work and enable accurate assembly and tune-up. Improvising and using improper tools can damage the equipment.




MEASURING

- ① Dial gauge set
P/N. 90890-01252
- ② Crank stand alignment
P/N. 90890-03107
- ③ Pocket tester
P/N. 90890-03112
- ④ Timing light
P/N. 90890-03141
- ⑤ Compression Gauge
P/N. 90890-03160
- ⑥ Peak voltage adaptor
P/N. 90890-03172
- ⑦ Digital circuit tester
P/N. 90890-03174
- ⑧ Ignition tester
P/N. 90890-06754
- ⑨ Vacuum/pressure pump gauge set
P/N. 90890-06756
- ⑩ Digital tachometer
P/N. 90890-06760
- ⑪ Leakage tester
P/N. 90890-06762
- ⑫ Digital caliper
P/N. 90890-06704




- ⑬ Cylinder gauge
P/N. 90890-06759
- ⑭ Outside micrometer
P/N. 90890-03006
P/N. 90890-03008
- ⑮ Inside micrometer
P/N. 90890-03010
- ⑯ Thickness gauge
P/N. 90890-03079
- ⑰ Shimming plate
P/N. 90890-06701
- ⑱ Pinion height gauge
P/N. 90890-06702
- ⑲ Magnet base
P/N. 90890-06705
- ⑳ Backlash indicator
P/N. 90890-06706
- ㉑ Magnet base plate
P/N. 90890-07003



REMOVING AND INSTALLING

- ① Flywheel puller
P/N. 90890-06521
- ② Flywheel holder
P/N. 90890-06522
- ③ Small end bearing installer
P/N. 90890-06527
- ④ Bearing separator
P/N. 90890-06534
- ⑤ Stopper guide plate
P/N. 90890-06501
- ⑥ Bearing housing puller claw
P/N. 90890-06564
- ⑦ Center bolt
P/N. 90890-06504
- ⑧ Drive shaft holder 3
P/N. 90890-06517
- ⑨ Bearing puller ass'y
P/N. 90890-06535
- ⑩ Stopper guide stand
P/N. 90890-06538
- ⑪ Driver rod LL
P/N. 90890-06605
- ⑫ Driver rod LS
P/N. 90890-06606
- ⑬ Driver rod L3
P/N. 90890-06652
- ⑭ Driver rod SL
P/N. 90890-06602
- ⑮ Driver rod SS
P/N. 90890-06604
- ⑯ Bearing depth plate
P/N. 90890-06603
- ⑰ Needle bearing attachment
P/N. 90890-06608
P/N. 90890-06611
P/N. 90890-06615
- ⑱ Ball bearing attachment
P/N. 90890-06633
- ⑲ Bearing inner race attachment
P/N. 90890-06643
P/N. 90890-06644
P/N. 90890-06645
- ⑳ Bearing outer race attachment
P/N. 90890-06622
P/N. 90890-06628



- 21 Frange
P/N. 90890-02351
- 22 Body
P/N. 90890-02352
- 23 Bolt
P/N. 90890-02353
- 24 Washer
P/N. 90890-02354
- 25 Bushing-5 (D25)
P/N. 90890-02359
- 26 Bushing-12 (D35)
P/N. 90890-02366
- 27 Height ring-13 (H57)
P/N. 90890-02379
- 28 Pressure Plate
P/N. 90890-02384
- 29 Press body
P/N. 90890-02385
- 30 Plate A
P/N. 90890-02386
- 31 Plate B
P/N. 90890-02387
- 32 Pressure pin B
P/N. 90890-02390
- 33 Bearing pressure B
P/N. 90890-02392
- 34 Bearing pressure C
P/N. 90890-02393
- 35 Support
P/N. 90890-02394
- 36 Spacer B
P/N. 90890-02396
- 37 Bushing-14
P/N. 90890-02419

FEATURES AND BENEFITS

POWER UNIT

The EK25B is designed to provide superior fuel economy, serviceability, and durability. They are based on the previous EK25A with newly designed linkage to control both throttle opening and ignition timing mechanically and simultaneously. Special attention was paid on the crankshaft bearings. Collar is now added to the upper main journal of the crankshaft. Roller bearing is applied for the center bearing. The collar added on the upper main journal contributes to get and better serviceability.




Fig. 1




Fig. 2

IGNITION SYSTEM

Ignition system on the EK25B consists of flywheel magnet, charge coil, pulser coil, CDI unit, and ignition coil.

Similar to the previous EK25A, the engine has the mechanical ignition timing advance system that works by way of the linkage.

Superior fuel economy is attained by the modified ignition timing control arrangement.

Also the system restricts the ignition timing advance to prevent engine kickback when the shift is in neutral.




Fig. 3

COOLING SYSTEM

New structure applied to the cooling system provides additional cooling capacity in the upper casing.

With additional cooling water passage (indicated by \leftarrow), water walls contained in the new upper casing contribute to the reduction of outer surface temperature.




Fig. 4

COOLING SYSTEM




Fig. 5

TILLER HANDLE

For the throttle grip on the steering handle of the EK25B, 100 degrees of opening angle covers all ranges from full-closed to wide-open positions.

Also, new steering handle parts were developed to assume the long use. Inner diameter of the steering handle engagement area, and both inner and outer diameters of steering bracket are increased.

Please note that if the new steering handle is installed on the previous models, Steering handle 2, Steering bracket, Collar, and Washer must be replaced.




Fig. 6




Fig. 7



BRACKET AND BOTTOM COWLING

The Bracket 1 is modified on the EK25B, and newly designed rubber seal is added to provide better sealing ability for the bottom cowling.




Fig. 8

CHAPTER 2 SPECIFICATIONS

GENERAL SPECIFICATIONS 2-1

MAINTENANCE SPECIFICATIONS 2-3

 POWER UNIT 2-3

 LOWER UNIT 2-5

 ELECTRICAL 2-6

 DIMENSIONS 2-8

 DIMENSIONS 2-9

TIGHTENING TORQUES 2-11

 SPECIFIED TORQUES 2-11

 GENERAL TORQUES 2-12





GENERAL SPECIFICATIONS






Item	Worldwide	Unit	Model
			EK25BMH
DIMENSIONS			
Overall length		mm (in)	843 (33.2)
Overall width		mm (in)	399 (15.7)
Overall height			
(S)		mm (in)	1,146 (45.1)
(L)		mm (in)	1,273 (50.1)
(Y)		mm (in)	1,320 (52.0)
Boat transom height			
(S)		mm (in)	381 (15.0)
(L)		mm (in)	508 (20.0)
(Y)		mm (in)	559 (22.0)
WEIGHT			
(S)		kg (lb)	53.0 (116.9)
(L)		kg (lb)	54.5 (120.2)
(Y)		kg (lb)	55.0 (121.3)
PERFORMANCE			
Maximum output (ISO)		kW (hp) @5,000 r/min	18.4 (25.0)
Full throttle operating range		r/min	4,500 - 5,500
Maximum fuel consumption		L (US gal, Imp gal) @5,500 r/min	13.8 (3.6, 3.0) Gasoline / Kerosene
POWER UNIT			
Type			2 stroke
Number of cylinders			2
Displacement		cm ³ (cu. in)	496 (30.3)
Bore and stroke		mm (in)	72.0 × 61.0 (2.83 × 2.40)
Compression ratio		kPa (kgf/cm ² , psi)	#1: 5.3 (0.05, 0.8), #2: 5.7 (0.06, 0.8)
Compression pressure		kPa (kgf/cm ² , psi)	#1: 680 (6.8, 98.6), #2: 730 (7.3, 105.9)
<Minimum>		kPa (kgf/cm ² , psi)	#1: 540 (5.4, 78.3), #2: 580 (5.8, 84.1)
Spark plug(NGK)			B7HS-10
Number of carburetor			1
Enrichment system			Chock valve
Intake system			Reed valve
Induction system			Loop charge
Exhaust system			Through propeller boss








Item	Worldwide	Unit	Model
			EK25BMH
Lubrication system			Mixed (Gasoline and oil, Kerosene and oil)
Cooling system			Water
Ignition control system			CDI
Alternator output		V - W	12 - 80
POWER UNIT			
Starting system			Manual
Control system			Mechanical
Advanced system			Mechanical
CARBURETOR			
ID mark			69T00
FUEL AND OIL			
Fuel type (Main)			Kerosene
Mixing ratio (Sub)			30 : 1
Mixing ratio			Unleaded regular gasoline
Engine oil type			50 : 1
Engine oil grade			2 stroke outboard engine oil
Gear oil			TC - W3
Gear oil grade			Hypoid gear oil
Gear oil capacity		cm ³ (US oz, Imp oz)	SAE #90 (API GL - 4) 320 (10.8, 11.3)
BRACKET			
Tilt angle		Degree	4, 8, 12, 16, 20
Tilt-up angle		Degree	76
Shallow water angle from transom		Degree	Tilt angle + 20
Steering angle		Degree	40 + 40
DRIVE UNIT			
Gear shift positions			F - N - R
Gear ratio			2.08 (27/13)
Gear type			Spiral bevel
Propeller direction (rear view)			Clockwise
Propeller drive system			Spline
Propeller mark			F



**MAINTENANCE SPECIFICATIONS
POWER UNIT**

Item	Worldwide	Unit	Model
			EK25BMH
CYLINDER HEAD			
Warpage limit		mm (in)	0.1 (0.004)
 <p>(lines indicate straightedge position)</p>			
CYLINDERS			
Bore size		mm (in)	72.00 - 72.02 (2.8346 - 2.8354)
Wear limit		mm (in)	72.10 (2.8386)
Taper limit		mm (in)	0.08 (0.0031)
Out-of-round limit		mm (in)	0.05 (0.0020)
PISTON			
Piston side "D"		mm (in)	71.94 - 71.96 (2.8323 - 2.8331)
Measuring point "H"		mm (in)	10.0 (0.3937)
			
Piston-cylinder clearance		mm (in)	0.060 - 0.065 (0.0024 - 0.0026)
<Limit>		mm (in)	0.1 (0.0039)
Oversize piston diameter	1st	mm (in)	72.25 (2.8445)
	2nd	mm (in)	72.50 (2.8543)
Pin boss inside diameter		mm (in)	19.904 - 19.915 (0.7836 - 0.7841)
PISTON PINS			
Outside diameter		mm (in)	19.895 - 19.900 (0.7833 - 0.7835)
PISTON RING (1st)			
Type			Keystone
(B)		mm (in)	2.0 (0.079)
(T)		mm (in)	3.0 (0.118)
End gap (installed)		mm (in)	0.20 - 0.35 (0.008 - 0.014)
<Limit>		mm (in)	0.35 (0.014)
Side clearance		mm (in)	0.03 - 0.05 (0.0012 - 0.0020)
<Limit>		mm (in)	0.05 (0.0020)



Item	Worldwide	Unit	Model	
			EK25BMH	
PISTON RING (2nd)				
Type			Plain	
(B)		mm (in)	2.0 (0.079)	
(T)		mm (in)	3.0 (0.118)	
End gap (installed)		mm (in)	0.20 - 0.35 (0.0079 - 0.0137)	
<Limit>		mm (in)	0.35 (0.014)	
Side clearance		mm (in)	0.03 - 0.07 (0.0012 - 0.0028)	
<Limit>		mm (in)	0.07 (0.0028)	
CRANKSHAFT				
Crank width (A)		mm (in)	56.90 - 56.95 (2.2401 - 2.2421)	
(B)		mm (in)	153.7 - 154.0 (6.0512 - 6.0630)	
(C)		mm (in)	39.9 - 40.1 (1.5709 - 1.5787)	
Runout limit (D)		mm (in)	0.03 (0.0012)	
Side clearance (E)		mm (in)	0.2 - 0.7 (0.0079 - 0.0276)	
Maximum axial play (F)		mm (in)	2.0 (0.079)	
CONNECTING ROD				
Small end diameter		mm (in)	23.904 - 23.917 (0.941 - 0.942)	
CARBURETOR				
Main jet (M.J.)		#	Kerosene carburetor	Gasoline carburetor
			155	—
Main air jet (M.A.J.)		φmm (in)	1.3 (0.051)	—
Main nozzle (M.N.)		φmm (in)	2.8 (0.110)	—
Pilot jet (P.J.)		#	50	48
Pilot air jet (P.A.J.)		mm (in)	0.92 (0.036)	0.90 (0.035)
Pilot screw (P.S.)		turns out	1/2 + 2 1/2 - 1/2	1 - 1/2 ± 1/2
Valve seat size (V.S.)		mm (in)	1.4 (0.055)	1.2 (0.047)
Float height		mm (in)	18 (0.079)	—
Float arm height		mm (in)	—	3 (0.118)
Idle speed		r/min	1,300 ± 50	



Item	Worldwide	Unit	Model
			EK25BMH
REED VALVES			
Thickness			0.2 (0.008)
Valve stopper height (Standard)		mm (in)	3.46 - 3.50 (0.136 - 0.138)
(for Sri Lanka)		mm (in)	4.20 - 4.60 (0.165 - 0.181)
Valve bending limit		mm (in)	0.2 (0.008)
THERMOSTAT			
Valve opening temperature		°C (°F)	48 - 52 (118 - 126)
Full-open temperature		°C (°F)	60 (140)
Minimum valve lift		mm (in)	3 (0.12)

LOWER UNIT

Item	Worldwide	Unit	Model
			EK25BMH
GEAR BACKLASH			
Pinion - forward gear		mm (in)	0.31 - 0.72 (0.012 - 0.028)
Pinion - reverse gear		mm (in)	0.93 - 1.65 (0.037 - 0.065)
Pinion gear shims		mm	0.7 / 1.0 / 1.1 / 1.2 / 1.3 / 1.4 / 1.5 / 1.6
Forward gear shims		mm	1.0 / 1.1 / 1.2 / 1.3 / 1.4
Reverse gear shims		mm	1.0 / 1.1 / 1.2 / 1.3
PROPELLER			
Material			Aluminium
No. of blades × diameter × pitch		in	3 × 9 - 7/8 × 11 - 1/4 3 × 9 - 7/8 × 8 3 × 9 - 7/8 × 9 3 × 9 - 7/8 × 10 - 1/2 3 × 9 - 7/8 × 12 3 × 9 - 7/8 × 13 3 × 9 - 7/8 × 14
Test propeller		P/N.	90890-01629
		r/min	5,250 - 5,450



ELECTRICAL

Item	Worldwide	Unit	Model
			EK25BMH
IGNITION SYSTEM			
Ignition timing (Full retard)		Degree	ATDC 2 ± 2
(Full advanced)		Degree	BTDC 22 ± 2
Spark plug gap		mm (in)	0.9 - 1.0 (0.035 - 0.039)
Ignition spark gap (Minimum)		mm (in)	8.0 (0.31)
Ignition coil resistance (Primary)		Ω	0.18 - 0.24
(Secondary)		k Ω	2.70 - 3.70
Charge coil resistance (Br - L)		Ω	342 - 418
Charge coil output peak voltage (Br - L)			
@ cranking 1 ^{*1}		V	146
@ cranking 2 ^{*1}		V	146
@ 1,500 r/min		V	150
@ 3,500 r/min		V	150
Pulser coil resistance (W/R - B , W/B - B)		Ω	311 - 381
Pulser coil output peak voltage (W/R - B , W/B - B)			
@ cranking 1 ^{*1}		V	6.8
@ cranking 2 ^{*1}		V	6.7
@ 1,500 r/min		V	16.0
@ 3,500 r/min		V	26.0
CDI unit resistance		Ω	Refer to the "CDI UNIT" on page 8-10
CDI unit output peak voltage (B/O - B , B/W - B)			
@ cranking 1 ^{*1}		V	5.5
@ cranking 2 ^{*1}		V	130.0
@ 1,500 r/min		V	135.0
@ 3,500 r/min		V	135.0

*1 Cranking 1: Open circuit.
Cranking 2: Related parts are connected.




Item	Worldwide	Unit	Model
			EK25BMH
CHARGING SYSTEM			
Lighting coil resistance (G - G)		Ω	0.31 - 0.37
Lighting coil output peak voltage (G - G)			
@ cranking 1 ^{*1}		V	4.6
@ cranking 2 ^{*1}		V	—
@ 1,500 r/min		V	—
@ 3,500 r/min		V	—
@ 1,500 r/min (Open circuit)		V	14.7
@ 3,500 r/min (Open circuit)		V	30.0

*1 Cranking 1: Open circuit.
Cranking 2: Related parts are connected.




DIMENSIONS





DIMENSIONS

Symbol	Worldwide	Unit	Model
			EK25BMH
L1		mm (in)	429 (16.89)
L2		mm (in)	180 (7.09)
L3		mm (in)	420 (16.54)
L4		mm (in)	385 (15.16)
L5	(S)	mm (in)	61 (2.40)
	(L)	mm (in)	83 (3.27)
	(Y)	mm (in)	83 (3.27)
L6	(S)	mm (in)	736 (28.98)
	(L)	mm (in)	854 (33.62)
	(Y)	mm (in)	897 (35.31)
L7		mm (in)	405 (15.94)
L8		mm (in)	195 (7.68)
L10		mm (in)	74.2 (2.92)
H1	(S)	mm (in)	707 (27.83)
	(L)	mm (in)	834 (32.83)
	(Y)	mm (in)	881 (34.68)
H2		mm (in)	439 (17.28)
H3		mm (in)	144 (5.67)
H4	(S)	mm (in)	423 (16.65)
	(L)	mm (in)	550 (21.65)
	(Y)	mm (in)	597 (23.50)
H5		mm (in)	466 (18.35)
H6	(S)	mm (in)	621 (24.45)
	(L)	mm (in)	701 (27.60)
	(Y)	mm (in)	730 (28.74)
H7		mm (in)	118 (4.65)
H8		mm (in)	30 (1.18)
H9		mm (in)	596 (23.46)
H10		mm (in)	40.3 (1.59)
W1		mm (in)	166 (6.54)
W2		mm (in)	233 (9.17)
W3		mm (in)	148 (5.83)
W4		mm (in)	192 (7.56)
W5		mm (in)	302 (11.89)
W6		mm (in)	472 (18.58)
A1		Degree	40
A2		Degree	68
C1		mm (in)	35 (1.38)
C2		mm (in)	65 (2.56)



Symbol	Worldwide	Unit	Model
			EK25BMH
B1		mm (in)	89 (3.50)
B2		mm (in)	140 (5.51)
B3		mm (in)	112.5 (4.43)
B4		mm (in)	96.5 (3.80)
B5		mm (in)	122.5 (4.82)
B6		mm (in)	176 (6.93)
B11		mm (in)	85 (3.35)
B12		mm (in)	51 (2.01)
D1		ømm (in)	8.5 (0.33)



TIGHTENING TORQUES


SPECIFIED TORQUES

Part to be tightened	Part name	Thread size	Q'ty	Tightening torques			Remarks	
				N•m	kgf•m	ft•lb		
POWER UNIT								
Recoil starter mounting	Bolt	M6	3	12	1.2	8.9		
Recoil starter center bolt	Bolt	M12	1	15	1.5	11		
Recoil starter center Nut	Nut	—	1	10	1.0	7.4		
Flywheel magnet	Nut	M12	1	140	14	103		
Power unit mounting	1st	Bolt	M8	6	11	1.1	8.1	
	2nd				22	2.2	16	
Intake manifold mounting	1st	Bolt	M6	9	4	0.4	3.0	
	2nd				8	0.8	5.9	
Spark plug	—	M14	2	25	2.5	18		
Cylinder head mounting	1st	Bolt	M8	11	15	1.5	11	
	2nd				30	3.0	22	
Exhaust cover mounting	1st	Bolt	M6	15	4	0.4	3.0	
	2nd				8	0.8	5.9	
Crankcase mounting	1st	Bolt	M8	10	15	1.5	11	
	2nd				30	3.0	22	
LOWER UNIT								
Propeller	Nut	—	1	35	3.5	26		
Lower unit mounting	Bolt	M10	6	37	3.7	27		
	Nut	M10	6	37	3.7	27		
Propeller shaft housing	Bolt	M6	2	11	1.1	8.1		
Pinion gear nut	Nut	M8	1	50	5.0	37		
Water inlet	Bolt	M5	2	5	0.5	3.7		
BRACKET								
Shift actuator mounting	Bolt	M6	4	11	1.1	8.1		
	Nut	M10	1	17	1.7	13		
Shift lever	Bolt	M6	1	11	1.1	8.1		
Mount rubber(side upper)	Nut	M10	2	17	1.7	13		
Mount rubber(lower front)	Bolt	M8	2	17	1.7	13		
Steering bracket mounting	Bolt	M6	4	11	1.1	8.1		
Clamp bracket nylon	Nut	—	2	45	4.5	33		
ELECTRICAL								
CDI unit	Bolt	M6	2	4	0.4	3.0		
Ignition coil	Bolt	M6	2	8	0.8	5.9		
Engine stop switch	Nut	M16	1	35	3.5	26		

* Do not apply too much torque.



Nut (A)	Bolt (B)	General torque specifications		
		N•m	kgf•m	ft•lb
8 mm	M5	5	0.5	3.7
10 mm	M6	8	0.8	5.9
12 mm	M8	18	1.8	13
14 mm	M10	36	3.6	27
17 mm	M12	43	4.3	32



GENERAL TORQUES

This chart specifies tightening torques for standard fasteners with a standard ISO thread pitch. Tightening torque specifications for special components or assemblies are provided in applicable sections of this manual. To avoid warpage, tighten multi-fastener assemblies in a crisscross fashion and progressive stages until the specified tightening torque is reached. Unless otherwise specified, tightening torque specifications require clean, dry threads. Components should be at room temperature.

CHAPTER 3

PERIODIC CHECK AND ADJUSTMENT

MAINTENANCE INTERVAL CHART	3-1
TOP COWLING	3-2
CHECKING THE TOP COWLING FIT	3-2
FUEL SYSTEM	3-2
CHECKING THE FUEL LINE	3-2
CHECKING THE FUEL FILTER	3-3
CHECKING THE FUEL PUMP	3-3
CHECKING THE FUEL JOINT	3-3
CONTROL SYSTEM	3-4
ADJUSTING THE IGNITION TIMING	3-4
ADJUSTING THE ENGINE IDLE SPEED	3-15
ADJUSTING THE START-IN-GEAR PROTECTION DEVICE	3-17
POWER UNIT	3-18
MEASURING THE COMPRESSION PRESSURE	3-18
COOLING SYSTEM	3-19
CHECKING THE COOLING WATER DISCHARGE	3-19
LOWER UNIT	3-19
CHECKING THE GEAR OIL LEVEL	3-19
CHANGING AND CHECKING THE GEAR OIL	3-19
CHECKING THE LOWER UNIT (FOR AIR LEAKS)	3-20
GENERAL	3-21
CHECKING THE ANODE	3-21
CHECKING THE SPARK PLUGS	3-22
CHECKING THE PROPELLER	3-23
CHECKING BOLTS AND NUTS	3-23
LUBRICATION POINTS	3-24

MAINTENANCE INTERVAL CHART

Frequency of maintenance operations may be adjusted according to the operating conditions, but the following table gives general guidelines.

The mark (●) indicates the check-ups which may be carried out by owner.




The mark (○) indicates work to be carried out by Yamaha dealer.

Item	Remarks	Initial		Every		Refer page
		10 hours	50 hours (3 months)	100 hours (6 months)	200 hours (1 year)	
FUEL SYSTEM						
Fuel filter	Clean	●	●	●		3-3
Fuel system	Check			○		3-2
Fuel tank	Clean				●	—
POWER UNIT						
Carburetor setting	Check	○		○		3-15
	Adjust	○		○		3-15
Cooling water passage	Clean	●		●	○	—
Exhaust leakage	Check	○	○	○		—
Water leakage	Check	○	○	○		—
CONTROL SYSTEM						
Ignition timing	Check	○		○		3-4
	Adjust	○		○		3-4
Idle speed	Check			○		3-15
	Adjust			●		3-15
LOWER UNIT						
Gear oil	Change	●		●		3-19
Propeller	Check		○	○		3-23
GENERAL						
Spark plug	Clean	●	●	●		3-22
	Adjust	●	●	●		3-22
	Replace	●	●	●		3-22
Wiring and connectors	Check	○	○	○		—
Grease points	Grease			●		3-24
Bolts and nuts	Retighten	○		○		3-23
Anode	Check	○	○	○		3-21
Motor exterior	Check		○	○		—

NOTE:

Cooling water passages:

When operating in salt water, turbid or muddy water, the engine should be flushed with clean water after each use.



TOP COWLING

CHECKING THE TOP COWLING FIT

Check:

- Top cowling
Cracks/damage → Replace.
- Hook
Bent → Correct.
- Rivet
Damage → Repair.
- Rubber of trim
Peel/tear → Repair.

NOTE: _____


Hooks and latches are unadjustable.

FUEL SYSTEM

CHECKING THE FUEL LINE

Check:


- Fuel hose
Cracks/damage/leak → Replace.
Refer to "FUEL JOINT, FUEL FILTER,
AND FUEL PUMP" on page 4-1.



CHECKING THE FUEL FILTER

Check:

- Fuel filter element ①
Foreign matter → Clean.
- Fuel filter cup ②
Cracks/damage/leak → Replace.
- O-ring ③
Cracks/damage → Replace.




CHECKING THE FUEL PUMP

Check:

- Fuel pump
Cracks/damage/leak →
Repair/replace.
Refer to "DISASSEMBLING THE
FUEL PUMP" on page 4-4.

NOTE: _____

Observe pump with naked eyes.



CHECKING THE FUEL JOINT

Check:

- Fuel joint ①
Cracks/damage/leak → Replace.
- Seal ②
Cracks/damage → Replace.



CONTROL SYSTEM ADJUSTING THE IGNITION TIMING

CAUTION:

Ignition timing adjustment on the running engine must be performed in the test tank with a test propeller installed on the engine.



Test propeller
90890-01629

⚠ WARNING

While checking the engine, do not touch the rotating part (flywheel), CDI unit, ignition coil, and any other hazardous areas.


1. Check:
 - Ignition timing
 Out of specification → Adjust.



Ignition timing (at idle)
ATDC $2^\circ \pm 2^\circ$
Ignition timing (at full advance)
BTDC $22^\circ \pm 2^\circ$



Engine idle speed
 $1,300 \pm 50$ r/min
Full throttle operating range
 $5,350 \pm 100$ r/min




Checking steps


- (1) Install the timing light (a) onto the spark plug lead of cylinder #1.
- (2) Install the digital tachometer (b) onto the spark plug lead of cylinder #1.
- (3) Press the position key "C" on the digital tachometer.
- (4) Start the engine and allow it to warm up for a few minutes.



Timing light (a)
90890-03141
Digital tachometer (b)
90890-06760




(5) Set the shift lever ① in forward position.




(6) Fully open the throttle by moving the throttle ② to the "FAST" position.

	Full throttle operating range 5,350 ± 100 r/min
--	--



(7) Check the ignition timing by pointing the timing light at the timing indicator on the starter case.

	Ignition timing (at full advance) BTDC 22° ± 2°
--	--




(8) Move the throttle ② to full-close position.

	Engine idle speed 1,300 ± 50 r/min
--	---






(9) Check the ignition timing by pointing the timing light at the timing indicator on the starter case.

	Ignition timing (at idle) ATDC 2° ± 2°
--	---



NOTE: _____

- Ignition timing adjustment is not required if the timing indicator reading falls within the specification.
- If the reading is out of specification, adjust the timing by the following procedure.



2. Adjustment with full-open throttle:
 - Magnet base stopper

CAUTION:

- Make sure that engine is not running.
- Remove the plug caps.


Adjustment steps

- (1) Set the shift lever ① in forward position.
- (2) Move the throttle ② to full-open position.
- (3) Slowly turn the flywheel clockwise to align the full advanced timing mark with the specified position on the timing indicator.




Ignition timing (at full advance)
BTDC 22° ± 2°

- (4) Turn the magnet base ③ until the timing mark (a) on the port side comes in line with the ignition mark (b) on the rotor.
- (5) Check that the magnet base stopper ④ is in contact with the stopper on the engine body (full-open end stopper) ⑤.



(6) If they are not in contact, loosen the set bolt (6), adjust until they are correctly in contact with each other, and secure the bolt again.




3. Adjusting the carburetor control link:


- Accelerator cam
- Carburetor control link

Adjustment steps


(1) Set the shift lever (1) in forward position.




(2) Move the throttle (2) to full-open position.



(3) Make sure that the magnet base stopper (3) is in contact with the stopper on the engine body (full-open end stopper) (4).




(4) Check to see that the full-open marking "C" on the accelerator cam aligns with the center of the cam roller.





(5) "Loosen the bolt, and align the full-open marking "C" with the center of carburetor throttle roller, and tighten the set-bolt."

NOTE: _____
Remove the manual starter before adjusting.



(6) "Loosen the rod tightening screw (a). While pushing the rod with your finger, tighten the screw so that the throttle is full-open (the full-open stopper (b) is pushed against the stopper (c)), and lock the screw."


NOTE: _____
After adjustment, open and close the throttle repeatedly for several times to reassure that the full-open position of the accelerator cam and the positioning of the carburetor control link stopper are correct.




4. Adjustment with full-closed throttle:
- Accelerator cam
 - Carburetor control link

Adjustment steps


(1) Set the shift lever (1) in forward position.




(2) Move the throttle (2) to full-close position.




(3) Make sure that the magnet base stopper ③ is in contact with the stopper on the engine body (full-close end stopper)④.




(4) Make sure that the lever is in contact with the carburetor throttle stop screw.



(5) Correct adjustment has been established if the cam roller is not in contact with the accelerator cam.








(6) If the lever is not in contact with the throttle stop screw move the plate cam to the left so that the lever comes to contact with the throttle stop screw.



NOTE:

- When shifting the plate cam slightly, do not shift it more than 2 mm (0.079 in) to the left from the point at which the marking line of the full-open mark "C" aligns with the centerline of the roller cam at full-throttle.
- After adjustment, open and close the throttle for several times, and reassure that the lever is in contact with the throttle stop screw on the carburetor, and that the cam roller is not in contact with the accelerator cam.



5. Adjusting the throttle cable
- Throttle cable

Adjusting steps

NOTE: _____

After adjustment, open and close the throttle for several times for reassurance.


- (1) Set the shift lever (1) in forward position.

- (2) Move the throttle (2) to full-open position.


- (3) Check that the magnet base stopper (3) is in contact with the stopper on the engine body (full-open end stopper) (4).

- (4) If the stoppers come in contact before the throttle is fully open, loosen the lock nut (6) on the throttle-opening cable, turn-in the adjusting nut (5) until the correct positioning is attained, and then secure it by the lock nut (6).


- (5) If the stoppers do not come in contact at full-open throttle, then turn-out the adjusting nut (5) on the throttle-opening cable until the correct positioning is attained, and secure it by the lock nut (6).




(6) After confirming the positive contact of stoppers at full-open throttle position, turn the adjusting nut ⑦ on the throttle-closing cable so that the cable has a little slack, and then secure it by the lock nut ⑧.




(7) Once the adjustment under full-open throttle is completed, move the throttle ② to full-close position.



(8) Make sure that the magnet base stopper ③ is in contact with the stopper on the engine body (full-close end stopper) ④.




(9) Move the throttle ② to full-open position.




(10) In this condition, make sure that the full-open stopper is in contact with the stopper.

NOTE: _____
If they are not in contact, adjust the carburetor control link.

Refer to "Adjusting the carburetor control link:" on page 3-7.



(11) Move the throttle ② to full-close position.




(12) At this point, make sure that the throttle lever is in contact with the throttle stop screw on the carburetor.

NOTE:

- After adjustment, open and close the throttle for several times for reassurance.
- If they are not in contact, adjust the carburetor control link.

Refer to "Adjusting the carburetor control link:" on page 3-7.




6. Adjusting the throttle control lever:


- Throttle control lever

Adjustment steps


(1) Set the shift lever ① at the forward position.




(2) Move the throttle ② to full-open position.



(3) Check that the magnet base stopper ③ is in contact with the stopper on the engine body (full-open end stopper) ④.




(4) Check that the throttle control lever ⑤ is in contact with the stopper ⑥ on the bottom cowling.



(5) If they are not in contact, adjust the length of the joint link (C) that the throttle control lever seats on the stopper on the bottom cowling.

NOTE: _____

After adjustment, open and close the throttle repeatedly for several times to reassure the correct positioning.




(6) Check that the magnet base stopper ③ is in contact with the stopper on the engine body (full-open end stopper) ④.

NOTE: _____

If they are not in contact, perform the adjustment with full-open throttle.

Refer to "Adjustment with full-open throttle:" on page 3-6.





(7) In this condition, make sure that the full-open stopper is in contact with the stopper.

NOTE: _____

If they are not in contact, adjust the carburetor control link.

Refer to "Adjusting the carburetor control link:" on page 3-7.



7. Adjusting the engine idle speed:
- Engine idle speed

Adjustment steps

- (1) Adjust the pilot screw.



Pilot screw turn-out

Gasoline carburetor:

1 - 1/2 ± 1/2

Kerosene carburetor:

1/2 + 2

1/2 - 1/2

- (2) Adjust the idling stop screw



Engine idle speed

1,300 ± 50 r/min

Refer to "ADJUSTING THE ENGINE IDLE SPEED" on page 3-15.



ADJUSTING THE ENGINE IDLE SPEED

NOTE:

- The engine should be warmed up for the adjustment. Correct adjustment cannot be obtained when the engine is cold.
- Make sure that the pilot screw adjustment is normal before implementing idling stop screw adjustment.

1. Measure:

- Engine idle speed
Out of specification → Adjust.




Engine idle speed
1,300 ± 50 r/min

CAUTION:

Install the engine in the test tank to check the engine idle speed.

Measuring steps

- (1) Start the engine and allow it to warm up for a few minutes.
- (2) Install the digital tachometer ① onto the spark plug lead of cylinder #1.
- (3) "Press the position key "C" on the digital tachometer."



Digital Tachometer.....①
90890-06760

2. Adjust:


- Carburetor pilot screw

CAUTION:

Do not adjust the carburetor when it is operating properly. Excessive adjustment may cause the engine poor performance.

Adjustment steps

- (1) Turn in the pilot screw (①:Gasoline, ②:Kerosene) until they are lightly seated.
- (2) Turn out the pilot screws by specified number of turns.



Pilot screw turn-out
Gasoline carburetor:
1 - 1/2 ± 1/2
Kerosene carburetor:
1/2 + 2
1/2 - 1/2



Download the full PDF manual instantly.

Our customer service e-mail:

aservicemanualpdf@yahoo.com