


HA250-1 S/N 60636-UP
HA250-1 S/N 60636-UP

Item	Part Name
	S6D125-1B8-FA S/N 10001-UP
10	ENGINE RELATED PARTS AND COOLING SYSTEM
20	TORQUE CONVERTER AND TRANSMISSION
30	DRIVE SHAFT?DIFFERENTIAL?WHEELS AND BRAKES
40	AIR PRESSURE SYSTEM
50	HYDRAULIC SYSTEM
60	ELECTRICAL SYSTEM
70	FRONT VEHICLE AND CAB
80	REAR VEHICLE
90	TOOL AND OTHERS

HA250-1 S/N 60636-UP
ENGINE RELATED PARTS AND COOLING SYSTEM

Item	Part Name	Qty
10	DAMPER?ENGINE FLYWHEEL	1
20	RADIATOR	1
30	ENGINE?FAN PROTECTOR(#61316-)	1
40	ENGINE WATER COOLING SYSTEM	1
50	ENGINE WATER EXPANSION TANK	1
60	ENGINE MOUNTING PARTS	1
70	FUEL OIL TANK	1
80	ENGINE CONTROL(#60636-61169)	1
90	ENGINE CONTROL(#61170-)	1
100	ENGINE AIR INTAKE SYSTEM	1
110	ENGINE EXHAUST SYSTEM	1

HA250-1 S/N 60636-UP
 @@Q36613




Ref. 1001

Page 030010

HA250-1 S/N 60636-UP
 DAMPER?ENGINE FLYWHEEL

Item	Part No.	Part Name	Qty	Serial No.
40	BW053593	COUPLING ASS'Y,RUBBER	1	60636-
41	BW053266	· BOLT	8	60636-
42	BW063266	· WASHER	8	60636-
43	BW053597	· HOUSING	1	60636-
44	BW053594	· RING, FRICTION	1	60636-
45	BW053598	· HUB	1	60636-
46	BW053595	· RING, FRICTION	1	60636-
47	BW053596	· DAMPER ASS'Y	1	60636-
48	BW061279	· BOLT	8	60636-
49	BW063352	· WASHER	8	60636-
50	BW153020	· BOLT	8	60636-
51	BW063348	· WASHER	8	60636-

HA250-1 S/N 60636-UP
 @@Q36614




Ref. 1101

Page 030020

HA250-1 S/N 60636-UP
 RADIATOR

Item	Part No.	Part Name	Qty	Serial No.
1	BW251234	RADIATOR ASS'Y	1	60636-
2	BW251323	· RADIATOR	1	60636-
3	BW251324	· SHROUD,FAN	1	60636-
4	BW061472	· SCREW	8	60636-
5	BW034042	STAY	2	60969-
	■BW033417	STAY (BW034212,BW045766)	2	60636-60968
5	BW034095	STAY,L.H. (WITH AIR CONDITIONER)	1	60969-
	■BW033713	STAY,L.H. (WITH AIR CONDITIONER) (BW034095,BW045766)	1	60636-60968
5	BW034212	STAY,R.H. (WITH AIR CONDITIONER)	1	61170-
	■BW033417	STAY,R.H. (WITH AIR CONDITIONER) (BW034212,BW045766)	1	60636-61169
6	BW061487	BOLT	2	60636-
7	BW061489	BOLT	2	60636-
8	BW063039	NUT	2	60636-
9	BW063348	WASHER	8	60636-
10	BW045766	SLEEVE	2	60969-
11	BW151975	CUSHION,RUBBER	2	60636-
12	BW063391	WASHER	2	60636-
13	BW060483	BOLT	2	60636-
15	BW011563	COVER,FAN SHROUD	1	61214-
16	BW045978	GASKET	1	61214-
17	BW045979	GASKET	2	61214-

HA250-1 S/N 60636-UP
 @@Q36615




Ref. 1103

Page 030030

HA250-1 S/N 60636-UP
 ENGINE?FAN PROTECTOR(#61316-)

Item	Part No.	Part Name	Qty	Serial No.
	BW034331	PROTECTOR ASS'Y,FAN	1	61316-
	BW034332	PROTECTOR ASS'Y,FAN (WITH AIR CONDITIONER)	1	61316-
1	BW011559	· NET,WIRE	2	61316-
2	BW061462	· BOLT	4	61316-
3	BW063386	· WASHER	8	61316-
4	BW063036	· NUT	4	61316-
5	BW034291	· BRACKET	1	61316-
6	BW034292	· BRACKET	2	61316-
7	BW061490	· BOLT	1	61316-
8	BW060476	· BOLT	1	61316-
9	BW022347	· SHIELD,UPPER	1	61316-
	BW022348	· SHIELD,UPPER (WITH AIR CONDITIONER)	1	61316-
10	BW022349	· SHIELD,LOWER	1	61316-
11	BW061459	· BOLT	4	61316-
12	BW063344	· WASHER	8	61316-
13	BW063036	· NUT	4	61316-
14	BW351192	· BRACKET	8	61316-
15	BW061455	· BOLT	8	61316-
16	BW057472	· RIVET	4	61316-
17	BW061476	· BOLT	2	61316-

**HA250-1 S/N 60636-UP
@@Q36616**



Ref. 1105

Page 030040

**HA250-1 S/N 60636-UP
ENGINE WATER COOLING SYSTEM**


Item	Part No.	Part Name	Qty	Serial No.
1	(BW251234)	RADIATOR ASS'Y,(SEE FIG.1101)	1	60636-
2	BW065023	CLAMP	6	60636-
3	BW046295	HOSE	1	61469-
	BW033646	HOSE	1	60636-61468
4	BW251125	TUBE	1	60636-
5	BW046297	HOSE	1	61469-
	BW033647	HOSE	1	60636-61468
6	BW033645	HOSE	1	60636-
7	BW065005	CLAMP	1	60636-
8	BW061456	BOLT	1	60636-
9	BW063036	NUT	1	60636-
11	(BW051589)	TANK,EXPANSION (SEE FIG.1107)	1	60636-
12	BW065023	CLAMP	1	60636-
13	BW051599	PLUG	1	60636-
14	BW065029	CLAMP	4	60636-
15	BW046296	HOSE	1	61649-
	BW033644	HOSE	1	60636-61648
16	BW045167	BRACKET	1	60636-
17	BW061456	BOLT	2	60636-
18	BW065012	CLAMP	3	60636-
19	BW063036	NUT	2	60636-
20	BW065034	CLAMP	2	60636-
21	BW033640	HOSE	1	60636-
22	BW022204	TUBE	1	60636-
23	BW065034	CLAMP	2	60636-
25	☆	HOUSING,THERMOSTAT (SEE ENG. FIG.0171)	1	60636-
26	BW054180	ADJUSTER	1	60636-
27	BW041336	NIPPLE	1	60636-
28	BW065025	CLAMP	2	60636-

HA250-1 S/N 60636-UP
ENGINE WATER COOLING SYSTEM

Item	Part No.	Part Name	Qty	Serial No.
31	BW065025	CLAMP	2	60636-
32	☆	CONNECTOR,(SEE ENG. FIG.0501)	1	60636-
33	BW065035	CLAMP	2	60636-
34	BW033756	HOSE	1	60636-
35	BW021907	TUBE	1	60636-
36	BW061484	BOLT	3	60636-
38	BW251233	HOSE	1	60636-
39	BW065034	CLAMP	2	60636-
40	(BW152139)	OIL COOLER,(SEE FIG.2301 OR 2671,2971)	1	60636-
41	BW065034	CLAMP	2	60636-
42	BW151715	HOSE	1	60636-
43	BW033651	TUBE	1	60636-
44	BW051102	COCK,DRAIN	1	60636-
45	BW065034	CLAMP	2	60636-
46	BW251344	HOSE	1	60636-
47	BW051595	PLUG	1	60636-
48	BW046268	HOSE	1	61469-
	BW051594	HOSE	1	60636-61468
49	BW045056	HOSE	1	60636-
50	BW151717	BEND,RUBBER	1	60636-
51	BW033706	PIPE	1	60636-
57	BW046280	HOSE	1	61469-
	BW051318	HOSE	1	60636-61468
58	BW065025	CLAMP	1	60636-
60	BW045752	BRACKET	1	60636-
61	BW063348	WASHER	1	60636-
62	BW061485	BOLT	1	60636-
63	BW065005	CLAMP	1	60636-
64	BW061456	BOLT	1	60636-
65	BW063036	NUT	1	60636-
70	BW033536	BRACKET	1	60636-
71	BW063348	WASHER	1	60636-
72	BW065006	CLAMP	1	60636-
73	BW061456	BOLT	1	60636-
74	BW063036	NUT	1	60636-
80	BW046302	HOSE	1	61649-
	BW033648	HOSE	1	60636-61648
81	BW033536	BRACKET	1	60636-
82	BW045514	BRACKET	1	60636-
83	BW045752	BRACKET	1	60636-
84	BW061485	BOLT	1	60636-
85	BW065011	CLAMP	1	60636-
86	BW063348	WASHER	3	60636-
87	BW065017	CLAMP	5	60636-
88	BW061456	BOLT	3	60636-
89	BW063036	NUT	3	60636-
90	BW046298	HOSE	1	61469-
	BW033649	HOSE	1	60636-61468
91	BW045167	BRACKET	1	60636-
92	BW063348	WASHER	1	60636-
93	BW061484	BOLT	1	60636-
94	BW065017	CLAMP	5	60636-
95	BW061456	BOLT	8	60636-
96	BW063036	NUT	8	60636-

HA250-1 S/N 60636-UP

@@Q36617




Ref. 1107

Page 030050

HA250-1 S/N 60636-UP
ENGINE WATER EXPANSION TANK

Item	Part No.	Part Name	Qty	Serial No.
1	BW051589	TANK,EXPANSION	1	60636-
2	BW051592	CAP	1	60636-
3	BW051591	PLATE	1	60636-
4	BW034087	BRACKET	1	60969-
	BW033610	BRACKET	1	60636-60968
5	BW051598	BUSHING,RUBBER	2	60636-
6	BW051593	SPACER	2	60636-
7	BW061485	BOLT	4	60636-
8	BW060464	BOLT	2	60636-
9	BW063038	NUT	2	60636-

HA250-1 S/N 60636-UP
 @@Q36618




Ref. 1201

Page 030060

HA250-1 S/N 60636-UP
 ENGINE MOUNTING PARTS

Item	Part No.	Part Name	Qty	Serial No.
1	BW033457	BRACKET,FRONT	1	60636-
2	BW060528	BOLT	2	60636-
4	BW063043	NUT	2	60636-
5	BW021857	BRACKET,REAR, R.H.	1	60636-
6	BW021856	BRACKET,REAR, L.H.	1	60636-
8	BW061517	BOLT	4	60636-
9	BW060552	BOLT	4	60636-
10	BW063395	WASHER	4	60636-
11	BW057410	WASHER	4	60636-
12	BW057447	BEARING,CONICAL	4	60636-
14	BW057409	WASHER	4	60636-
15	BW063044	NUT	4	60636-
16	BW061497	BOLT	12	60636-
17	BW063040	NUT	12	60636-

HA250-1 S/N 60636-UP
 @@Q36619



Ref. 1301

Page 030070


HA250-1 S/N 60636-UP
 FUEL OIL TANK

Item	Part No.	Part Name	Qty	Serial No.
1	BW000380	TANK,FUEL	1	61214-
	BW000300	TANK,FUEL	1	60636-61213
2	BW061503	BOLT	2	61097-
3	BW063391	WASHER	2	61097-
3A	BW045765	SLEEVE	2	61097-
4	BW061516	BOLT	1	60636-
5	BW063393	WASHER	1	60636-
6	BW033210	LOCK	1	60636-
7	BW044710	PIN	1	60636-
8	BW057243	PLUG,DRAIN	3	60636-61213
8A	BW055546	RING,SEAL	1	60636-61213
9	BW033683	FLANGE	1	60636-
10	BW053499	O-RING	1	60901-
11	BW061484	BOLT	4	60636-
13	BW043466	CAP ASS'Y	1	60636-
14	☆	· CAP	1	60636-
16	BW057262	· GASKET	1	60636-
17	BW043403	· PLATE	1	60636-
18	BW061474	· BOLT	1	60636-
20	BW065023	CLAMP	4	60636-
21	BW046270	TUBE	1	60636-
	(☒BW033609)	TUBE	1	(60636-61468)
22	BW046269	TUBE	1	60636-
	(☒BW033608)	TUBE	1	(60636-61468)
40	BW055073	GAUGE,OIL LEVEL	1	60901-
43	BW045167	BRACKET	3	60636-
44	BW065006	CLAMP	7	60636-
45	BW061456	BOLT	7	60636-
46	BW063036	NUT	7	60636-

HA250-1 S/N 60636-UP
FUEL OIL TANK

Item	Part No.	Part Name	Qty	Serial No.
47	BW063348	WASHER	3	60969-
50	BW066866	RING,SEAL	3	61214-
51	BW065786	CONNECTOR	1	61214-
52	BW055348	COCK,DRAIN	1	61214-
53	BW065494	PLUG	1	61214-
60	BW046073	SEAL,NOISE REDUCTION	1	61372-
61	BW046074	SEAL,NOISE REDUCTION	1	61372-

HA250-1 S/N 60636-UP
 @@Q36620



Ref. 1401

Page 030080


HA250-1 S/N 60636-UP
 ENGINE CONTROL(#60636-61169)

Item	Part No.	Part Name	Qty	Serial No.
1	BW051202	CABLE,ENGINE STOP	1	60636-61169
2	BW063350	WASHER	1	60636-61169
3	BW066322	GROMMET	1	60636-61169
4	BW033639	BRACKET	1	60636-61169
5	BW061472	SCREW	2	60636-61169
6	BW051300	NUT	2	60636-61169
7	BW045122	LEVER,ENGINE STOP	1	60636-61169
9	BW051294	STOPPER	1	60636-61169
10	BW062159	BOLT	1	60636-61169
11	BW063102	NUT	1	60636-61169
15	BW051267	PEDAL,ACCELERATOR	1	60636-61169
16	BW051261	PIN,CLEVIS	1	60636-61169
17	BW066778	PIN,COTTER	1	60636-61169
18	BW051264	BELLOWS,RUBBER	1	60636-61169
19	BW062162	SCREW	2	60636-61169
20	BW051262	ROD	1	60636-61169
21	BW063101	NUT	1	60636-61169
22	BW052089	YOKE,JOINT (WITH PIN)	1	60636-61169
23	BW045528	PLATE	1	60636-61169
24	BW057160	CLIP	2	60636-61169
25	BW033535	SHAFT	1	60717-61169
	BW033618	SHAFT	1	60636-60716
26	BW066532	BUSHING	2	60636-61169
27	BW040926	WASHER	2	60636-61169
28	BW033534	BRACKET	1	60636-61169
29	BW061476	BOLT	2	60636-61169
30	BW063345	WASHER	2	60636-61169
31	BW063098	NUT	2	60636-61169
32	BW061503	BOLT	1	60636-61169

HA250-1 S/N 60636-UP
ENGINE CONTROL(#60636-61169)

Item	Part No.	Part Name	Qty	Serial No.
33	BW063102	NUT	1	60636-61169
34	BW051270	JOINT,BALL	2	60636-61169
35	BW051271	PLUG	2	60636-61169
37	BW063098	NUT	2	60636-61169
38	BW044892	ROD	1	60636-61169
39	BW041155	SPRING	1	60636-61169
40	BW051272	STUD,BALL	2	60636-61169
41	BW033742	BRACKET	1	60636-61169

**HA250-1 S/N 60636-UP
@@Q36621**



Ref. 1451

Page 030090


**HA250-1 S/N 60636-UP
ENGINE CONTROL(#61170-)**

Item	Part No.	Part Name	Qty	Serial No.
1	BW351158	CABLE,ENGINE STOP	1	61170-
2	BW351155	KNOB,ENGINE STOP	1	61170-
3	BW044834	BRACKET	1	61170-
4	BW061160	BOLT	4	61170-
5	BW063035	NUT	4	61170-
6	BW066322	GROMMET	1	61170-
7	BW045916	BRACKET	1	61170-
8	BW045122	LEVER,ENGINE STOP	1	61170-
9	BW051294	STOPPER	1	61170-
10	BW062159	BOLT	1	61170-
12	BW045914	PEDAL,ACCELERATOR	1	61170-
12A	☆	PLATE,FLOOR (SEE FIG.7401)	1	61170-
13	BW351252	CUSHION,RUBBER	1	61170-
14	BW061481	BOLT	1	61170-
15	BW063100	NUT	1	61170-
16	BW061459	BOLT	3	61170-
17	BW063036	NUT	3	61170-
18	BW034220	BRACKET	1	61170-
18A	BW056286	SWITCH,EXHAUST BRAKE	1	61170-
19	BW034221	PLATE	1	61170-
20	BW061454	BOLT	2	61170-
21	BW351153	CABLE,ACCELERATOR	1	61170-
22	BW351154	YOKE,JOINT (WITH PIN)	1	61170-
23	BW034218	BRACKET	1	61170-
24	BW061485	BOLT	2	61170-
26	BW351169	SPRING	1	61170-
27	BW351156	CABLE,ACCELERATOR (HAND CONTROL)	1	61170-
28	BW066322	GROMMET	1	61170-
29	BW034225	LEVER,ENGINE CONTROL	1	61170-

HA250-1 S/N 60636-UP
ENGINE CONTROL(#61170-)

Item	Part No.	Part Name	Qty	Serial No.
30	BW351194	PUSH ROD KIT	1	61170-
31	BW351196	LEVER KIT,HAND CONTROL	1	61170-
32	BW351197	ASSEMBLY KIT,ENGINE CONTROL	1	61170-
33	BW351195	ASSEMBLY KIT,ACCELERATOR	1	61170-

HA250-1 S/N 60636-UP
 @@Q36622



Ref. 1501

Page 030100


HA250-1 S/N 60636-UP
 ENGINE AIR INTAKE SYSTEM

Item	Part No.	Part Name	Qty	Serial No.
1	BW151568	COVER	1	60636-
2	BW065040	CLAMP	1	60636-
3	BW044904	CLAMP	1	60636-
4	BW021882	BRACKET	1	60636-
5	BW063346	WASHER	2	60636-
6	BW063038	NUT	2	60636-
7	BW061478	BOLT	2	60636-
8	BW063346	WASHER	2	60636-
9	BW063038	NUT	2	60636-
10	BW351114	PIPE	1	60636-
11	BW065040	CLAMP	1	60636-
12	BW057436	COUPLING,RUBBER	1	60636-
13	BW065040	CLAMP	1	60636-
14	BW151447	CLAMP	2	60636-
15	BW063039	NUT	4	60636-
15A	BW063348	WASHER	4	60636-
16	BW061487	BOLT	4	60636-
17	BW065040	CLAMP	1	60636-
18	BW057404	CONNECTOR,RUBBER	1	60636-
19	BW065038	CLAMP	1	60636-
20	BW022023	ELBOW	1	60636-
21	BW061484	BOLT	2	60636-
22	BW046303	HOSE	1	61469-
	BW033650	HOSE	1	60636-61468
23	BW065038	CLAMP	2	60636-
24	BW011273	ELBOW	1	60726-
	BW021911	ELBOW	1	60636-60725
25	BW251340	PLUG	1	60726-
26	BW033630	BRACKET	1	60636-

**HA250-1 S/N 60636-UP
ENGINE AIR INTAKE SYSTEM**

Item	Part No.	Part Name	Qty	Serial No.
28	BW061492	BOLT	2	60636-
29	BW065037	CLAMP	1	60636-
30	BW046306	HOSE	1	61469-
	BW033629	HOSE	1	60636-61468
31	BW065037	CLAMP	1	60636-
32	BW045772	BRACKET	1	60969-
	BW045147	BRACKET	1	60636-60968
33	BW044259	RUBBER	1	60636-
34	BW065037	CLAMP	1	60636-
35	BW061485	BOLT	1	60636-
41	BW251326	NIPPLE	1	60636-
42	BW066314	GROMMET	1	60636-
43	BW045602	HOSE	1	60636-
47	BW051527	METER,VACUUM	1	60636-
50	BW151446	AIR CLEANER ASS'Y	1	60636-
51	☆	· HOUSING	1	60636-
52	BW151570	· ELEMENT,INNER	1	60636-
53	BW051154	· WASHER	1	60636-
54	BW351108	· NUT,WING	1	60636-
55	BW151571	· ELEMENT,OUTER	1	60636-
56	BW051154	· WASHER	1	60636-
57	BW351108	· NUT,WING	1	60636-
58	BW351111	· COVER	1	60636-
59	BW351110	· CLAMP	1	60636-
60	BW351109	· O-RING	1	60636-
61	BW151576	· COVER	1	60636-
62	BW151572	· VALVE	1	60636-
65	BW045753	RUBBER	1	60969-
66	BW065036	CLAMP	2	60636-

HA250-1 S/N 60636-UP
 @@Q36623



Ref. 1511

Page 030110


HA250-1 S/N 60636-UP
 ENGINE EXHAUST SYSTEM

Item	Part No.	Part Name	Qty	Serial No.
1	BW021879	PIPE	1	60636-
	BW021933	PIPE,(FOR GERMANY)	1	60636-
	BW057482	CAP,(FOR GERMANY)	1	60636-
2	BW044918	CLAMP	1	60636-
3	BW033546	BRACKET	1	60636-
	BW033852	BRACKET,(FOR GERMANY)	1	60636-
4	BW051576	CUSHION	1	60636-
5	BW063388	WASHER	2	60636-
6	BW063038	NUT	2	60636-
7	BW063346	WASHER	2	60636-
8	BW063100	NUT	2	60636-
9	BW151443	CLAMP	2	60636-
10	BW051522	COVER	1	60636-
11	BW051521	HANDLE	1	60636-
12	BW051524	CLAMP,(WITH NUT)	1	60636-
13	BW063390	WASHER	2	60636-
14	BW051520	CLAMP	1	60636-
15	BW033533	PIPE	1	60636-
16	BW051513	CLAMP	2	60636-
17	BW044909	HOSE,FLEXIBLE	1	60636-
18	BW044908	PIPE	1	60636-
19	BW051368	MUFFLER	1	60636-
20	BW051576	CUSHION	4	60636-
21	BW063346	WASHER	8	60636-
22	BW063100	NUT	8	60636-
23	BW051359	CLAMP	1	60636-
24	BW032072	PIPE	1	60636-
25	BW051570	GASKET	1	60636-
33	BW054194	CLAMP	2	60636-

HA250-1 S/N 60636-UP
ENGINE EXHAUST SYSTEM

Item	Part No.	Part Name	Qty	Serial No.
35	BW044910	HOSE,FLEXIBLE	1	60636-
36	BW051513	CLAMP	2	60636-
37	BW021894	PIPE	1	60636-
38	BW060495	BOLT	4	60636-
39	BW044979	STAY	1	60636-
40	BW060468	BOLT	2	60636-
41	BW063390	WASHER	4	60636-
42	BW063101	NUT	2	60636-
43	BW021893	PIPE	1	60636-
46	BW022050	COVER	1	60881-
49	BW043840	BRACKET	2	60881-
50	BW061459	BOLT	2	60881-
51	BW063344	WASHER	2	60881-
52	BW063036	NUT	2	60881-
53	BW063100	NUT	2	60881-
54	BW063038	NUT	2	60881-

HA250-1 S/N 60636-UP
 @@Q36624



Ref. 2001


Page 060010

HA250-1 S/N 60636-UP
TORQUE CONVERTER CASE (T/M NO.4644 026 011)(#60636-61999)

Item	Part No.	Part Name	Qty	Serial No.
10	BW152143	CASE,TORQUE CONVERTER	1	60636-61999
30	BW152200	BOLT	14	60636-61999
40	BW060711	PIN,SPRING	2	60636-61999
44	BW060725	PIN,SPRING	2	60636-61999
60	BW152026	COVER	1	60636-61999
110	BW152027	BEARING	1	60636-61999
130	BW052523	RING,SNAP	1	60636-61999
160	BW152028	FLANGE	1	60636-61999
180	BW052526	HOLDER	1	60636-61999
190	BW052527	PLATE	1	60636-61999
200	BW052528	BOLT	2	60636-61999
210	BW053266	BOLT	8	60636-61999
220	BW060479	BOLT	12	60636-61999
240	BW063101	NUT	12	60636-61999

HA250-1 S/N 60636-UP
 @@Q36625

To Fig. 2191 →



Ref. 2011


Page 060020

HA250-1 S/N 60636-UP
 TORQUE CONVERTER (T/M NO.4644 026 011)(#60636-61999)

Item	Part No.	Part Name	Qty	Serial No.
	BW152146	TORQUE CONVERTER A.	1	60636-61999
10	BW152029	· COVER	1	60636-61999
60	BW152198	· BOLT	24	60636-61999
65	BW060453	· BOLT	12	60636-61999
70	BW152340	· WASHER	36	60636-61999
75	BW063100	· NUT	12	60636-61999
80	BW052531	· GASKET	1	60636-61999
90	BW052532	· PLATE,PISTON	1	60636-61999
100	BW052533	· RING	1	60636-61999
110	BW052534	· RING	1	60636-61999
120	BW052535	· DISC,INNER	1	60636-61999
130	BW052536	· DISC,OUTER	3	60636-61999
140	BW052537	· ROLLER	12	60636-61999
150	BW052538	· PLATE,BACK-UP	1	60636-61999
160	BW052539	· BOLT	12	60636-61999
170	BW052540	· RING,SPRING	1	60636-61999
180	BW152923	· SHIM ASS'Y	1	60636-61999
	☆	· · SHIM, 2.6MM	1	60636-61999
	☆	· · SHIM, 2.7MM	1	60636-61999
	☆	· · SHIM, 3.1MM	1	60636-61999
	☆	· · SHIM, 3.2MM	1	60636-61999
	☆	· · SHIM, 3.4MM	1	60636-61999
190	BW052542	· RING,SNAP	1	60636-61999
200	BW052543	· HUB,TURBINE	1	60636-61999
210	BW061475	· BOLT	16	60636-61999
220	BW152340	· WASHER	16	60636-61999
230	BW052544	· SEAL,OIL	1	60636-61999
240	BW052545	· BEARING	1	60636-61999
250	BW052546	· SHIM, 1.0MM	2	60636-61999

HA250-1 S/N 60636-UP
TORQUE CONVERTER (T/M NO.4644 026 011)(#60636-61999)


Item	Part No.	Part Name	Qty	Serial No.
260	BW052547	· SHIM, 0.1MM,0.1MM	1	60636-61999
	BW152219	· SHIM, 0.2MM,0.2MM	1	60636-61999
	BW152220	· SHIM, 0.5MM,0.5MM	1	60636-61999
270	BW052548	· SPACER	2	60636-61999
280	BW052549	· PLATE	2	60636-61999
290	BW052550	· CAGE,NEEDLE	1	60636-61999
300	BW152030	· CAGE,ROLLER	1	60636-61999
310	BW052552	· RING,SNAP	1	60636-61999
320	BW052553	· FLANGE	1	60636-61999
330	BW052554	· GASKET	1	60636-61999
340	BW061475	· BOLT	12	60636-61999
350	BW152340	· WASHER	12	60636-61999
360	BW052013	· O-RING	1	60636-61999
500	BW152144	· WHEEL,PUMP	1	60636-61999
510	BW152110	· WHEEL,TURBINE	1	60636-61999
520	BW152145	· STATOR	1	60636-61999
600	BW052558	· RANGE,FLYWHEEL	1	60636-61999
610	BW052559	· ROLLER	28	60636-61999
620	BW052560	· CAP,SPRING	28	60636-61999
630	BW052561	· SPRING	28	60636-61999
640	BW052562	· ROLLER	28	60636-61999
650	BW052563	· WASHER,THRUST	2	60636-61999
660	BW052564	· BEARING	2	60636-61999
670	BW052565	· RACE,FLYWHEEL	1	60636-61999



HA250-1 S/N 60636-UP
TRANSMISSION CASE (T/M NO.4644 026 011)(#60636-61999)

Item	Part No.	Part Name	Qty	Serial No.
10	BW052566	HOUSING,TRANSMISSION	1	60636-61999
30	BW052568	PLUG	1	60636-61999
40	☆	PLATE, NAME	1	60636-61999
50	BW052570	PIN,GROOVE	4	60636-61999
60	BW052571	SOCKET,TRANSMISSION OIL TEMPERATURE	1	60636-61999
70	BW052572	O-RING	1	60636-61999
80	BW052574	PLATE	1	60636-61999
90	BW052573	COVER	1	60636-61999
100	BW061474	BOLT	3	60636-61999
110	BW152340	WASHER	3	60636-61999
120	BW052575	CAP,END	2	60636-61999
140	BW052576	O-RING	1	60636-61999
150	BW252026	PLUG	1	60636-61999
320	BW052580	O-RING	1	60636-61999
330	BW052581	PLUG	1	60636-61999
370	BW152031	COVER	1	60636-61999
450	BW052583	PLUG	1	60636-61999
460	BW052584	O-RING	1	60636-61999
530	BW052585	BREATHER	1	60636-61999
760	BW152032	COVER	1	60636-61999

HA250-1 S/N 60636-UP
 @@Q36627




Ref. 2111

Page 060040

HA250-1 S/N 60636-UP
TRANSMISSION CONTROL VALVE (T/M NO.4644 026 011)(#60636-61999)

Item	Part No.	Part Name	Qty	Serial No.
10	BW052603	PLATE,VALVE	1	60636-61999
20	BW052604	GASKET	1	60636-61999
24	BW152114	GASKET	1	60636-61999
30	BW152037	PLATE,VALVE	1	60636-61999
50	BW152038	ORIFICE	1	60636-61999
60	BW052608	BALL	2	60636-61999
70	BW052609	SPRING	2	60636-61999
80	BW152891	BOLT	3	60636-61999
100	BW152039	BOLT	3	60636-61999
120	BW152040	BOLT	6	60636-61999
140	BW152041	PLATE,VALVE	1	60636-61999
150	BW052612	GASKET	1	60636-61999
154	BW152115	GASKET	1	60636-61999
160	BW152039	BOLT	10	60636-61999
180	BW152042	BOLT	6	60636-61999
260	BW052613	PLUG	1	60636-61999
270	BW052614	O-RING	1	60636-61999
280	BW152043	PLUG	1	60636-61999
350	BW056035	SENSOR,TRANSMISSION OIL PRESSURE	1	60636-61999
360	BW052614	O-RING	1	60636-61999

**HA250-1 S/N 60636-UP
@@Q36628**



Ref. 2113

Page 060050

**HA250-1 S/N 60636-UP
TRANSMISSION CONTROL VALVE AND ELECTRICAL (T/M NO.4644 026
011)(#60636-61999)**


Item	Part No.	Part Name	Qty	Serial No.
	BW152986	CONTROL ASS'Y,SHIFT	1	60636-61999
10	BW152154	· BODY,VALVE	1	60636-61999
20	BW052618	· DETENT	1	60636-61999
30	BW152045	· SPRING	1	60636-61999
40	BW152046	· SPOOL	1	60636-61999
50	BW052621	· SPRING	1	60636-61999
60	BW152193	· SPACER,0.5MM	1	60636-61999
	BW152273	· SPACER,1.0MM	1	60636-61999
	BW152274	· SPACER,2.0MM	1	60636-61999
	BW152275	· SPACER,3.0MM	1	60636-61999
	BW152276	· SPACER,5.0MM	1	60636-61999
70	BW152194	· SHIM	1	60636-61999
80	BW152047	· SLEEVE	1	60636-61999
84	BW060707	· PIN,SPRING	1	60636-61999
90	BW052624	· PISTON	1	60636-61999
100	BW052623	· SPRING	1	60636-61999
110	BW052625	· DETENT	1	60636-61999
120	BW052626	· O-RING	1	60636-61999
130	BW052627	· PISTON	1	60636-61999
140	BW152301	· SPRING	1	60636-61999
150	BW052629	· SPOOL	1	60636-61999
160	BW052630	· DETENT	1	60636-61999
170	BW052631	· DETENT	1	60636-61999
180	BW052632	· PISTON	1	60636-61999
184	BW152194	· SHIM	1	60636-61999
190	BW052633	· SPRING	1	60636-61999
200	BW052623	· SPRING	1	60636-61999
210	BW052634	· PISTON	1	60636-61999

Reference:2113

Page:060050

HA250-1 S/N 60636-UP
TRANSMISSION CONTROL VALVE AND ELECTRICAL (T/M NO.4644 026
011)(#60636-61999)

Item	Part No.	Part Name	Qty	Serial No.
220	BW052625	· DETENT	1	60636-61999
230	BW052626	· O-RING	1	60636-61999
240	BW052635	· DETENT	1	60636-61999
250	BW052630	· DETENT	1	60636-61999
260	BW052623	· SPRING	1	60636-61999
270	BW052636	· PISTON	1	60636-61999
280	BW052623	· SPRING	1	60636-61999
290	BW052637	· PISTON	1	60636-61999
300	BW052625	· DETENT	1	60636-61999
310	BW052626	· O-RING	1	60636-61999
350	BW052640	· VALVE,SOLENOID	4	60636-61999
355	BW152764	· O-RING	4	60636-61999
358	BW152765	· O-RING	4	60636-61999
360	BW152892	· BOLT	8	60636-61999
370	BW152162	· WASHER,SPRING	8	60636-61999
380	BW052641	· WIRING HARNESS,TRANSMISSION CONTROL	1	60636-61999
400	BW152048	· BOLT	4	60636-61999
410	BW152651	· WASHER,SPRING	4	60636-61999
460	BW052644	· COVER	1	60636-61999
470	BW052645	· O-RING	1	60636-61999
480	BW052646	· CLAMP	1	60636-61999
490	BW052613	· PLUG	10	60636-61999
500	BW052614	· O-RING	10	60636-61999
560	BW152970	· HOUSING,VALVE	1	60636-61999
580	BW152156	· BALL	1	60636-61999
590	BW152157	· BALL	1	60636-61999
600	BW152158	· BALL	1	60636-61999
610	BW152159	· PISTON	1	60636-61999
620	BW152187	· SPRING	1	60636-61999
630	BW152188	· PLUG	1	60636-61999
640	BW152160	· O-RING	1	60636-61999
650	BW252259	· VALVE	1	60636-61999
660	BW152161	· O-RING	1	60636-61999
670	BW152892	· BOLT	2	60636-61999
680	BW152162	· WASHER,SPRING	2	60636-61999
690	BW152163	· GASKET	1	60636-61999
700	BW152893	· BOLT	11	60636-61999




HA250-1 S/N 60636-UP

TRANSMISSION SHIFT CONTROLER (T/M NO.4644 026 011)(#60636-61999)

Item	Part No.	Part Name	Qty	Serial No.
1	BW152900	SELECTOR,GEAR	1	61120-61999
	BW152767	SELECTOR,GEAR	1	60911-61119
	BW152133	SELECTOR,GEAR	1	60636-60910
	BW152901	SELECTOR,GEAR (FOR SWEEDEN)	1	60636-61999
2	BW044407	PLATE	2	60636-61999
3	BW061474	BOLT	2	60636-61999
4	BW063260	WASHER	2	60636-61999
5	BW152759	MODULE	1	60636-61999
6	BW062178	BOLT	3	60636-61999
7	BW063343	WASHER	3	60636-61999
8	BW063097	NUT	3	60636-61999

HA250-1 S/N 60636-UP
 @@Q36630



Ref. 2121

Page 060070

HA250-1 S/N 60636-UP
PRESSURE REGULATOR VALVE (T/M NO.4644 026 011)(#60636-61999)

Item	Part No.	Part Name	Qty	Serial No.
80	(BW152151)	FLANGE,(SEE FIG.2191)	1	60636-61999
180	(BW052713)	GASKET,(SEE FIG.2191)	1	60636-61999
184	(BW052714)	GEAR PUMP,(SEE FIG.2191)	1	60636-61999
710	BW052650	BALL	1	60636-61999
720	BW052651	SPRING	1	60636-61999
730	BW052652	SLEEVE,VALVE	1	60636-61999
740	BW052653	PISTON	1	60636-61999
750	BW052654	SPRING	1	60636-61999
760	BW052655	WASHER	1	60636-61999
770	BW052656	RING,RETAINER	1	60636-61999
780	BW152049	PIN	1	60636-61999
790	BW052657	RING,RETAINER	1	60636-61999



Download the full PDF manual instantly.

Our customer service e-mail:

aservicemanualpdf@yahoo.com