


**HA270-1 S/N 65226-UP**  
**HA270-1 S/N 65226-UP**

Item	Part Name
	S6D125-1B8-FA S/N 10001-UP
10	ENGINE RELATED PARTS AND COOLING SYSTEM
20	TORQUE CONVERTER AND TRANSMISSION
30	DRIVE SHAFT?DIFFERENTIAL?WHEELS AND BRAKES
40	AIR PRESSURE SYSTEM
50	HYDRAULIC SYSTEM
60	ELECTRICAL SYSTEM
70	FRONT VEHICLE AND CAB
80	REAR VEHICLE
90	TOOL AND OTHERS

**HA270-1 S/N 65226-UP**  
**ENGINE RELATED PARTS AND COOLING SYSTEM**

Item	Part Name	Qty
10	DAMPER?ENGINE FLYWHEEL	1
20	RADIATOR	1
30	ENGINE?FAN PROTECTOR(#65831-)	1
40	ENGINE WATER COOLING SYSTEM	1
50	ENGINE WATER EXPANSION TANK	1
60	ENGINE MOUNTING PARTS	1
70	FUEL OIL TANK	1
80	ENGINE CONTROL(#65226-65660)	1
90	ENGINE CONTROL(#65661-)	1
100	ENGINE AIR INTAKE SYSTEM	1
110	ENGINE EXHAUST SYSTEM	1

HA270-1 S/N 65226-UP  
 @@Q37090




Ref. 1001

Page 030010

HA270-1 S/N 65226-UP  
 DAMPER?ENGINE FLYWHEEL

Item	Part No.	Part Name	Qty	Serial No.
40	BW053593	COUPLING ASS'Y,RUBBER	1	65226-
41	BW053266	· BOLT	8	65226-
42	BW063266	· WASHER	8	65226-
43	BW053597	· HOUSING	1	65226-
44	BW053594	· RING, FRICTION	1	65226-
45	BW053598	· HUB	1	65226-
46	BW053595	· RING, FRICTION	1	65226-
47	BW053596	· DAMPER ASS'Y	1	65226-
48	BW061279	· BOLT	8	65226-
49	BW063352	· WASHER	8	65226-
50	BW153020	· BOLT	8	65226-
51	BW063348	· WASHER	8	65226-

**HA270-1 S/N 65226-UP  
@@Q37091**




Ref. 1101

Page 030020

**HA270-1 S/N 65226-UP  
RADIATOR**

Item	Part No.	Part Name	Qty	Serial No.
1	BW251234	RADIATOR ASS'Y	1	65226-
2	BW251323	· RADIATOR	1	65226-
3	BW251324	· SHROUD,FAN	1	65226-
4	BW061472	· SCREW	8	65226-
5	BW034042	STAY	2	65432-
	■BW033417	STAY (BW034212,BW045766)	2	65226-65431
5	BW034095	STAY,L.H. (WITH AIR CONDITIONER)	1	65432-
	■BW033713	STAY,L.H. (WITH AIR CONDITIONER) (BW034095,BW045766)	1	65226-65431
5	BW034212	STAY,R.H. (WITH AIR CONDITIONER)	1	65663-
	■BW033417	STAY,R.H. (WITH AIR CONDITIONER) (BW034212,BW045766)	1	65226-65662
6	BW061487	BOLT	2	65226-
7	BW061489	BOLT	2	65226-
8	BW063039	NUT	2	65226-
9	BW063348	WASHER	8	65226-
10	BW045766	SLEEVE	2	65432-
11	BW151975	CUSHION,RUBBER	2	65226-
12	BW063391	WASHER	2	65226-
13	BW060483	BOLT	2	65226-
15	BW011563	COVER,FAN SHROUD	1	65706-
16	BW045978	GASKET	1	65706-
17	BW045979	GASKET	2	65706-

HA270-1 S/N 65226-UP  
 @@Q37092




Ref. 1103

Page 030030

HA270-1 S/N 65226-UP  
 ENGINE?FAN PROTECTOR(#65831-)

Item	Part No.	Part Name	Qty	Serial No.
	BW034331	PROTECTOR ASS'Y,FAN	1	65831-
	BW034332	PROTECTOR ASS'Y,FAN (WITH AIR CONDITIONER)	1	65831-
1	BW011559	· NET,WIRE	2	65831-
2	BW061462	· BOLT	4	65831-
3	BW063386	· WASHER	8	65831-
4	BW063036	· NUT	4	65831-
5	BW034291	· BRACKET	1	65831-
6	BW034292	· BRACKET	2	65831-
7	BW061490	· BOLT	1	65831-
8	BW060476	· BOLT	1	65831-
9	BW022347	· SHIELD,UPPER	1	65831-
	BW022348	· SHIELD,UPPER (WITH AIR CONDITIONER)	1	65831-
10	BW022349	· SHIELD,LOWER	1	65831-
11	BW061459	· BOLT	4	65831-
12	BW063344	· WASHER	8	65831-
13	BW063036	· NUT	4	65831-
14	BW351192	· BRACKET	8	65831-
15	BW061455	· BOLT	8	65831-
16	BW057472	· RIVET	4	65831-
17	BW061476	· BOLT	2	65831-

**HA270-1 S/N 65226-UP  
@@Q37093**



Ref. 1105

Page 030040

**HA270-1 S/N 65226-UP  
ENGINE WATER COOLING SYSTEM**


Item	Part No.	Part Name	Qty	Serial No.
1	(BW251234)	RADIATOR ASS'Y,(SEE FIG.1101)	1	65226-
2	BW065023	CLAMP	6	65226-
3	BW046295	HOSE	1	65901-
	BW033646	HOSE	1	65226-65900
4	BW251125	TUBE	1	65226-
5	BW046297	HOSE	1	65901-
	BW033647	HOSE	1	65226-65900
6	BW033645	HOSE	1	65226-
7	BW065005	CLAMP	1	65226-
8	BW061456	BOLT	1	65226-
9	BW063036	NUT	1	65226-
11	(BW051589)	TANK,EXPANSION (SEE FIG.1107)	1	65226-
12	BW065023	CLAMP	1	65226-
13	BW051599	PLUG	1	65226-
14	BW065029	CLAMP	4	65226-
15	BW046296	HOSE	1	65901-
	BW033644	HOSE	1	65226-65900
16	BW045167	BRACKET	1	65226-
17	BW061456	BOLT	2	65226-
18	BW065012	CLAMP	3	65226-
19	BW063036	NUT	2	65226-
20	BW065034	CLAMP	2	65226-
21	BW033640	HOSE	1	65226-
22	BW022204	TUBE	1	65226-
23	BW065034	CLAMP	2	65226-
25	☆	HOUSING,THERMOSTAT (SEE ENG. FIG.0171)	1	65226-
26	BW054180	ADJUSTER	1	65226-
27	BW041336	NIPPLE	1	65226-
28	BW065025	CLAMP	2	65226-

**HA270-1 S/N 65226-UP**  
**ENGINE WATER COOLING SYSTEM**

Item	Part No.	Part Name	Qty	Serial No.
31	BW065025	CLAMP	2	65226-
32	☆	CONNECTOR,(SEE ENG. FIG.0501)	1	65226-
33	BW065035	CLAMP	2	65226-
34	BW033756	HOSE	1	65226-
35	BW021907	TUBE	1	65226-
36	BW061484	BOLT	3	65226-
38	BW251233	HOSE	1	65226-
39	BW065034	CLAMP	2	65226-
40	(BW152139)	OIL COOLER,(SEE FIG.2301 OR 2671,2971)	1	65226-
41	BW065034	CLAMP	2	65226-
42	BW151715	HOSE	1	65226-
43	BW033651	TUBE	1	65226-
44	BW051102	COCK,DRAIN	1	65226-
45	BW065034	CLAMP	2	65226-
46	BW251344	HOSE	1	65226-
47	BW051595	PLUG	1	65226-
48	BW046268	HOSE	1	65901-
	BW051594	HOSE	1	65226-65900
49	BW045056	HOSE	1	65226-
50	BW151717	BEND,RUBBER	1	65226-
51	BW033706	PIPE	1	65226-
57	BW046280	HOSE	1	65901-
	BW051318	HOSE	1	65226-65900
58	BW065025	CLAMP	1	65226-
60	BW045752	BRACKET	1	65226-
61	BW063348	WASHER	1	65226-
62	BW061485	BOLT	1	65226-
63	BW065005	CLAMP	1	65226-
64	BW061456	BOLT	1	65226-
65	BW063036	NUT	1	65226-
70	BW033536	BRACKET	1	65226-
71	BW063348	WASHER	1	65226-
72	BW065006	CLAMP	1	65226-
73	BW061456	BOLT	1	65226-
74	BW063036	NUT	1	65226-
80	BW046302	HOSE	1	65901-
	BW033648	HOSE	1	65226-65900
81	BW033536	BRACKET	1	65226-
82	BW045514	BRACKET	1	65226-
83	BW045752	BRACKET	1	65226-
84	BW061485	BOLT	1	65226-
85	BW065011	CLAMP	1	65226-
86	BW063348	WASHER	3	65226-
87	BW065017	CLAMP	5	65226-
88	BW061456	BOLT	3	65226-
89	BW063036	NUT	3	65226-
90	BW046298	HOSE	1	65901-
	BW033649	HOSE	1	65226-65900
91	BW045167	BRACKET	1	65226-
92	BW063348	WASHER	1	65226-
93	BW061484	BOLT	1	65226-
94	BW065017	CLAMP	5	65226-
95	BW061456	BOLT	8	65226-
96	BW063036	NUT	8	65226-

HA270-1 S/N 65226-UP

@@Q37094



Ref. 1107


Page 030050

HA270-1 S/N 65226-UP  
ENGINE WATER EXPANSION TANK

Item	Part No.	Part Name	Qty	Serial No.
1	BW051589	TANK,EXPANSION	1	65226-
2	BW051592	CAP	1	65226-
3	BW051591	PLATE	1	65226-
4	BW034087	BRACKET	1	65432-
	BW033610	BRACKET	1	65226-65431
5	BW051598	BUSHING,RUBBER	2	65226-
6	BW051593	SPACER	2	65226-
7	BW061485	BOLT	4	65226-
8	BW060464	BOLT	2	65226-
9	BW063038	NUT	2	65226-



HA270-1 S/N 65226-UP  
 @@Q37095




Ref. 1201

Page 030060

HA270-1 S/N 65226-UP  
 ENGINE MOUNTING PARTS

Item	Part No.	Part Name	Qty	Serial No.
1	BW033457	BRACKET,FRONT	1	65226-
2	BW060528	BOLT	2	65226-
4	BW063043	NUT	2	65226-
5	BW021857	BRACKET,REAR, R.H.	1	65226-
6	BW021856	BRACKET,REAR, L.H.	1	65226-
8	BW061517	BOLT	4	65226-
9	BW060552	BOLT	4	65226-
10	BW063395	WASHER	4	65226-
11	BW057410	WASHER	4	65226-
12	BW057447	BEARING,CONICAL	4	65226-
14	BW057409	WASHER	4	65226-
15	BW063044	NUT	4	65226-
16	BW061497	BOLT	12	65226-
17	BW063040	NUT	12	65226-

HA270-1 S/N 65226-UP  
 @@Q37096



Ref. 1301

Page 030070


HA270-1 S/N 65226-UP  
 FUEL OIL TANK

Item	Part No.	Part Name	Qty	Serial No.
1	BW000380	TANK,FUEL	1	65706-
	BW000300	TANK,FUEL	1	65226-65705
2	BW061503	BOLT	2	65620-
3	BW063391	WASHER	2	65620-
3A	BW045765	SLEEVE	2	65620-
4	BW061516	BOLT	1	65226-
5	BW063393	WASHER	1	65226-
6	BW033210	LOCK	1	65226-
7	BW044710	PIN	1	65226-
8	BW057243	PLUG,DRAIN	3	65226-65705
8A	BW055546	RING,SEAL	1	65226-65705
9	BW033683	FLANGE	1	65226-
10	BW053499	O-RING	1	65396-
11	BW061484	BOLT	4	65226-
13	BW043466	CAP ASS'Y	1	65226-
14	☆	· CAP	1	65226-
16	BW057262	· GASKET	1	65226-
17	BW043403	· PLATE	1	65226-
18	BW061474	· BOLT	1	65226-
20	BW065023	CLAMP	4	65226-
21	BW046270	TUBE	1	65226-
	(☒BW033609)	TUBE	1	(65226-65900)
22	BW046269	TUBE	1	65226-
	(☒BW033608)	TUBE	1	(65226-65900)
40	BW055073	GAUGE,OIL LEVEL	1	65396-
43	BW045167	BRACKET	3	65226-
44	BW065006	CLAMP	7	65226-
45	BW061456	BOLT	7	65226-
46	BW063036	NUT	7	65226-

**HA270-1 S/N 65226-UP**  
**FUEL OIL TANK**

Item	Part No.	Part Name	Qty	Serial No.
47	BW063348	WASHER	3	65432-
50	BW066866	RING,SEAL	3	65706-
51	BW065786	CONNECTOR	1	65706-
52	BW055348	COCK,DRAIN	1	65706-
53	BW065494	PLUG	1	65706-
60	BW046073	SEAL,NOISE REDUCTION	1	65831-
61	BW046074	SEAL,NOISE REDUCTION	1	65831-

**HA270-1 S/N 65226-UP  
@@Q37097**



Ref. 1401

Page 030080

**HA270-1 S/N 65226-UP  
ENGINE CONTROL(#65226-65660)**


Item	Part No.	Part Name	Qty	Serial No.
1	BW051202	CABLE,ENGINE STOP	1	65226-65660
2	BW063350	WASHER	1	65226-65660
3	BW066322	GROMMET	1	65226-65660
4	BW033639	BRACKET	1	65226-65660
5	BW061472	SCREW	2	65226-65660
6	BW051300	NUT	2	65226-65660
7	BW045122	LEVER,ENGINE STOP	1	65226-65660
9	BW051294	STOPPER	1	65226-65660
10	BW062159	BOLT	1	65226-65660
11	BW063102	NUT	1	65226-65660
15	BW051267	PEDAL,ACCELERATOR	1	65226-65660
16	BW051261	PIN,CLEVIS	1	65226-65660
17	BW066778	PIN,COTTER	1	65226-65660
18	BW051264	BELLOWS,RUBBER	1	65226-65660
19	BW062162	SCREW	2	65226-65660
20	BW051262	ROD	1	65226-65660
21	BW063101	NUT	1	65226-65660
22	BW052089	YOKE,JOINT (WITH PIN)	1	65226-65660
23	BW045528	PLATE	1	65226-65660
24	BW057160	CLIP	2	65226-65660
25	BW033535	SHAFT	1	65232-65660
	BW033618	SHAFT	1	65226-65231
26	BW066532	BUSHING	2	65226-65660
27	BW040926	WASHER	2	65226-65660
28	BW033534	BRACKET	1	65226-65660
29	BW061476	BOLT	2	65226-65660
30	BW063345	WASHER	2	65226-65660
31	BW063098	NUT	2	65226-65660
32	BW061503	BOLT	1	65226-65660

**HA270-1 S/N 65226-UP**  
**ENGINE CONTROL(#65226-65660)**

---

Item	Part No.	Part Name	Qty	Serial No.
33	BW063102	NUT	1	65226-65660
34	BW051270	JOINT,BALL	2	65226-65660
35	BW051271	PLUG	2	65226-65660
37	BW063098	NUT	2	65226-65660
38	BW044892	ROD	1	65226-65660
39	BW041155	SPRING	1	65226-65660
40	BW051272	STUD,BALL	2	65226-65660
41	BW033742	BRACKET	1	65226-65660

HA270-1 S/N 65226-UP  
 @@Q37098



Ref. 1451

Page 030090


HA270-1 S/N 65226-UP  
 ENGINE CONTROL(#65661-)

Item	Part No.	Part Name	Qty	Serial No.
1	BW351158	CABLE,ENGINE STOP	1	65661-
2	BW351155	KNOB,ENGINE STOP	1	65661-
3	BW044834	BRACKET	1	65661-
4	BW061160	BOLT	4	65661-
5	BW063035	NUT	4	65661-
6	BW066322	GROMMET	1	65661-
7	BW045916	BRACKET	1	65661-
8	BW045122	LEVER,ENGINE STOP	1	65661-
9	BW051294	STOPPER	1	65661-
10	BW062159	BOLT	1	65661-
12	BW045914	PEDAL,ACCELERATOR	1	65661-
12A	☆	PLATE,FLOOR (SEE FIG.7401)	1	65661-
13	BW351252	CUSHION,RUBBER	1	65661-
14	BW061481	BOLT	1	65661-
15	BW063100	NUT	1	65661-
16	BW061459	BOLT	3	65661-
17	BW063036	NUT	3	65661-
18	BW034220	BRACKET	1	65661-
18A	BW056286	SWITCH,EXHAUST BRAKE	1	65661-
19	BW034221	PLATE	1	65661-
20	BW061454	BOLT	2	65661-
21	BW351153	CABLE,ACCELERATOR	1	65661-
22	BW351154	YOKE,JOINT (WITH PIN)	1	65661-
23	BW034218	BRACKET	1	65661-
24	BW061485	BOLT	2	65661-
26	BW351169	SPRING	1	65661-
27	BW351156	CABLE,ACCELERATOR (HAND CONTROL)	1	65661-
28	BW066322	GROMMET	1	65661-
29	BW034225	LEVER,ENGINE CONTROL	1	65661-

**HA270-1 S/N 65226-UP**  
**ENGINE CONTROL(#65661-)**

Item	Part No.	Part Name	Qty	Serial No.
30	BW351194	PUSH ROD KIT	1	65661-
31	BW351196	LEVER KIT,HAND CONTROL	1	65661-
32	BW351197	ASSEMBLY KIT,ENGINE CONTROL	1	65661-
33	BW351195	ASSEMBLY KIT,ACCELERATOR	1	65661-

HA270-1 S/N 65226-UP  
 @@Q37099



Ref. 1501

Page 030100

HA270-1 S/N 65226-UP  
 ENGINE AIR INTAKE SYSTEM


Item	Part No.	Part Name	Qty	Serial No.
1	BW151568	COVER	1	65226-
2	BW065040	CLAMP	1	65226-
3	BW044904	CLAMP	1	65226-
4	BW021882	BRACKET	1	65226-
5	BW063346	WASHER	2	65226-
6	BW063038	NUT	2	65226-
7	BW061478	BOLT	2	65226-
8	BW063346	WASHER	2	65226-
9	BW063038	NUT	2	65226-
10	BW351114	PIPE	1	65226-
11	BW065040	CLAMP	1	65226-
12	BW057436	COUPLING,RUBBER	1	65226-
13	BW065040	CLAMP	1	65226-
14	BW151447	CLAMP	2	65226-
15	BW063039	NUT	4	65226-
15A	BW063348	WASHER	4	65226-
16	BW061487	BOLT	4	65226-
17	BW065040	CLAMP	1	65226-
18	BW057404	CONNECTOR,RUBBER	1	65226-
19	BW065038	CLAMP	1	65226-
20	BW022023	ELBOW	1	65226-
21	BW061484	BOLT	2	65226-
22	BW046303	HOSE	1	65901-
	BW033650	HOSE	1	65226-65900
23	BW065038	CLAMP	2	65226-
24	BW011273	ELBOW	1	65236-
	BW021911	ELBOW	1	65226-65235
25	BW251340	PLUG	1	65236-
26	BW033630	BRACKET	1	65226-



**HA270-1 S/N 65226-UP  
ENGINE AIR INTAKE SYSTEM**

Item	Part No.	Part Name	Qty	Serial No.
28	BW061492	BOLT	2	65226-
29	BW065037	CLAMP	1	65226-
30	BW046306	HOSE	1	65901-
	BW033629	HOSE	1	65226-65900
31	BW065037	CLAMP	1	65226-
32	BW045772	BRACKET	1	65432-
	BW045147	BRACKET	1	65226-65431
33	BW044259	RUBBER	1	65226-
34	BW065037	CLAMP	1	65226-
35	BW061485	BOLT	1	65226-
41	BW251326	NIPPLE	1	65226-
42	BW066314	GROMMET	1	65226-
43	BW045602	HOSE	1	65226-
47	BW051527	METER,VACUUM	1	65226-
50	BW151446	AIR CLEANER ASS'Y	1	65226-
51	☆	· HOUSING	1	65226-
52	BW151570	· ELEMENT,INNER	1	65226-
53	BW051154	· WASHER	1	65226-
54	BW351108	· NUT,WING	1	65226-
55	BW151571	· ELEMENT,OUTER	1	65226-
56	BW051154	· WASHER	1	65226-
57	BW351108	· NUT,WING	1	65226-
58	BW351111	· COVER	1	65226-
59	BW351110	· CLAMP	1	65226-
60	BW351109	· O-RING	1	65226-
61	BW151576	· COVER	1	65226-
62	BW151572	· VALVE	1	65226-
65	BW045753	RUBBER	1	65432-
66	BW065036	CLAMP	2	65226-

HA270-1 S/N 65226-UP  
 @@Q37100



Ref. 1511

Page 030110

HA270-1 S/N 65226-UP  
 ENGINE EXHAUST SYSTEM

Item	Part No.	Part Name	Qty	Serial No.
1	BW021879	PIPE	1	65226-
	BW021933	PIPE,(FOR GERMANY)	1	65226-
	BW057482	CAP,(FOR GERMANY)	1	65226-
2	BW044918	CLAMP	1	65226-
3	BW033546	BRACKET	1	65226-
	BW033852	BRACKET,(FOR GERMANY)	1	65226-
4	BW051576	CUSHION	1	65226-
5	BW063388	WASHER	2	65226-
6	BW063038	NUT	2	65226-
7	BW063346	WASHER	2	65226-
8	BW063100	NUT	2	65226-
9	BW151443	CLAMP	2	65226-
10	BW051522	COVER	1	65226-
11	BW051521	HANDLE	1	65226-
12	BW051524	CLAMP,(WITH NUT)	1	65226-
13	BW063390	WASHER	2	65226-
14	BW051520	CLAMP	1	65226-
15	BW033533	PIPE	1	65226-
16	BW051513	CLAMP	2	65226-
17	BW044909	HOSE,FLEXIBLE	1	65226-
18	BW044908	PIPE	1	65226-
19	BW051368	MUFFLER	1	65226-
20	BW051576	CUSHION	4	65226-
21	BW063346	WASHER	8	65226-
22	BW063100	NUT	8	65226-
23	BW051359	CLAMP	1	65226-
24	BW032072	PIPE	1	65226-
25	BW051570	GASKET	1	65226-
33	BW054194	CLAMP	2	65226-

**HA270-1 S/N 65226-UP**  
**ENGINE EXHAUST SYSTEM**

Item	Part No.	Part Name	Qty	Serial No.
35	BW044910	HOSE,FLEXIBLE	1	65226-
36	BW051513	CLAMP	2	65226-
37	BW021894	PIPE	1	65226-
38	BW060495	BOLT	4	65226-
39	BW044979	STAY	1	65226-
40	BW060468	BOLT	2	65226-
41	BW063390	WASHER	4	65226-
42	BW063101	NUT	2	65226-
43	BW021893	PIPE	1	65226-
46	BW022050	COVER	1	65386-
49	BW043840	BRACKET	2	65386-
50	BW061459	BOLT	2	65386-
51	BW063344	WASHER	2	65386-
52	BW063036	NUT	2	65386-
53	BW063100	NUT	2	65836-
54	BW063038	NUT	2	65386-


**HA270-1 S/N 65226-UP**  
**TORQUE CONVERTER AND TRANSMISSION**

Item	Part Name	Qty
10	TORQUE CONVERTER CASE (T/M NO.4644 026 011)(#65226-66999)	1
20	TORQUE CONVERTER (T/M NO.4644 026 011)(#65226-66999)	1
30	TRANSMISSION CASE (T/M NO.4644 026 011)(#65226-66999)	1
40	TRANSMISSION CONTROL VALVE (T/M NO.4644 026 011)(#65226-66999)	1
50	TRANSMISSION CONTROL VALVE AND ELECTRICAL (T/M NO.4644 026 011)(#65226-66999)	1
60	TRANSMISSION SHIFT CONTROLER (T/M NO.4644 026 011)(#65226-66999)	1
70	PRESSURE REGULATOR VALVE (T/M NO.4644 026 011)(#65226-66999)	1
80	INDUCT TRANSMITTER (T/M NO.4644 026 011)(#65226-66999)	1
90	TRANSMISSION OIL FILTER (T/M NO.4644 026 011)(#65226-66999)	1
100	PIPING SYSTEM (T/M NO.4644 026 011)(#65226-66999)	1
110	EMERGENCY STEERING PUMP (T/M NO.4644 026 011)(#65226-66999)	1
120	SPEED METER OUT PUT UNIT (T/M NO.4644 026 011)(#65226-66999)	1
130	TRANSMISSION OIL DIPSTICK (T/M NO.4644 026 011)(#65226-66999)	1
140	DRIVE ASS'Y (T/M NO.4644 026 011)(#65226-66999)	1
150	COUNTER SHAFT (T/M NO.4644 026 011)(#65226-66999)	1
160	CLUTCH ASS'Y?(KV + K1) (T/M NO.4644 026 011)(#65226-66999)	1
170	CLUTCH ASS'Y?(KR + K2) (T/M NO.4644 026 011)(#65226-66999)	1
180	CLUTCH ASS'Y?(K4 + K3) (T/M NO.4644 026 011)(#65226-66999)	1
190	INTER AXLE DIFFERENTIAL (T/M NO.4644 026 011)(#65226-66999)	1
200	POWER TAKE OFF (1/2) (T/M NO.4644 026 011)(#65226-66999)	1
210	POWER TAKE OFF (2/2) (T/M NO.4644 026 011)(#65226-66999)	1
220	FRONT DIFFERENTIAL CASE (T/M NO.4644 026 011)(#65226-66999)	1
230	FRONT DIFFERENTIAL GEAR (T/M NO.4644 026 011)(#65226-66999)	1
240	INTER AXLE DIFFERENTIAL LOCK CONTROLER (T/M NO.4644 026 011)(#65226-66999)	1
250	TORQUE CONVERTER OIL COOLER (T/M NO.4644 026 011)(#65226-66999)	1
260	TRANSMISSION MOUNTING BRACKET?FRONT (T/M NO.4644 026 011)(#65226-66999)	1
270	TRANSMISSION MOUNTING BRACKET?REAR (T/M NO.4644 026 011)(#65226-66999)	1
280	TORQUE CONVERTER CASE (T/M NO.4644 026 201)(#65226-66999)	1
290	TORQUE CONVERTER (T/M NO.4644 026 201)(#65226-66999)	1
300	TRANSMISSION CASE (T/M NO.4644 026 201)(#65226-66999)	1
310	TRANSMISSION CONTROL VALVE (T/M NO.4644 026 201)(#65226-66999)	1
320	TRANSMISSION CONTROL VALVE AND ELECTRICAL (T/M NO.4644 026 201)(#65226-66999)	1
330	TRANSMISSION SHIFT CONTROLER (T/M NO.4644 026 201)(#65226-66999)	1
340	PRESSURE REGULATOR VALVE (T/M NO.4644 026 201)(#65226-66999)	1
350	INDUCT TRANSMITTER (T/M NO.4644 026 201)(#65226-66999)	1
360	TRANSMISSION OIL FILTER (T/M NO.4644 026 201)(#65226-66999)	1
370	PIPING SYSTEM (T/M NO.4644 026 201)(#65226-66999)	1
380	EMERGENCY STEERING PUMP (T/M NO.4644 026 201)(#65226-66999)	1
390	SPEED METER OUT PUT UNIT (T/M NO.4644 026 201)(#65226-66999)	1
400	TRANSMISSION OIL DIPSTICK (T/M NO.4644 026 201)(#65226-66999)	1
410	DRIVE ASS'Y (T/M NO.4644 026 201)(#65226-66999)	1
420	COUNTER SHAFT (T/M NO.4644 026 201)(#65226-66999)	1
430	CLUTCH ASS'Y?(KV + K1) (T/M NO.4644 026 201)(#65226-66999)	1
440	CLUTCH ASS'Y?(KR + K2) (T/M NO.4644 026 201)(#65226-66999)	1
450	CLUTCH ASS'Y?(K4 + K3) (T/M NO.4644 026 201)(#65226-66999)	1
460	INTER AXLE DIFFERENTIAL (T/M NO.4644 026 201)(#65226-66999)	1
470	POWER TAKE OFF (T/M NO.4644 026 201)(#65226-66999)	1
480	FRONT DIFFERENTIAL CASE (T/M NO.4644 026 201)(#65226-66999)	1
490	FRONT DIFFERENTIAL GEAR (T/M NO.4644 026 201)(#65226-66999)	1
500	INTER AXLE DIFFERENTIAL LOCK CONTROLER (T/M NO.4644 026 201)(#65226-66999)	1
510	TORQUE CONVERTER OIL COOLER (T/M NO.4644 026 201)(#65226-66999)	1
520	TRANSMISSION MOUNTING BRACKET?FRONT (T/M NO.4644 026 201)(#65226-66999)	1
530	TRANSMISSION MOUNTING BRACKET?REAR (T/M NO.4644 026 201)(#65226-66999)	1
540	TORQUE CONVERTER CASE (T/M NO.4644 026 063)(#311001-)	1
550	TORQUE CONVERTER (T/M NO.4644 026 063)(#311001-)	1
560	TRANSMISSION CASE (T/M NO.4644 026 063)(#311001-)	1
570	TRANSMISSION CONTROL VALVE (T/M NO.4644 026 063)(#311001-)	1
580	TRANSMISSION CONTROL VALVE AND ELECTRICAL (T/M NO.4644 026 063)(#311001-)	1
590	TRANSMISSION SHIFT CONTROLER (T/M NO.4644 026 063)(#311001-)	1
600	PRESSURE REGULATOR VALVE (T/M NO.4644 026 063)(#311001-)	1
610	INDUCT TRANSMITTER (T/M NO.4644 026 063)(#311001-)	1
620	TRANSMISSION OIL FILTER (T/M NO.4644 026 063)(#311001-)	1
630	PIPING SYSTEM (T/M NO.4644 026 063)(#311001-)	1
640	EMERGENCY STEERING PUMP (T/M NO.4644 026 063)(#311001-)	1
650	SPEED METER OUT PUT UNIT (T/M NO.4644 026 063)(#311001-)	1
660	TRANSMISSION OIL DIPSTICK (T/M NO.4644 026 063)(#311001-)	1

**HA270-1 S/N 65226-UP**  
**TORQUE CONVERTER AND TRANSMISSION**

Item	Part Name	Qty
670	DRIVE ASS'Y (T/M NO.4644 026 063)(#311001-)	1
680	COUNTER SHAFT (T/M NO.4644 026 063)(#311001-)	1
690	CLUTCH ASS'Y?(KV + K1) (T/M NO.4644 026 063)(#311001-)	1
700	CLUTCH ASS'Y?(KR + K2) (T/M NO.4644 026 063)(#311001-)	1
710	CLUTCH ASS'Y?(K4 + K3) (T/M NO.4644 026 063)(#311001-)	1
720	INTER AXLE DIFFERENTIAL (T/M NO.4644 026 063)(#311001-)	1
730	POWER TAKE OFF (T/M NO.4644 026 063)(#311001-)	1
740	FRONT DIFFERENTIAL CASE (T/M NO.4644 026 063)(#311001-)	1
750	FRONT DIFFERENTIAL GEAR (T/M NO.4644 026 063)(#311001-)	1
760	INTER AXLE DIFFERENTIAL LOCK CONTROLER (T/M NO.4644 026 063)(#311001-)	1
770	TORQUE CONVERTER OIL COOLER (T/M NO.4644 026 063)(#311001-)	1
780	TRANSMISSION MOUNTING BRACKET?FRONT (T/M NO.4644 026 063)(#311001-311005)	1
790	TRANSMISSION MOUNTING BRACKET?FRONT (T/M NO.4644 026 063)(#311006-)	1
800	TRANSMISSION MOUNTING BRACKET?REAR (T/M NO.4644 026 063)(#311001-)	1

HA270-1 S/N 65226-UP  
 @@Q37101



Ref. 2001


Page 060010

HA270-1 S/N 65226-UP  
 TORQUE CONVERTER CASE (T/M NO.4644 026 011)(#65226-66999)

Item	Part No.	Part Name	Qty	Serial No.
10	BW152143	CASE,TORQUE CONVERTER	1	65226-66999
30	BW152200	BOLT	14	65226-66999
40	BW060711	PIN,SPRING	2	65226-66999
44	BW060725	PIN,SPRING	2	65226-66999
60	BW152026	COVER	1	65226-66999
110	BW152027	BEARING	1	65226-66999
130	BW052523	RING,SNAP	1	65226-66999
160	BW152028	FLANGE	1	65226-66999
180	BW052526	HOLDER	1	65226-66999
190	BW052527	PLATE	1	65226-66999
200	BW052528	BOLT	2	65226-66999
210	BW053266	BOLT	8	65226-66999
220	BW060479	BOLT	12	65226-66999
240	BW063101	NUT	12	65226-66999

HA270-1 S/N 65226-UP  
 @@Q37102

To Fig. 2191



To Fig. 2001

Ref. 2011

Page 060020


HA270-1 S/N 65226-UP  
 TORQUE CONVERTER (T/M NO.4644 026 011)(#65226-66999)

Item	Part No.	Part Name	Qty	Serial No.
	BW152146	TORQUE CONVERTER A.	1	65226-66999
10	BW152029	· COVER	1	65226-66999
60	BW152198	· BOLT	24	65226-66999
65	BW060453	· BOLT	12	65226-66999
70	BW152340	· WASHER	36	65226-66999
75	BW063100	· NUT	12	65226-66999
80	BW052531	· GASKET	1	65226-66999
90	BW052532	· PLATE,PISTON	1	65226-66999
100	BW052533	· RING	1	65226-66999
110	BW052534	· RING	1	65226-66999
120	BW052535	· DISC,INNER	1	65226-66999
130	BW052536	· DISC,OUTER	3	65226-66999
140	BW052537	· ROLLER	12	65226-66999
150	BW052538	· PLATE,BACK-UP	1	65226-66999
160	BW052539	· BOLT	12	65226-66999
170	BW052540	· RING,SPRING	1	65226-66999
180	BW152923	· SHIM ASS'Y	1	65226-66999
	☆	· · SHIM, 2.6MM	1	65226-66999
	☆	· · SHIM, 2.7MM	1	65226-66999
	☆	· · SHIM, 3.1MM	1	65226-66999
	☆	· · SHIM, 3.2MM	1	65226-66999
	☆	· · SHIM, 3.4MM	1	65226-66999
190	BW052542	· RING,SNAP	1	65226-66999
200	BW052543	· HUB,TURBINE	1	65226-66999
210	BW061475	· BOLT	16	65226-66999
220	BW152340	· WASHER	16	65226-66999
230	BW052544	· SEAL,OIL	1	65226-66999
240	BW052545	· BEARING	1	65226-66999
250	BW052546	· SHIM, 1.0MM	2	65226-66999

**HA270-1 S/N 65226-UP**  
**TORQUE CONVERTER (T/M NO.4644 026 011)(#65226-66999)**

Item	Part No.	Part Name	Qty	Serial No.
260	BW052547	· SHIM, 0.1MM,0.1MM	1	65226-66999
	BW152219	· SHIM, 0.2MM,0.2MM	1	65226-66999
	BW152220	· SHIM, 0.5MM,0.5MM	1	65226-66999
270	BW052548	· SPACER	2	65226-66999
280	BW052549	· PLATE	2	65226-66999
290	BW052550	· CAGE,NEEDLE	1	65226-66999
300	BW152030	· CAGE,ROLLER	1	65226-66999
310	BW052552	· RING,SNAP	1	65226-66999
320	BW052553	· FLANGE	1	65226-66999
330	BW052554	· GASKET	1	65226-66999
340	BW061475	· BOLT	12	65226-66999
350	BW152340	· WASHER	12	65226-66999
360	BW052013	· O-RING	1	65226-66999
500	BW152144	· WHEEL,PUMP	1	65226-66999
510	BW152110	· WHEEL,TURBINE	1	65226-66999
520	BW152145	· STATOR	1	65226-66999
600	BW052558	· RANGE,FLYWHEEL	1	65226-66999
610	BW052559	· ROLLER	28	65226-66999
620	BW052560	· CAP,SPRING	28	65226-66999
630	BW052561	· SPRING	28	65226-66999
640	BW052562	· ROLLER	28	65226-66999
650	BW052563	· WASHER,THRUST	2	65226-66999
660	BW052564	· BEARING	2	65226-66999
670	BW052565	· RACE,FLYWHEEL	1	65226-66999






HA270-1 S/N 65226-UP  
**TRANSMISSION CASE (T/M NO.4644 026 011)(#65226-66999)**

Item	Part No.	Part Name	Qty	Serial No.
10	BW052566	HOUSING,TRANSMISSION	1	65226-66999
30	BW052568	PLUG	1	65226-66999
40	☆	PLATE, NAME	1	65226-66999
50	BW052570	PIN,GROOVE	4	65226-66999
60	BW052571	SOCKET,TRANSMISSION OIL TEMPERATURE	1	65226-66999
70	BW052572	O-RING	1	65226-66999
80	BW052574	PLATE	1	65226-66999
90	BW052573	COVER	1	65226-66999
100	BW061474	BOLT	3	65226-66999
110	BW152340	WASHER	3	65226-66999
120	BW052575	CAP,END	2	65226-66999
140	BW052576	O-RING	1	65226-66999
150	BW252026	PLUG	1	65226-66999
320	BW052580	O-RING	1	65226-66999
330	BW052581	PLUG	1	65226-66999
370	BW152031	COVER	1	65226-66999
450	BW052583	PLUG	1	65226-66999
460	BW052584	O-RING	1	65226-66999
530	BW052585	BREATHER	1	65226-66999
760	BW152032	COVER	1	65226-66999

HA270-1 S/N 65226-UP  
 @@Q37104




Ref. 2111

Page 060040

HA270-1 S/N 65226-UP  
**TRANSMISSION CONTROL VALVE (T/M NO.4644 026 011)(#65226-66999)**

Item	Part No.	Part Name	Qty	Serial No.
10	BW052603	PLATE,VALVE	1	65226-66999
20	BW052604	GASKET	1	65226-66999
24	BW152114	GASKET	1	65226-66999
30	BW152037	PLATE,VALVE	1	65226-66999
50	BW152038	ORIFICE	1	65226-66999
60	BW052608	BALL	2	65226-66999
70	BW052609	SPRING	2	65226-66999
80	BW152891	BOLT	3	65226-66999
100	BW152039	BOLT	3	65226-66999
120	BW152040	BOLT	6	65226-66999
140	BW152041	PLATE,VALVE	1	65226-66999
150	BW052612	GASKET	1	65226-66999
154	BW152115	GASKET	1	65226-66999
160	BW152039	BOLT	10	65226-66999
180	BW152042	BOLT	6	65226-66999
260	BW052613	PLUG	1	65226-66999
270	BW052614	O-RING	1	65226-66999
280	BW152043	PLUG	1	65226-66999
350	BW056035	SENSOR,TRANSMISSION OIL PRESSURE	1	65226-66999
360	BW052614	O-RING	1	65226-66999

**HA270-1 S/N 65226-UP  
@@Q37105**



Ref. 2113

Page 060050

**HA270-1 S/N 65226-UP  
TRANSMISSION CONTROL VALVE AND ELECTRICAL (T/M NO.4644 026  
011)(#65226-66999)**

Item	Part No.	Part Name	Qty	Serial No.
	BW152986	CONTROL ASS'Y,SHIFT	1	65226-66999
10	BW152154	· BODY,VALVE	1	65226-66999
20	BW052618	· DETENT	1	65226-66999
30	BW152045	· SPRING	1	65226-66999
40	BW152046	· SPOOL	1	65226-66999
50	BW052621	· SPRING	1	65226-66999
60	BW152193	· SPACER,0.5MM	1	65226-66999
	BW152273	· SPACER,1.0MM	1	65226-66999
	BW152274	· SPACER,2.0MM	1	65226-66999
	BW152275	· SPACER,3.0MM	1	65226-66999
	BW152276	· SPACER,5.0MM	1	65226-66999
70	BW152194	· SHIM	1	65226-66999
80	BW152047	· SLEEVE	1	65226-66999
84	BW060707	· PIN,SPRING	1	65226-66999
90	BW052624	· PISTON	1	65226-66999
100	BW052623	· SPRING	1	65226-66999
110	BW052625	· DETENT	1	65226-66999
120	BW052626	· O-RING	1	65226-66999
130	BW052627	· PISTON	1	65226-66999
140	BW152301	· SPRING	1	65226-66999
150	BW052629	· SPOOL	1	65226-66999
160	BW052630	· DETENT	1	65226-66999
170	BW052631	· DETENT	1	65226-66999
180	BW052632	· PISTON	1	65226-66999
184	BW152194	· SHIM	1	65226-66999
190	BW052633	· SPRING	1	65226-66999
200	BW052623	· SPRING	1	65226-66999
210	BW052634	· PISTON	1	65226-66999


Reference:2113

Page:060050

**HA270-1 S/N 65226-UP  
TRANSMISSION CONTROL VALVE AND ELECTRICAL (T/M NO.4644 026  
011)(#65226-66999)**

Item	Part No.	Part Name	Qty	Serial No.
220	BW052625	· DETENT	1	65226-66999
230	BW052626	· O-RING	1	65226-66999
240	BW052635	· DETENT	1	65226-66999
250	BW052630	· DETENT	1	65226-66999
260	BW052623	· SPRING	1	65226-66999
270	BW052636	· PISTON	1	65226-66999
280	BW052623	· SPRING	1	65226-66999
290	BW052637	· PISTON	1	65226-66999
300	BW052625	· DETENT	1	65226-66999
310	BW052626	· O-RING	1	65226-66999
350	BW052640	· VALVE,SOLENOID	4	65226-66999
355	BW152764	· O-RING	4	65226-66999
358	BW152765	· O-RING	4	65226-66999
360	BW152892	· BOLT	8	65226-66999
370	BW152162	· WASHER,SPRING	8	65226-66999
380	BW052641	· WIRING HARNESS,TRANSMISSION CONTROL	1	65226-66999
400	BW152048	· BOLT	4	65226-66999
410	BW152651	· WASHER,SPRING	4	65226-66999
460	BW052644	· COVER	1	65226-66999
470	BW052645	· O-RING	1	65226-66999
480	BW052646	· CLAMP	1	65226-66999
490	BW052613	· PLUG	10	65226-66999
500	BW052614	· O-RING	10	65226-66999
560	BW152970	· HOUSING,VALVE	1	65226-66999
580	BW152156	· BALL	1	65226-66999
590	BW152157	· BALL	1	65226-66999
600	BW152158	· BALL	1	65226-66999
610	BW152159	· PISTON	1	65226-66999
620	BW152187	· SPRING	1	65226-66999
630	BW152188	· PLUG	1	65226-66999
640	BW152160	· O-RING	1	65226-66999
650	BW252259	· VALVE	1	65226-66999
660	BW152161	· O-RING	1	65226-66999
670	BW152892	· BOLT	2	65226-66999
680	BW152162	· WASHER,SPRING	2	65226-66999
690	BW152163	· GASKET	1	65226-66999
700	BW152893	· BOLT	11	65226-66999

HA270-1 S/N 65226-UP  
 @@Q37106




Ref. 2115

Page 060060

HA270-1 S/N 65226-UP  
**TRANSMISSION SHIFT CONTROLER (T/M NO.4644 026 011)(#65226-66999)**

Item	Part No.	Part Name	Qty	Serial No.
1	BW152900	SELECTOR,GEAR	1	65616-66999
	BW152767	SELECTOR,GEAR	1	65421-65615
	BW152133	SELECTOR,GEAR	1	65226-65420
	BW152901	SELECTOR,GEAR (FOR SWEEDEN)	1	65226-66999
2	BW044407	PLATE	2	65226-66999
3	BW061474	BOLT	2	65226-66999
4	BW063260	WASHER	2	65226-66999
5	BW152759	MODULE	1	65226-66999
6	BW062178	BOLT	3	65226-66999
7	BW063343	WASHER	3	65226-66999
8	BW063097	NUT	3	65226-66999

HA270-1 S/N 65226-UP  
 @@Q37107



Ref. 2121

Page 060070

HA270-1 S/N 65226-UP  
**PRESSURE REGULATOR VALVE (T/M NO.4644 026 011)(#65226-66999)**

Item	Part No.	Part Name	Qty	Serial No.
80	(BW152151)	FLANGE,(SEE FIG.2191)	1	65226-66999
180	(BW052713)	GASKET,(SEE FIG.2191)	1	65226-66999
184	(BW052714)	GEAR PUMP,(SEE FIG.2191)	1	65226-66999
710	BW052650	BALL	1	65226-66999
720	BW052651	SPRING	1	65226-66999
730	BW052652	SLEEVE,VALVE	1	65226-66999
740	BW052653	PISTON	1	65226-66999
750	BW052654	SPRING	1	65226-66699
760	BW052655	WASHER	1	65226-66999
770	BW052656	RING,RETAINER	1	65226-66999
780	BW152049	PIN	1	65226-66999
790	BW052657	RING,RETAINER	1	65226-66999



**Download the full PDF manual instantly.**

**Our customer service e-mail:**

**[aservicemanualpdf@yahoo.com](mailto:aservicemanualpdf@yahoo.com)**